

# SmartGen

MAKING CONTROL SMARTER

## HPM6/HPM6D POWER MANAGEMENT CONTROLLER USER MANUAL



郑州众智科技股份有限公司  
SMARTGEN(ZHENGZHOU)TECHNOLOGY CO.,LTD.

## SmartGen Registered Trademark

No. 28 Xuemei Street, Zhengzhou, Henan, China

Tel: +86-371-67988888/67981888/67992951

+86-371-67981000(overseas)

Fax: +86-371-67992952

Web: [www.smartgen.com.cn/](http://www.smartgen.com.cn/)

[www.smartgen.cn/](http://www.smartgen.cn/)

Email: [sales@smartgen.cn](mailto:sales@smartgen.cn)

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

SmartGen Technology reserves the right to change the contents of this document without prior notice.

**Table 1 – Version History**

Date	Version	Contents
2021-11-26	1.0	Original release.
2022-09-19	1.1	1. Modify the error in typical application diagram; 2. Update company logo.
2022-11-22	1.2	Modify the product model as "HMP6/HPM6D".

This manual is suitable for HPM6/HPM6D power management controller only.

**Table 2 – Notation Clarification**

Sign	Instruction
 NOTE	Highlights an essential element of a procedure to ensure correctness.
 CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
 WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.
X	Indicates the controller without this function.
√	Indicates the controller with this function.

SmartGen


# CONTENTS

1. OVERVIEW.....	7
2. MODEL CONFIGURATION .....	7
3. PERFORMANCE AND CHARACTERISTICS.....	7
4. FUNCTION DESCRIPTION .....	9
4.1 HPM6-DG FUNCTION DESCRIPTION .....	9
4.1.1 FUNCTION.....	9
4.1.2 PROTECTION .....	9
4.1.3 DISPLAY PANEL.....	9
4.1.4 POWER MANAGEMENT .....	10
4.2 HPM6-SG FUNCTION DESCRIPTION .....	10
4.2.1 OPERATION.....	10
4.2.2 PROTECTION .....	10
4.2.3 DISPLAY PANEL.....	11
4.2.4 POWER MANAGEMENT .....	11
5. SPECIFICATION .....	12
6. OPERATION.....	15
6.1 PANEL DISPLAY .....	15
6.2 KEY FUNCTION DESCRIPTION.....	17
6.3 PARAMETERS SETTING .....	18
7. DG SYSTEM MODE DESCRIPTION.....	20
7.1 SYSTEM MODE.....	20
7.1.1 MANUAL MODE .....	20
7.1.2 SEMI-AUTO MODE.....	20
7.1.3 AUTO MODE.....	21
7.2 START MODE DESCRIPTION.....	23
7.3 SCHEDULED MODE DESCRIPTION .....	24
8. SG SYSTEM MODE DESCRIPTION.....	25
8.1 SG SYSTEM MODE.....	25
8.1.1 MANUAL MODE .....	25
8.1.2 SEMI-AUTO MODE.....	25
8.1.3 AUTO MODE.....	26
8.2 WORKING MODE DESCRIPTION.....	27
9. PROTECTION .....	28
10. HARDWARE STRUCTURE.....	39
10.1 STRUCTURE DESCRIPTION.....	39
10.2 HPM6D MODULE.....	39
10.2.1 TERMINAL DESCRIPTION .....	39
10.2.2 TS #1 COMMUNICATION PORT .....	40
10.2.3 TS #2 RS485 COMMUNICATION, RELAY OUTPUT, POWER PORT .....	40
10.3 HPM6 MODULE.....	41
10.3.1 TERMINAL DESCRIPTION .....	41

10.3.2	TS #1 POWER AND RELAY OUTPUT PORT .....	41
10.3.3	TS #2 CANBUS AND RS485 COMMUNICATION PORT .....	42
10.3.4	TS #3 ANALOG OUTPUT PORT .....	42
10.3.5	TS #4 TRIODE OUTPUT PORT .....	43
10.3.6	TS #5 ANALOG INPUT PORT .....	43
10.3.7	TS #6, TS #7 DIGITAL INPUT PORT .....	44
10.3.8	TS #8, TS #9, TS #10 GEN/BUS VOLTAGE, GEN/EARTH CURRENT INPUT PORT .....	45
10.3.9	COMMUNICATION PORT .....	45
10.4	WIRE CONNECTION .....	46
10.4.1	TYPICAL APPLICATION DIAGRAM.....	46
10.4.2	AC WIRE CONNECTION (3 PHASE 4 WIRE) .....	46
10.4.3	AC WIRE CONNECTION (SINGLE PHASE) .....	47
10.4.4	AC WIRE CONNECTION (2 PHASE 3 WIRE) .....	47
10.4.5	ANALOG INPUT PORT .....	48
10.4.6	MSC NETWORK COMMUNICATION PORT .....	48
10.4.7	MSC APPLICATION DIAGRAM.....	49
11.	POWER MANAGEMENT AND WORKFLOW CHART .....	51
11.1	ILLUSTRATION .....	51
11.2	EQUAL LOAD SHARING .....	51
11.3	FIXED POWER OUTPUT .....	51
11.4	SYNCHRONIZATION .....	52
11.5	HEAVY CONSUMER INQUIRY .....	52
11.5.1	ILLUSTRATION.....	52
11.5.2	HEAVY CONSUMER REQUEST.....	53
11.5.3	HEAVY CONSUMER RESPONSE.....	53
11.5.4	HEAVY CONSUMER PERMISSION.....	53
11.5.5	HEAVY CONSUMER FEEDBACK .....	53
11.6	NON ESSENTIAL LOAD (NEL) TRIP.....	56
11.7	WORKFLOW CHART.....	57
11.7.1	START.....	57
11.7.2	STOP.....	58
11.7.3	CLOSE BREAKER.....	59
11.7.4	OPEN BREAKER .....	60
11.7.5	HEAVY CONSUMER.....	61
11.7.6	LIGHT CONSUMER .....	62
12.	PARAMETER SETTINGS.....	63
12.1	ILLUSTRATION .....	63
12.2	MODULE SETTING .....	63
12.3	BUS SETTING.....	67
12.4	GENERATOR SETTING.....	72
12.5	GENERATOR LOAD SETTING .....	81
12.6	TIMER SETTING .....	94
12.7	ANALOG INPUT PORTS SETTING .....	95
12.8	DIGITAL INPUT PORTS SETTING .....	99

---

12.9	DIGITAL OUTPUT PORTS SETTING.....	108
12.10	ANALOG OUTPUT PORTS SETTING.....	123
12.11	GB SETTING.....	126
12.12	SYNCHRONIZATION SETTING.....	127
12.13	SYNCHRONOUS CALIBRATION .....	130
12.14	ENGINE SETTING .....	134
12.15	DISPLAY SETTING .....	134
12.16	USER-DEFINED PROTOCOL FORM SETTING.....	135
12.17	DIN16 SETTING.....	136
12.18	DOUT16 SETTING .....	138
12.19	USER-DEFINED PROTOCOL SETTING .....	140
13.	COMMISSIONING .....	141
13.1	STEP 1: SINGLE UNIT DEBUGGING .....	141
13.2	STEP 2: SEMI-AUTO PARALLEL OPERATION OFF-LOAD.....	141
13.3	STEP 3: SEMI-AUTO PARALLEL OPERATION ON-LOAD .....	141
13.4	STEP 4: AUTOMATIC PARALLEL OPERATION .....	141
14.	INSTALLATION .....	142
15.	FAULT FINDING .....	144



## 1. OVERVIEW

HPM6/HPM6D power management controller is a special power management system for marine applications. The system carries out genset control, protection, power detection functions. The system is a true multi-master system whose power management function is realized by calculating all generator control units. One of the control units is internally defined as the “command unit”. This unit is the one where start priority and other power management-related functions are calculated.

HPM6 can realize up to 20 gensets automatic synchronization and load sharing. Should the command unit fail, the power management calculations will automatically be transferred to the next available control unit. Each control unit is connected via network bus, which has device level ring redundancy function.

## 2. MODEL CONFIGURATION

According to the functions, it is divided into HPM6-DG diesel genset power management controller and HPM6-SG genset power management controller. All controllers share one set of hardware (master control module + display module).

## 3. PERFORMANCE AND CHARACTERISTICS

HPM6 power management controller adopts split-type design, which is composed of display module HPM6D and master control module HPM6.

- 4.3-inch LCD, 480x272 resolution with backlight, Chinese, English and other languages display interface;
- Suitable for 3-phase 4-wire, 3-phase 3-wire, 2-phase 3-wire and single phase systems with frequency 50/60Hz;
- PLC function enables user to define control logic;
- User-defined system SLD function;
- 3-level password protection, two password permissions can customize user configuration items, i.e. configuration items that user can modify can be customized;
- 3 accumulated data, two user accumulated data (user A and user B), user can clear accumulated data. 3 accumulated data are simultaneously and synchronously calculated, but user A and user B data can be cleared at any time;
- Parameter setting: parameters can be modified, most of them can be configured from front panel of the controller and all of them can be configured using PC via USB, RS485 or RJ45 ports;
- Alarm log, which cannot be lost even in case of power outage, maximum 500 pieces can be recorded;
- Event log, which cannot be lost even in case of power outage, maximum 500 pieces can be recorded;
- User-defined protocol content function;
- User-defined bus data function, can read other genset controller data from one controller;
- Harmonic analysis and generator voltage, current waveform display function;
- Monitor data curve at real time;

- Black box function, record data before and after alarm, do data analysis and find problem via PC software;
- Master control module can record USB, open USB record via PC software can do data analysis;
- Display module can open USB, save configuration files.

SmartGen

## 4. FUNCTION DESCRIPTION

### 4.1 HPM6-DG FUNCTION DESCRIPTION

#### 4.1.1 FUNCTION

- Support up to 16 master diesel gensets
- Load distribution (load sharing, fixed power output) between diesel gensets
- 4 heavy consumer inquiry for each controller
- Safe mode (reserve an additional unit running)
- Reserved power (reserve appropriate power for bus running)
- Drop power (run at the set percentage of rated power)
- Start/stop control
- Synchronous close
- Soft loading/unloading
- Engine speed adjusting control: relay output, analog voltage output, analog current output
- Genset voltage adjusting control: relay output, analog voltage output, analog current output

#### 4.1.2 PROTECTION

- Over current, 6-level
- Reverse power, 2-level
- Over power, 2-level
- Over voltage, 3-level
- Under voltage, 3-level
- Over frequency, 3-level
- Under frequency, 3-level
- Unbalanced voltage, 2-level
- Unbalanced current, 2-level
- ROCOF, 2-level
- Vector shift, 2-level
- Loss of excitation, 2-level
- Power factor low, 2-level
- Voltage single and total harmonics, 2-level
- Current single and total harmonics, 2-level
- Earth fault, 2-level
- Unbalanced active power distribution, 2-level
- Unbalanced reactive power distribution, 2-level
- Loss of phase and reverse phase sequence
- Close/open failure
- Digital inputs

#### 4.1.3 DISPLAY PANEL

- Genset start/stop key
- Auto/semi-auto mode transfer key

- Breaker close/open key
- Top priority key
- ACK alarm key
- Status, alarm and information text messages

## 4.1.4 POWER MANAGEMENT

- Blackout handling
- Load-dependent start/stop
- Auto start mode selection
  - ▶ Linear start
  - ▶ Duty time start
- Auto scheduled start mode selection
  - ▶ Active power percentage
  - ▶ Left active power
  - ▶ Apparent power percentage
  - ▶ Left apparent power
- NEL priority trip (3-way for single unit)
- Light consumer active, genset will not stop when load is lower than stop load
- Reserved running gensets, minimum load running gensets on the bus
- Safety stop, safety trip
- Limited on-grid gensets
- Bus breaking handling
- Shore power handling

## 4.2 HPM6-SG FUNCTION DESCRIPTION

### 4.2.1 OPERATION

- Support up to 4 shaft gensets
- Load distribution (load sharing, fixed power output) between shaft gensets and diesel gensets
- 4 heavy consumer inquiry for each controller
- Drop power (run at the set percentage of rated power)
- Start/stop control
- Synchronous close
- Soft loading/unloading
- SG/DG load transfer
- Engine speed adjusting control: relay output, analog voltage output, analog current output
- Genset voltage adjusting control: relay output, analog voltage output, analog current output

### 4.2.2 PROTECTION

- Over current, 6-level
- Reverse power, 2-level
- Over power, 2-level
- Over voltage, 3-level
- Under voltage, 3-level
- Over frequency, 3-level

- Under frequency, 3-level
- Unbalanced voltage, 2-level
- Unbalanced current, 2-level
- ROCOF, 2-level
- Vector shift, 2-level
- Loss of excitation, 2-level
- Power factor low, 2-level
- Voltage single and total harmonics, 2-level
- Current single and total harmonics, 2-level
- Earth fault, 2-level
- Unbalanced active power distribution, 2-level
- Unbalanced reactive power distribution, 2-level
- Loss of phase and reverse phase sequence
- Close/open failure
- Digital inputs
- DG insufficient capacity
- SG insufficient capacity
- SG and DG paralleled number over
- SG and DG grid-connection timeout

#### 4.2.3 DISPLAY PANEL

- SG genset start/stop key
- Auto/semi-auto mode transfer key
- Breaker close/open key
- Top priority key
- ACK alarm key
- Status, alarm and information text messages

#### 4.2.4 POWER MANAGEMENT

- Blackout handling
- Load-dependent start/stop
- Work mode selection
  - ▶ Load takeover mode
  - ▶ Fixed power mode
  - ▶ Load sharing mode
- NEL priority trip (3-way for single unit)
- Reserved power
- Safety stop, safety trip
- Limited on-grid gensets
- Bus breaking handling
- Shore power handling

**5. SPECIFICATION**

**Table 3 – Specification Parameters**

Item	Content
Working Voltage	Range: DC8V - DC35V continuous power supply, DC reverse connection protection Resolution: 0.1V Accuracy: 1%
Overall Consumption	Display: <4W (standby: ≤2.5W) Master control: <8W (standby: ≤5W)
AC Voltage	Phase Voltage Range: AC15V - AC520V (ph-N) Resolution: 0.1V Accuracy: 0.5%
	Line Voltage Range: AC30V - AC900V (ph-ph) Resolution: 0.1V Accuracy: 0.5%
AC Frequency	Range: 5Hz - 75Hz Resolution: 0.01Hz Accuracy: 0.1Hz
AC Current	Rated: 5A Range: 0A - 15A Resolution: 0.1A Accuracy: 0.5%
Analog Inputs	Resistance Input Range: (0 - 6000)Ω Resolution: 0.1 Accuracy: 1Ω (below 300Ω)
	Voltage Input Range: (0 - 5)V Resolution: 0.001V Accuracy: 0.5%
	Current Input Range: (0 - 20)mA Resolution: 0.001mA Accuracy: 0.5%
Analog Outputs	Current Output Range: (-20 - 20)mA Resolution: 0.001mA Accuracy: 0.5%
Digital Output Port 1-2	8A DC30V Volt-free (relay output)

Item	Content
Digital Output Port 3-4	8A DC30V Active (relay output)
Digital Output Port 5	8A DC30V Volt-free (relay output)
Digital Output Port 6-7	7A DC30V Volt-free (relay output)
Digital Output Port 8-20	1A DC30V DC (transistor output)
Digital Input Port 1-20	Low on threshold voltage 4.6V, max. input voltage 60V
RS485 Port	Isolated, half-duplex, 9600bps, max. communication distance 1000m
Ethernet	Self-adaption, 10/100Mbit
MSC CAN Port	Isolated, max. communication distance 250m, use Belden 9841 cable or equivalence
CE-EMC Certificate	EN 55032, EN 55024
Vibration	5Hz~8Hz: displacement=±7.5mm 8Hz~500Hz: a=±2g IEC 60068-2-6
Shock	50g, 11ms, half-sine, three consecutive shocks are applied in each of the three mutually perpendicular directions, i.e., a total of 18 times. IEC 60068-2-27
Bump	25g, 16ms, half-sine IEC 60255-21-2
Safety Requirements	According to EN 61010-1 installation category (over voltage category) III, 300V, pollution class 2, altitude 3000m
Case Dimensions	HPM6D: 220mm x 130mm x 52mm HPM6: 250mm x 165mm x 83mm
Panel Cutout	HPM6D: 201mm x 111mm, embedded panel installation HPM6: aperture φ5.5 x 4, hole distance 237.5mm x 152.5mm, screw fixed installation
Working Temperature	(-25~+70)°C
Work Humidity	(20~93)%RH
Storage Temperature	(-30~+80)°C
Protection Level	HPM6D display module: front panel IP65, back panel IP20 when waterproof rubber ring is added between controller and control panel. HPM6 master control module: IP20
Insulation Intensity	Apply AC2.2kV voltage between high voltage terminal and low voltage terminal, leakage current is less than 3mA within 1min.
Product Standard	GB/T 2820.4-2009 Reciprocating internal combustion engine driven alternating current generating sets - Part 4: Control gear and switchgear GB/T 10250-2007 Electrical and electronic installations in ships – Electromagnetic compatibility GD 22-2015 Guidelines for type approval test of electric and electronic products E-14-2015 Generator protection gear, power station automatic control gear Rules for classification of sea-going steel ships 2015, Volume 4, Part 7:

Item	Content
	Automatic system Rules for classification of sea-going steel ships 2015, Volume 4, Part 4: Electric device, chapter 2, section 5 System protection
Weight	HPM6D display module 0.57kg; HPM6 master control module 1.31kg.

SmartGen

## 6. OPERATION

### 6.1 PANEL DISPLAY

HPM6D display module TFT LCD is 4.3 inches with 480x272 resolutions, as follows:



**Fig.1 – HPM6D Display Panel**

**Table 4 – Alarm Indicator Introduction**

Alarm Type	Indicator Color	Indicator Status
Indication Alarm	Green	Slowly flash (once per second)
Warning Alarm	Yellow	Slowly flash (once per second)
Block Alarm	Yellow	Slowly flash (once per second)
Safety Trip Alarm	Red	Fast flash (twice per second)
Safety Trip and Stop Alarm	Red	Fast flash (twice per second)
Trip Alarm	Red	Fast flash (twice per second)
Trip and Stop Alarm	Red	Fast flash (twice per second)

**NOTE1:** Alarm Indicator (red, green, yellow): flashes when alarm is not acknowledged, always illuminates when alarm is acknowledged but not disappear, extinguishes when the alarm is disappeared;

**NOTE2:** Power Indicator (green): green light always illuminates when the power is normal;

**NOTE3:** Running Indicator (red and green, yellow represents green and red lights are illuminated simultaneously):

Green light always illuminates: genset is normally running;

Red light always illuminates: ready to start signal abnormal or genset in start inhibit status;

Yellow light always illuminates: genset normal running, but standby engine starts signal abnormal or genset in start inhibit status;

Light off: genset standby and normal running;

**NOTE4:** Self-check Indicator (green): green light illuminates when self-check is normal;

**NOTE5:** Gen Normal Indicator (green): it always illuminates when generating is normal, flashes when generating is abnormal, extinguishes when there is no generating;


**NOTE6:** Bus Normal Indicator (green): it always illuminates when bus is normal, extinguishes when bus is abnormal or bus voltage blackout;

**NOTE7:** Top Priority Indicator (green): When the top priority is enabled, press current controller “Top Priority Key”, system will sort all gensets priority and set the current genset as the first (priority value is smallest), controller indicator always illuminates (on-grid genset in non-auto mode is prior to genset in auto mode), otherwise it will extinguish. When the top priority is disabled, press current controller “Top Priority Key”, indicator illuminates, representing current genset is master,

controller priority shows -1 simultaneously, press the key again, indicator extinguishes and priority shows normally. When the top priority key more than two gensets is pressed, indicators will illuminate simultaneously, representing they are all in master status, priority refers to number, smaller the number, higher the priority.

**Table 5 – Switch Status Indicator Introduction**

Alarm Type	Alarm Indicator Status
Opened	All lights between gen indicator and bus indicator (except for gen c/o indicator) illuminate according to gen and bus status.
Closed	All lights between gen indicator and bus indicator always illuminate.
Synchronous Closing	All lights between gen indicator and bus indicator cycle illuminate from left to right.
Soft-loading	All lights between gen indicator and bus indicator cycle illuminate from left to right.
Soft Unloading Opening	All lights between gen indicator and bus indicator cycle illuminate from right to left.
Close Failure	All lights between gen indicator and bus indicator flash.
Open Failure	All lights between gen indicator and bus indicator flash.
Close Feedback Failure	All lights between gen indicator and bus indicator always illuminate, but gen c/o indicator flashes.
Open Feedback Failure	All lights between gen indicator and bus indicator always illuminate, but gen c/o indicator flashes.



**Fig.2 – HPM6 Master Control Panel**

**NOTE1:** Power Indicator (red, green, yellow): green light always illuminates when power is normal, yellow light always illuminates when power is abnormal;

**NOTE2:** Running Indicator (red and green, yellow represents green and red light simultaneously): refer to display module indicator description;

**NOTE3:** Self-check Indicator (green): green light illuminates when self-checking is normal;

**NOTE4:** Alarm Indicator (red, green, yellow): refer to display module indicator description;

**NOTE5:** CAN Communication Indicator (green): flashes in communication, extinguishes in other periods;

**NOTE6:** RS485 Communication Indicator (green): flashes in communication, extinguishes in other periods.

## 6.2 KEY FUNCTION DESCRIPTION

**Table 6 – Key Description**

Icon	Key	Description
	Stop	Open and stop the parallel running genset in Semi-auto mode. Lamp test (press at least 3s).
	Start	Start the standby genset in Semi-auto mode.
	Semi-auto	Press this key and controller enters <b>Semi-auto</b> mode.
	Auto	Press this key and controller enters <b>Auto</b> mode.
	Top Priority	Place current genset at the highest priority by pressing the key. Start current genset first under corresponding running mode. Details refer to top priority indicator description.
	ACK	Press it to fast switch to alarm interface, press it in alarm interface to acknowledge all alarms, alarm indicator changes from flash to flat.
	Close	Control breaker synchronous close in <b>Semi-auto</b> mode.
	Open	Control breaker unloading open in <b>Semi-auto</b> mode.
	Up/Increase	1. Screen scroll; 2. Up cursor and increase value in setting menu.
	Down/Decrease	1. Screen scroll; 2. Down cursor and decrease value in setting menu.
	Left	1. Page scroll; 2. Left move cursor in setting menu.
	Right	1. Page scroll; 2. Right move cursor in setting menu.
	Set/Confirm	1. Press it more than 3s and enter parameter setting menu; 2. In setting menu, confirm the set value; 3. Alarm interface can acknowledge and unlock alarms.
	Exit	1. Return to first interface; 2. Return to previous menu in setting menu.

**NOTE:** Press any key in the main interface can mute sound.

### 6.3 PARAMETERS SETTING

Press  key for more than 3s to enter into user menu.

★ Parameter setting

After entering the correct password, you can enter parameter settings interface.

Password can be divided into 3 levels: one highest level (engineer, default is 00318) and two user-defined levels (technician, default is 00317; operator, default is 00316). After entering highest level password, all configuration items can be set; after entering user-defined level password, users can only configure parameters within the permission field.

Parameter setting includes the following contents:

- ★ Module setting
- ★ Bus setting
- ★ Generator setting
- ★ Generator load setting
- ★ Timers setting
- ★ Analog inputs setting
- ★ Digital inputs setting
- ★ Digital outputs setting
- ★ Analog outputs setting
- ★ Breaker setting
- ★ Synchronization setting
- ★ Synchronous calibration
- ★ SLD setting (only configure via upper computer)
- ★ Engine setting
- ★ 1# DIN16 setting
- ★ 2# DIN16 setting
- ★ 1# DOUT16 setting
- ★ 2# DOUT16 setting

**Example:**

Return	>Start delay	Interface 1: Use   to change setting contents,  to enter settings (interface 2),  to exit settings menu.
Module setting	>Stop delay	
Bus setting	>Start output time	
Generator setting	>Stop output time	
Generator load setting	>Wait for start time	
<b>Timers setting &gt;</b>	>Wait for stop time	
Analog inputs setting	>Load stable time	
Digital inputs setting	>Transient fault delay	
Digital outputs setting	>Alarm start delay	
Analog outputs setting	>Trigger start delay	
Breaker setting	>Alarm stop delay	

Return	>Start delay	<p>Interface 2:</p> <p>Use   to change setting contents,  to enter settings (interface 3),  to return to previous menu. (interface 1)</p>
Module setting	>Stop delay	
Bus setting	>Start output time	
Generator setting	>Stop output time	
Generator load setting	>Wait for start time	
<b>Timers setting &gt;</b>	>Wait for stop time	
Analog inputs setting	>Load stable time	
Digital inputs setting	>Transient fault delay	
Digital outputs setting	>Alarm start delay	
Analog outputs setting	>Trigger start delay	
Breaker setting	>Alarm stop delay	

Return	>Start delay	<p>Interface 3:</p> <p>Use   to change setting contents,  to confirm settings (interface 4),  to return to previous menu. (interface 1).</p>
Module setting	<b>&gt;Stop delay</b>	
Bus setting	>Start output time	
Generator setting	>Stop output time	
Generator load setting	>Wait for start time	
<b>Timers setting &gt;</b>	>Wait for stop time	
Analog inputs setting	>Load stable time	
Digital inputs setting	>Transient fault delay	
Digital outputs setting	>Alarm start delay	
Analog outputs setting	>Trigger start delay	
Breaker setting	>Alarm stop delay	

>Start delay		<p>Interface 4:</p> <p>Press  to enter settings (interface 5),  to return to previous menu. (interface 3).</p>
<b>&gt;Stop delay</b>	<b>00005</b>	
>Start output time		
>Stop output time		
>Wait for start time		
>Wait for stop time		
>Load stable time		
>Transient fault delay		
>Alarm start delay		
>Trigger start delay		
>Alarm stop delay		

>Start delay <b style="background-color: #0056b3; color: white; padding: 2px;">&gt;Stop delay</b> >Start output time >Stop output time >Wait for start time >Wait for stop time >Load stable time >Transient fault delay >Alarm start delay >Trigger start delay >Alarm stop delay	00005	Interface 5: Press   to change cursor position,   are used for changing cursor value,  to confirm setting and the setting will be stored in internal memory automatically;  to exit setting.
--	-------	--

## 7. DG SYSTEM MODE DESCRIPTION

### 7.1 SYSTEM MODE

#### 7.1.1 MANUAL MODE

When manual mode signal is active, the system will enter manual mode. In this mode, HPM6 controller can only monitor data and issue alarms but cannot control switch or genset. In addition, GOV and AVR do not work but the manual GOV IN, manual GOV OUT, manual AVR IN and manual AVR OUT do work in this mode.

#### 7.1.2 SEMI-AUTO MODE

Semi-auto mode is activated by pressing  key; Semi-auto means that the unit will not initiate any sequences automatically. It will only initiate sequences if external signal is given and alarm protection function is always active.

The external signal may be given in three ways:

1. Using display panel keys
2. Using digital inputs
3. Using Modbus command

In semi-auto mode, all available diesel gensets start/stop/synchronizing closed/unloaded open can be controlled by front panel keys.

The system monitors that if gensets are overloaded. Should that be the case, the Non Essential Load (NEL) trip will activate to maintain power supply to bus.

If a heavy consumer is requested, the system will calculate the power needed. If the available power is insufficient, the heavy consumer connection will not be allowed.

#### Semi-auto Start:

- a) Start command will be initiated by HPM6 after pressing  key. The system enters into "Start Output Delay" while the start relay will activate;
- b) When "Start Output Delay" is over, "Wait for Start Delay" will be initiated. "Fail to Start" block alarm will be initiated if measured generator voltage and frequency do not reach the set value after start wait delay is over;

- c) "Load Stable Delay" will be initiated when crank disconnect conditions are reached during start wait delay process. "Frequency/Voltage Fault" block alarm and shutdown will be initiated if generator voltage and frequency do not reach the set value after the "Load Stable Delay" has expired. It enters into "Normal Running" status if the on-load requirement has been achieved;
- d) If the switch is not closed during the normal running status and the voltage/frequency has not satisfied the on-load requirement suddenly, "Transient Fault Delay" will be initiated. "Frequency/Voltage Fault" block alarm and shutdown will be initiated if the on-load requirement has not been achieved after the delay has expired. It enters into "Normal Running" status if the on-load requirement has been achieved during delay period;
- e) Under normal running status, genset will close and synchronize automatically after pressing the  key; In case of single unit running, it will close breaker directly;
- f) In case of multi-set operation, the genset will share load automatically;
- g) If there is trip or shutdown alarm occurs, then the system will trip or stop and the corresponding alarm information will be displayed on the LCD.

### Semi-auto Stop:

- a) In breaker close status, press  key, in case of multi-set operation, first of all, the system will transfer load and open breaker; in case of single unit running and semi-auto intelligent open is enabled, it cannot open, otherwise it will open directly;
- b) In breaker open status, press  key, system will enter into "Stop Output Delay" while the stop relay will activate;
- c) After "Stop Output Delay" is over, system will enter into "Wait for Stop" delay. If genset voltage and frequency signals disappear during the delay, controller will judge that the genset stops and in standby state; otherwise, if genset voltage and frequency signals still can be detected after the delay expired, controller will judge that the genset fails to stop;
- d) After genset fails to stop, if voltage and frequency signals are disappeared, controller will judge that the genset stops completely and in standby state.

### 7.1.3 AUTO MODE

Auto mode is activated by pressing  key.

All available diesel gensets are controlled by the power management system and are started and stopped according to the start priority and the actual bus load. Should a running generator develop the trip alarm, the system will start the next generator in line and synchronize its breaker before taking the failing generator out of service. At the same time, the system detects whether gensets are overloaded. Should that be the case, the Non Essential Load (NEL) trip will activate to maintain power supply to bus.

#### Auto Start Rules:

- a) If the system detects that there is no voltage signal on bus, then corresponding gensets are started according to the start priority;
- b) After load increasing, the system will start the next genset in line if the power is insufficient;
- c) If a heavy consumer is requested, the system will calculate the power needed and automatically start corresponding gensets to satisfy the requirement when power is insufficient;

- d) If there are trip and shutdown fault alarms occur, the corresponding units are automatically started to meet the load requirements;
- e) Linear start mode: if priority is disabled, priority changes will not affect loading genset, it will work in next genset scheduling (current power is over than start power); if enabled and priority changes, higher priority level standby genset will start;
- f) Duty time start mode: gensets will start according to the duty-hour.

### **Auto Start Sequence:**

- a) Genset enters into "Start Delay" as soon as "Auto Start" is active;
- b) After the "Start Delay" has expired, the system enters into "Start Output Delay" while the start relay will activate;
- c) When start delay is over, "Wait for Start Delay" will be initiated. "Fail to Start" block alarm will be initiated if measured generator voltage and frequency do not reach the set value after start wait delay is over;
- d) If crank disconnect conditions are satisfied in "Wait for Start Delay", "Load Stable Delay" will be initiated. "Frequency/Voltage Fault" block alarm and shutdown will be initiated if generator voltage and frequency do not reach the set value after the "Load Stable Delay" has expired. It enters into "Normal Running" status if the on-load requirement has been achieved;
- e) After controller entering into normal running state, and meanwhile on-load requirement has been achieved (generator normal light will illuminate), genset will close and synchronize automatically;
- f) In case of multi-set operation after closing, genset will share load automatically;
- g) If there is trip alarm or shutdown alarm occurs, then the system will trip or shutdown and the alarm information will be displayed on the LCD.

### **Auto Stop Rules:**

- a) In multiple gensets running system, if the system detects that the load power has fallen below the stop power, the controller will transfer load according to the start mode rules firstly and then open breaker and shutdown;
- b) If there is trip alarm or shutdown alarm occurs, the fault genset will open breaker and stop;
- c) If there is safety trip alarm or safety shutdown alarm occurs, the fault genset will take off load and open breaker to stop after new genset start up and on-load requirement of the bus is satisfied;
- d) Linear start mode: if priority is enabled and priority changes, after genset with higher priority takes load, genset with lower priority will take off load and stop; if disabled, priority changes will not affect loading genset, it will work in next genset scheduling (total load power is lower than stop power);
- e) Duty time start mode: gensets will stop according to the duty-hour.

### **Auto Stop Sequence:**

- a) When stop input is activated in auto mode, system enters into "Stop Delay" state;
- b) After "Stop Delay" is expired, in case of multi-set operation, genset will open breaker after transferring the load;
- c) After the switch is opened, the system enters into "Stop Output Delay" while the stop relay will activate;
- d) After "Stop Output Delay" expired, system enters into "Wait for Stop Delay", If genset voltage and frequency signals disappear during the delay, controller will judge that the genset stops and in standby state; otherwise, if genset voltage and frequency signals still can be detected after the delay expired, controller will judge that the genset fails to stop;
- e) After genset fails to stop, if voltage and frequency signals are disappeared, controller will judge that

the genset stops completely and enters into standby state.

**Table 7 – System Modes Description**

Mode	Start/Stop Method	Close/Open	GOV/AVR	Alarm Protection	Description
Manual	Exterior (not via controller)	Exterior (not via controller)	Exterior (not via controller)	Auto	Also called switchboard mode, mainly for monitoring and protection.
Semi-auto	Exterior controller (by)	Exterior controller (by)	Auto	Auto	Used for semi-auto power station.
Auto	Auto	Auto	Auto	Auto	Used for full-auto power station.

**7.2 START MODE DESCRIPTION**

**Table 8 – Start Mode Description**

Start Mode	Start Method	Stop Method	Auto Mode	Semi-auto Mode	Manual Mode
Linear Start Mode	Start the gensets according to the set priority. The genset with higher priority will start first. The smaller the number, the higher the priority.	Stop the gensets according to the priority, genset with lower priority will stop first. E.g. If start sequence is 1-2-3, then the stop sequence of 3-2-1.	√	X	X
Duty Time Start Mode	The gensets which has the shortest running hours will start first. After start time reaches set duty time, the next genset which has the shortest running hours will start.	The gensets which has the longest running hours will stop first.	√	X	X

**7.3 SCHEDULED MODE DESCRIPTION**

**Table 9 – Scheduled Mode Description**

Mode	Start Method	Stop Method	Auto	Semi-auto	Manual
Active Power PCT	When start according to "Start Max. Load PCT", if load active power $\div$ bus total active power $\geq$ start max. load PCT, it will schedule other gensets to start.	When stop according to "Stop Min. Load PCT", if current load active power $\div$ (bus total active power - rated active power of genset to be shutdown) $<$ stop max. load PCT, it will schedule this genset to stop.	√	X	X
Left Active Power	When start according to "Left Start Active Power", if current bus total left active power $\leq$ start active power, it will schedule other gensets to start.	When stop according to "Left Stop Active Power", if (current bus total left active power - rated active power of genset to be shutdown) $<$ left stop active power, it will schedule this genset to stop.	√	X	X
Apparent Power PCT	When start according to "Start Max. Load PCT", if load apparent power $\div$ bus total apparent power $\geq$ start max. load PCT, it will schedule other gensets to start.	When stop according to "Stop Min. Load PCT", if current load apparent power $\div$ (bus total apparent power - rated apparent power of genset to be shutdown) $<$ stop max. load PCT, it will schedule this genset to stop.	√	X	X
Left Apparent Power	When start according to "Left Start Apparent Power", if current bus total left apparent power $\leq$ left start apparent power, it will schedule other gensets to start.	When stop according to "Left Stop Apparent Power", if (current bus total left apparent power - rated apparent power of genset to be shutdown) $<$ left stop apparent power, it will schedule this genset to stop.	√	X	X

## 8. SG SYSTEM MODE DESCRIPTION

### 8.1 SG SYSTEM MODE

#### 8.1.1 MANUAL MODE

When manual mode signal is active, the system will work through manual mode. In this mode, HPM6 controller can only monitor data and alarm information but cannot control switch or genset. In addition, GOV and AVR do not work but the manual GOV IN, manual GOV OUT, manual AVR IN and manual AVR OUT do work in this mode.

#### 8.1.2 SEMI-AUTO MODE

Semi-auto mode is activated by pressing  key; Semi-auto means that the unit will not initiate any sequences automatically. It will only initiate sequences if external signal is given and alarm protection function is always active.

The external signal may be given in three ways:

1. Using display panel keys
2. Using digital inputs
3. Using Modbus command

In semi-auto mode, all available gensets start/stop/synchronizing closed/unloaded open can be controlled by front panel keys.

The system detects whether gensets are overloaded. Should that be the case, the Non Essential Load (NEL) trip will activate to maintain power supply to bus.

If a heavy consumer is requested, the system will calculate the power needed. If the available power is insufficient, the heavy consumer connection will not be allowed.

#### **Semi-auto Start:**

- a) Press  key, the controller firstly judges the feedback state of the shaft solenoid valve closing (if configured). If the state is not detected, the shaft solenoid valve closing outputs (if configured) and will wait for the feedback state to be effective;
- b) After the feedback signal of shaft solenoid valve closing is detected, HPM6 initiates a start command and the system enters the "Start Output Delay", during which the engine start relay outputs;
- c) When "Start Output Delay" is over, "Wait for Start Delay" will be initiated. "Fail to Start" block alarm will be initiated if the measured generator voltage and frequency do not reach the set value after the delay has expired;
- d) When this delay is over, "Load Stable Delay" will be initiated. "Frequency/Voltage Fault" block alarm and shutdown will be initiated if generator voltage and frequency do not reach the set value after the "Load Stable Delay" has expired. It will enter into "Normal Running" status if the on-load requirement has been achieved;
- e) If the switch is not closed during the normal running status and the voltage/frequency has not satisfied the on-load requirement suddenly, "Transient Fault Delay" will be initiated. "Frequency/Voltage Fault" block alarm and shutdown will be initiated if the on-load requirement has

not been achieved after the “Transient Fault Delay” has expired. It enters into “Normal Running” status if the on-load requirement has been achieved during delay period;

- f) When the shaft genset is in normal running status, it will close and synchronize automatically after pressing  key;
- g) It will judge whether the SG power can receive all the DG power when closing in load takeover mode. If not, the controller will initiate an alarm and stop the closing operation. If it meets the requirements, the DG will open and stop after all the loads are received by the SG (DG is effective in auto mode); In the fixed power mode, the controller synchronously closes and operates at fixed power and grid connection with DG;
- h) If there is trip or shutdown alarm occurs, then the system will trip or stop and the corresponding alarm information will be displayed on the LCD.

### Semi-auto Stop:

- a) Press  key in close status or input port of DG with load is effective, the system will dispatch the DG starting (DG is effective in auto mode), judging whether DG power receives all the SG power, if not, controller will initiate an alarm and stop operations, if it meets the requirements, SG soft unloads and opens;
- b) After breaker opened or in breaker open status, press  key, system will enter into “Stop Output Delay” while the stop relay will activate;
- c) After “Stop Output Delay” is over, system will enter into “Wait for Stop” delay. If genset voltage and frequency signals disappear during the delay, controller will judge that the genset stops and in standby state; otherwise, if genset voltage and frequency signals still can be detected after the delay expired, controller will judge that the genset fails to stop;
- d) After genset fails to stop, if voltage and frequency signals are disappeared, controller will judge that the genset stops completely and enters into standby state.

### 8.1.3 AUTO MODE

Auto mode is activated by pressing  key (or by auto mode switch).

The start/stop, opening/closing sequence of auto mode is the same as the semi-auto mode, except for start/stop, opening/closing keys on the panel are inactive and can only be operated through the input port in auto mode.

When DG is loaded, SG will start and close automatically when the input of SG is effective with load, and DG will automatically unload and stop;

When SG is loaded, DG will start and close automatically when the input of DG is effective with load, and SG will automatically unload and stop;

In fixed power mode, SG will automatically start and connect to the grid with DG when the input of SG is effective with load;

In load sharing mode, SG will automatically start and connect to the grid with DG when the input of SG is effective with load.

**8.2 WORKING MODE DESCRIPTION**

**Table 10 – Working Mode Description**

Working Mode	Description	Auto Mode	Semi-auto Mode	Manual Mode
Load Takeover Mode	After SG closing, all loads will be transferred to SG side, DG opens and stops; When SG opening, all loads will be transferred to DG side, SG opens and stops.	√	√	X
Fixed Power Mode	After SG closing, SG shares with parts of loads, DG shares the rest of power; When SG opening, all load will be transferred to DG side, SG opens and stops.	√	√	X
Load Sharing Mode	After SG closing, loads will be shared by SG and DG; When SG opening, all loads will be transferred to DG side, SG opens and stops.	√	√	X

**NOTE:** When in SG mode, outputs of GOV and AVR should be set as “none” if SG can not achieve speed governing.

## 9. PROTECTION

Generator protection, bus protection, current protection, power protection and switch protection can be provided by HPM6. Each kind of protection can configure alarm types and ranges.

**Table 11 – Controller Alarm Types**

Alarm Type/Action	Buzzer	Display	Start	Close	Unload	Trip	Stop
Block	√	√	X	X	X	X	X
Warning	√	√	√	√	X	X	X
Safety Trip	√	√	√	X	√	√	√
Safety Trip and Stop	√	√	X	X	√	√	X
Trip	√	√	√	X	X	√	X
Trip and Stop	√	√	X	X	X	√	√
Indication	X	√	√	√	X	X	X


**Table 12 – Alarm Active Ranges**

Active Range	Description
Always Active	All statuses detect alarm.
Inactive	Alarm is inactive.
Before Gen Close	It detects alarm when genset is not closed.
After Gen Close	It detects alarm after genset is closed with load.
Gen Close on Bus	It detects alarm when genset closes with load (bus is available).
No Gen Close on Bus	It detects alarm when genset not close with load (bus is unavailable).
Gen Normal	It detects alarm when generator is normal.
Other Gens Close	It detects alarm after other gensets except for bus close with load.
Start Delay	It detects alarm after genset start delay time.
After Gen Close Delay	It detects alarm after gen close delay.
Before Gen Close Delay	It detects alarm after gen open delay.
Gen Load Normal	It detects alarm after genset takes load and soft loading.
Gen Close Delay on Bus	It detects alarm after genset closes delay with load on bus (bus is available).
No Gen Close Delay on Bus	It detects alarm after no gen close delay with load (bus is unavailable).
Gen Normal Delay	It detects alarm after gen normal delay.
Other Gens Close Delay	It detects alarm after other gensets except for bus close delay with load.
Gen Load Normal Delay	It detects alarm after genset takes load ad soft loading delay.

If alarm self-locked function is enabled, when the alarm condition is not satisfied and acknowledged, this alarm can be removed after unlocking. If this function is disabled, alarm information will be automatically removed after alarm condition is not satisfied and acknowledged.

If alarm automatic acknowledging function is disabled, when the alarm condition is not satisfied, this alarm can be removed after acknowledging. If this function is enabled, alarm information will be automatically removed after alarm condition is not satisfied.

Users can remove the alarm by “Alarm Reset” auxiliary input port.



**Fig.3 – Alarm Display Diagram**

Press   to select the alarm you are going to reply, and press  to acknowledge the alarm.

**Table 13 – HPM6 Alarms List**

No.	Types	Description	Alarm Type
Bus Protection			
1	Overvolt 1	When bus voltage has exceeded the set value 1, it will initiate a warning alarm.	<b>Warn</b> Always active
2	Overvolt 2	When bus voltage has exceeded the set value 2, it will initiate a trip alarm.	<b>Trip</b> Always active
3	Overvolt 3	When bus voltage has exceeded the set value 3, it will initiate an alarm.	Disabled
4	Undervolt 1	When bus voltage has fallen below than the set value 1, it will initiate a warning alarm.	<b>Warn</b> It is active after gen has closed on bus.
5	Undervolt 2	When bus voltage has fallen below than the set value 2, it will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed on bus.
6	Undervolt 3	When bus voltage has fallen below than the set value 3, it will initiate an alarm.	Disabled
7	Overfreq 1	When bus frequency has exceeded the set value 1, it will initiate a warning alarm.	<b>Warn</b> Always active
8	Overfreq 2	When bus frequency has exceeded the set value 2, it will initiate a trip alarm.	<b>Trip</b> Always active
9	Overfreq 3	When bus frequency has exceeded the set value 3, it will initiate an alarm.	Disabled

No.	Types	Description	Alarm Type
10	Underfreq 1	When bus frequency has fallen below than the set value 1, it will initiate a warning alarm.	<b>Warn</b> It is active after gen has closed on bus.
11	Underfreq 2	When bus frequency has fallen below than the set value 2, it will initiate a trip alarm.	<b>Trip</b> It is active gen has closed on bus.
12	Underfreq 3	When bus frequency has fallen below than the set value 3, it will initiate an alarm.	Disabled
13	ROCOF	Alarm when rate of change of frequency is greater than the set value.	Disabled
14	Vector Shift	Alarm when the change of phase angle is greater than the set value.	Disabled
15	Loss of Phase	Alarm when bus losses of phase.	<b>Warn</b> It is active after gen is normal.
16	Reverse Phase Sequence	Alarm when bus has reverse phase sequence.	<b>Warn</b> It is active after gen is normal.
17	Input Fault	Alarm when other gensets on bus close and controller detects that there is no voltage sampling signal when it is about to close.	<b>Block</b> It is active after synchronous close.
<b>Generator Protection</b>			
1	Overvolt 1	When genset voltage has exceeded the set value 1, it will initiate a warning alarm.	<b>Warn</b> Always active
2	Overvolt 2	When genset voltage has exceeded the set value 2, it will initiate a trip alarm.	<b>Trip</b> Always active
3	Overvolt 3	When genset voltage has exceeded the set value 3, it will initiate an alarm.	Disabled
4	Undervolt 1	When genset voltage has fallen below than the set value 1, it will initiate a warning alarm.	<b>Warn</b> It is active after gen has closed.
5	Undervolt 2	When genset voltage has fallen below than the set value 2, it will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed.
6	Undervolt 3	When genset voltage has fallen below than the set value 3, it will initiate an alarm.	Disabled
7	Overfreq 1	When genset frequency has exceeded the set value 1, it will initiate a warning alarm.	<b>Warn</b> Always active
8	Overfreq 2	When genset frequency has exceeded the set value 2, it will initiate a trip alarm.	<b>Trip</b> Always active
9	Overfreq 3	When genset frequency has exceeded the set value 3, it will initiate an alarm.	Disabled

No.	Types	Description	Alarm Type
10	Underfreq 1	When genset frequency has fallen below than the set value 1, it will initiate a warning alarm.	<b>Warn</b> It is active after gen has closed.
11	Underfreq 2	When genset frequency has fallen below than the set value 2, it will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed.
12	Underfreq 3	When genset frequency has fallen below than the set value 3, it will initiate an alarm.	Disabled
13	Reverse Phase Sequence	When controller detects the reverse phase sequence, it will initiate a warning alarm.	<b>Warn</b> It is active after gen is normal.
14	Loss of Phase	When controller detects loss of phase, it will initiate a warning alarm.	<b>Warn</b> It is active after gen is normal.
15	Generator ROCOF 1	Alarm when rate of change of frequency is greater than set value.	Disabled
16	Generator ROCOF 2		Disabled
17	Vector Shift 1	Alarm when vector shift is greater than set value.	Disabled
18	Vector Shift 2		Disabled
19	Unbalanced Voltage 1	Alarm when unbalanced voltage is greater than set value. Unbalanced voltage refers to the difference value between maximum voltage and average voltage.	<b>Warn</b> It is active after gen has closed.
20	Unbalanced Voltage 2		Disabled
21	Voltage THD 1	Alarm when controller detects voltage total harmonic distortion value is greater than set value.	Disabled
22	Voltage THD 2		Disabled
23	Voltage SHD 1	Alarm when controller detects voltage single harmonic distortion value is greater than set value.	Disabled
24	Voltage SHD 2		Disabled
25	Loss of Excitation 1	Alarm when controller detects the absolute value of genset negative reactive power is greater than the set value.	<b>Warn</b> Always active
26	Loss of Excitation 2		Disabled
27	Low Power Factor 1	Alarm when controller detects genset power factor is lower than set vale.	<b>Warn</b> It is active after gen has closed.
28	Low Power Factor 2		Disabled
29	Freq./Volt Fault	Frequency/voltage alarm will be initiated when controller starts and can't meet load conditions after load stable delay.	<b>Block</b> It is active after starting.
Engine Protection			

No.	Types	Description	Alarm Type
1	Start Failure	Alarm when genset not reach load condition after starting and start wait delay is over.	<b>Block</b> It is active after starting.
2	Stop Failure	Alarm when it detects generator signal after stop wait delay is over.	<b>Warn</b> It is active after stop wait delay.
3	Sync. Failure	When controller not detect synchronous signal during set time, it will initiate a warning alarm.	<b>Warn</b> It is active in synchronization.
4	Engine Fault	When controller detects engine fault input is active, it will initiate a warning alarm.	<b>Block</b> Always active.
5	No Running Feedback Fault	When running feedback function is enabled, if controller detects that voltage and frequency meet crank disconnect conditions after starting, but running feedback input is inactive, running feedback fault alarm will be initiated.	<b>Warn</b> It is active after starting.
6	External Start	In semi-auto mode, when controller detects generator signal, alarm signal will be initiated; In manual mode, alarm signal will be initiated after external start and close with load.	<b>Indication</b> It is active at standby.
7	External Stop	In manual mode, controller will send alarm signal in external stop.	<b>Indication</b> It is active at stop.
8	Freq. Error	Alarm signal will be initiated when generator and bus frequency are greater than 8Hz in synchronous close.	<b>Warn</b> It is active in synchronous close.
9	Emergency Stop	Controller will send alarm signal when emergency stop input port is active.	<b>Trip and Stop</b> Always active.
<b>Current Protection</b>			
1	Over Current 1	When controller detects the generator current has exceeded the set value 1, it will initiate a warning alarm.	<b>Warn</b> Always active.
2	Over Current 2	When controller detects the generator current has exceeded the set value 2, it will initiate a trip alarm.	<b>Trip</b> Always active.
3	Over Current 3	When controller detects the generator current has exceeded the set value 3, it will initiate a trip alarm.	<b>Trip</b> Always active.
4	Over Current 4	When controller detects the generator current has exceeded the set value 4, it will initiate a trip alarm.	<b>Trip</b> Always active.
5	Over Current 5	When controller detects the generator current has exceeded the set value 5, it will initiate a trip alarm.	Disabled
6	Over Current 6	When controller detects the generator current has	Disabled

No.	Types	Description	Alarm Type
		exceeded the set value 6, it will initiate a trip alarm.	
7	Unbalanced Current 1	When the controller detects that unbalanced current has exceeded the set value, it will initiate a warning alarm. Unbalanced current refers to the difference value between max. current and average current.	<b>Warn</b> It is active after gen has closed.
8	Unbalanced Current 2		Disabled
9	Current THD 1	Alarm when controller detects current total harmonic distortion value is greater than set value.	Disabled
10	Current THD 2		Disabled
11	Current SHD 1	Alarm when controller detects current single harmonic distortion value is greater than set value.	Disabled
12	Current SHD 2		Disabled
13	Earth Fault 1	Alarm when controller detects earth current is greater than set value.	Disabled
14	Earth Fault 2		Disabled
15	External Overcurrent Short	Alarm when external overcurrent input port is active.	<b>Trip</b> Always active.
<b>Power Protection</b>			
1	Reverse Power 1	When controller detects the reverse power value (power is negative) has fallen below than the set value 1, it will initiate a trip alarm.	<b>Warn</b> Always active.
2	Reverse Power 2	When controller detects the reverse power value (power is negative) has fallen below than the set value 2, it will initiate a trip alarm.	<b>Trip</b> Always active.
3	Over Power 1	When controller detects the power value (power is positive) has exceeded the set value 1, it will initiate a warning alarm.	<b>Warn</b> Always active.
4	Over Power 2	When controller detects the power value (power is positive) has exceeded the set value 2, it will initiate a trip alarm.	<b>Trip</b> Always active.
5	Non Essential Load 1 Trip	When controller detects the power value (power is positive) has exceeded the <i>Non Essential Load 1 Trip</i> set value, it will trip and initiate alarm.	<b>Warn</b> (Non Essential Load 1 Trip) It is active after the Non Essential Load switch 1 has closed.
6	Non Essential Load 2 Trip	When controller detects the power value (power is positive) has exceeded the <i>Non Essential Load 2 Trip</i> set value, it will trip and initiate alarm.	<b>Warn</b> (Non Essential Load 2 Trip) It is active after the Non Essential Load switch 2 has closed.
7	Non Essential Load 3 Trip	When controller detects the power value (power is positive) has exceeded the <i>Non Essential Load 3 Trip</i> set value, it will trip and initiate alarm.	<b>Warn</b> (Non Essential Load 3 Trip) It is active after the Non

No.	Types	Description	Alarm Type
			Essential Load switch 3 has closed.
8	Gen Insufficient Capacity	When controller detects all normal gensets are on grid and the remaining power cannot request power, it will initiate a warning alarm.	<b>Warn</b> Always active.
9	Unbalanced Distribution of Active Power 1	When the controller detects the unbalanced distribution of active power percentage is greater than the set value, the unbalanced active power distribution outputs and alarms.	<b>Warn</b> It is active after gen has closed.
10	Unbalanced Distribution of Active Power 2		Disabled
11	Unbalanced Distribution of Reactive Power 1	When the controller detects the unbalanced distribution of reactive power percentage is greater than the set value, the unbalanced reactive power distribution outputs and alarms.	<b>Warn</b> It is active after gen has closed.
12	Unbalanced Distribution of Reactive Power 2		Disabled
13	SG & DG Parallel No. Out of Limit	When the controller detects that the number of DG on grid exceeds the limit when SG synchronizes, SG & DG parallel number exceeds the limit and alarms.	<b>Warn</b> It is active when it is SG mode.
14	SG Insufficient Capacity	When the controller detects that SG capacity is unable to receive the total loads, SG capacity is insufficient to output and an alarm is given.	<b>Warn</b> It is active when it is SG mode.
15	DG Insufficient Capacity	When the controller detects that SG capacity is unable to receive the total loads, DG & DG parallel number exceeds the limit and alarms.	<b>Warn</b> It is active when it is SG mode.
16	SG & DG Grid-connection Timeout	When the controller detects timeout of SG & DG grid-connection, it outputs and alarms.	<b>Warn</b> Always active.
17	SG Solenoid Valve Fault	Alarm when controller detects SG solenoid valve has faults.	<b>Block</b> It is active when it is SG mode.
18	HC1 Feedback Failure	When heavy consumer is acknowledged, HC feedback running signal is not received in set time, controller will send alarm signal.	<b>Warn</b> After heavy consumer is acknowledged.
19	HC2 Feedback Failure		<b>Warn</b> After heavy consumer is acknowledged.
20	HC3 Feedback Failure		<b>Warn</b> After heavy consumer is

No.	Types	Description	Alarm Type
			acknowledged.
21	HC4 Feedback Failure		<b>Warn</b> After heavy consumer is acknowledged.
22	HC1 Request Failure	When heavy request is active, if bus left available power can't meet HC demand, controller will send alarm signal.	<b>Warn</b> After heavy consumer is active.
23	HC2 Request Failure		<b>Warn</b> After heavy consumer is active.
24	HC3 Request Failure		<b>Warn</b> After heavy consumer is active.
25	HC4 Request Failure		<b>Warn</b> After heavy consumer is active.
<b>Switch Protection</b>			
1	Fail to Close	When controller detects that there is no <i>Close</i> signal after the <i>Close</i> delay has expired, and no other close signals (current, power), it will initiate a block alarm.	<b>Block</b> It is active after gen has closed.
2	Fail to Open	When controller detects that there is no <i>Open</i> signal after the <i>Open</i> delay has expired, and no other open signals (current, power), it will initiate a block alarm.	<b>Block</b> It is active after gen has opened.
3	Close Fault	When controller detects that there is no <i>Close</i> signal after the <i>Close</i> delay has expired, but detects other close signals (current, power), it will initiate a warning alarm.	<b>Warn</b> Always active.
4	Open Fault	When controller detects that there is no <i>Open</i> signal after the <i>Open</i> delay has expired, but detects other open signals (current, power), it will initiate a warning alarm.	<b>Warn</b> Always active.
5	Unload Failure	When controller detects unload failure in set time, it will initiate a warning alarm.	<b>Warn</b> It is active in unloading.
6	Bustie Switch 0 Fault	The bustie switch fault signal of ring bus. When controller detects fault signal (signal is inconsistent), it will initiate an alarm.	Disabled
7	Bustie Switch 1 Fault	When controller detects bustie switch fault signal (signal is inconsistent), it will initiate an alarm.	<b>Warn</b> Always active.
8	Bustie Switch 2 Fault		Disabled
9	Bustie Switch 3 Fault		Disabled

No.	Types	Description	Alarm Type
	Fault		
10	Bustie Switch 4 Fault		Disabled
11	Bustie Switch 5 Fault		Disabled
12	Bustie Series Switch 0 Fault		Disabled
13	Bustie Series Switch 1 Fault		Disabled
14	Bustie Series Switch 2 Fault	Series switch refers to middle switch of bus section has two or more isolating switches. When controller detects bustie series switch fault signal (signal is inconsistent), it will initiate an alarm.	Disabled
15	Bustie Series Switch 3 Fault		Disabled
16	Bustie Series Switch 4 Fault		Disabled
17	Bustie Series Switch 5 Fault		Disabled
18	Shore Switch 1 Fault		When controller detects shore switch fault signal (signal is inconsistent), it will initiate an alarm.
19	Shore Switch 2 Fault	Disabled	
20	Shore Switch 3 Fault	Disabled	
21	Shore Switch 4 Fault	Disabled	
22	Shore Switch 5 Fault	Disabled	
23	Abnormal Trip of Main Switch	When controller detects the input is active, it will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed.
24	External Open of Main Switch	When controller is grid-connected with load in non-manual mode, gen close input port is inactive and power and current are both 0, it will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed.
25	Bus Break Fault	When bus break function is enabled, if other controllers on the bus have bus break input, and current bus break input port is inactive, it will initiate a warning alarm.	<b>Warn</b> It is active after bus break is enabled.
26	SG Solenoid Valve Fault	When SG mode is enabled and SG solenoid valve closed input is configured, if SG valve close status and controller valve close/open status are inconsistent, it will initiate a warning alarm.	<b>Warn</b> It is active after SG mode is enabled and SG solenoid valve close

No.	Types	Description	Alarm Type
			input is configured.
27	Volt Asynchrony	When voltage asynchrony is detected after synchronous close, controller will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed.
28	Freq. Asynchrony	When frequency asynchrony is detected after synchronous close, controller will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed.
29	Phase Asynchrony	When phase asynchrony is detected after synchronous close, controller will initiate a trip alarm.	<b>Trip</b> It is active after gen has closed.
<b>Module Protection</b>			
1	Over Volt 1	When controller detects the power supply voltage has exceeded the set value, it will initiate a warning alarm.	<b>Warn</b> Always active.
2	Over Volt 2		Disabled
3	Under Volt 1	When controller detects the power supply voltage has fallen below the set value, it will initiate a warning alarm.	<b>Warn</b> Always active.
4	Under Volt 2		Disabled
5	Input Port 1~20 Alarm	When digital input port action selects "Alarm", controller sends corresponding alarm signal when the alarm is active.	Disabled
6	AI1 Open	When controller detects analog input ports are open, it will initiate an alarm.	<b>Not Used</b> Always active.
7	AI2 Open		<b>Not Used</b> Always active.
8	AI1 Upper Limit 1 Alarm	When analog input port is configured as temperature sensor, temperature value is higher than the upper limit or below the lower limit, controller will initiate an alarm.	<b>Not Used</b> Always active.
9	AI1 Upper Limit 2 Alarm		<b>Not Used</b> Always active.
10	AI1 Lower Limit 1 Alarm		<b>Not Used</b> Always active.
11	AI1 Lower Limit 2 Alarm		<b>Not Used</b> Always active.
12	AI2 Upper Limit 1 Alarm		<b>Not Used</b> Always active.
13	AI2 Upper Limit 2 Alarm		<b>Not Used</b> Always active.
14	AI2 Lower Limit 1 Alarm		<b>Not Used</b> Always active.
15	AI2 Lower Limit 2 Alarm		<b>Not Used</b> Always active.
16	AI1 Fault		When analog input fault is detected, controller will initiate an alarm.
17	AI2 Fault	Disabled	

No.	Types	Description	Alarm Type
18	MSC Too Few Sets	When the controller detects fewer modules on the MSC link than the minimum number configured in the unit, it will initiate a warning alarm. There are 2 possible reasons: a) Communication line between the controllers disconnects, which interrupts communication. b) Other parallel gensets controllers have not been powered on.	<b>Warn</b> Always active.
19	ID Address Error	When repetitive ID on network bus is detected, controller will initiate a warning alarm.	<b>Warn</b> Always active.
20	Switch Error	When switch fault signal is detected, controller will initiate a warning alarm.	<b>Warn</b> Always active.
21	IP Address Error	When repetitive IP on network bus is detected, controller will initiate a warning alarm.	<b>Warn</b> Always active.
22	SLD Config. Error	When single line drawing configuration is wrong, controller will initiate a warning alarm.	<b>Warn</b> Always active.
23	Ring Disconnect	When network bus ring is disconnected, controller will initiate a warning alarm.	<b>Warn</b> Always active.
24	1#DIN16 Input Port 1-16	When digital input port action selects "Alarm", controller sends corresponding alarm signal when the alarm is active.	<b>Not Used</b> Always active.
25	2#DIN16 Input Port 1-16	When digital input port action selects "Alarm", controller sends corresponding alarm signal when the alarm is active.	<b>Not Used</b> Always active.
26	PLC Function 1-16	When PLC result is function and action selects "Alarm", controller sends corresponding alarm signal when the condition is active.	<b>Not Used</b> Active after PLC configuration.
27	1#DIN16 Comm. Failure	When the controller detects DIN1 module communication failure, it will initiate an alarm.	Disabled
28	2#DIN16 Comm. Failure	When the controller detects DIN2 module communication failure, it will initiate an alarm.	Disabled
29	1#DOUT16 Comm. Failure	When the controller detects DOUT1 module communication failure, it will initiate an alarm.	Disabled
30	2#DOUT16 Comm. Failure	When the controller detects DOUT2 module communication failure, it will initiate an alarm.	Disabled
31	Local Controller Comm. Failure	When HPM6 controller detects communication failure with local controller, it will initiate an alarm.	Disabled
32	1#HMP300 Comm. Failure	When the controller detects communication failure with HMP300 module, it will initiate an alarm.	Disabled
33	2#HMP300 Comm. Failure		Disabled

**10. HARDWARE STRUCTURE**

**10.1 STRUCTURE DESCRIPTION**

HPM6 is composed of display module HPM6D and master control module HPM6. Its terminals are standard configuration. Users only can expand 16-way digital input module, 16-way digital output module via CANBUS port to realize expansion.

**Table 14 – HPM6D Terminals**

Slot	Terminal	Remarks
TS #1		Communication port.
TS #2	1-9	RS485 communication, relay output, power port.

**Table 15 – HPM6 Terminals**

Slot	Terminal	Remarks
TS #1	1-16	Power port; reply output port
TS #2	17-22	CANBUS and RS485 communication port
TS #3	23-30	Analog output port
TS #4	31-45	Triode output port
TS #5	46-50	Analog input port
TS #6	51-59	Digital input port
TS #7	60-71	Digital input port
TS #8	72-75	Bus voltage input
TS #9	76-79	Gen voltage input
TS #10	80-87	Gen current input and earth current input
		Communication port

**10.2 HPM6D MODULE**

**10.2.1 TERMINAL DESCRIPTION**



**Fig.4 – HPM6D Terminal Drawing**

**10.2.2 TS #1 COMMUNICATION PORT**

**Table 16 – TS #1 Communication Port**

Terminal	Function	Cable Size	Parameter	Remarks
	USB DEVICE		USB communication port	USB-TYPE B port, connect PC software.
	USB HOST		USB port	USB-TYPE B port, connect USB read and write configuration files.
	ETHERNET 1	SF/UTP CAT5e	ETHERNET port 1	RJ45 port, connect master control module, PC software.
	ETHERNET 2	SF/UTP CAT5e	ETHERNET port 2	


**10.2.3 TS #2 RS485 COMMUNICATION, RELAY OUTPUT, POWER PORT**

**Table 17 – TS #2 RS485 Communication, Relay Output, Power Port**

Terminal	Function	Cable Size	Description	Remark
1	B(-)	0.5mm <sup>2</sup>	RS485 communication port	Default baud rate 9600bps, no parity, 2-bit stop bit; Standard MODBUS protocol.
2	A(+)	0.5mm <sup>2</sup>		
3	TR	0.5mm <sup>2</sup>	Pin-out terminal of 120Ω terminal matching resistor inside the controller RS485 communication port	TR and A(+) terminal short connected, which means 120Ω resistor inside controller A(+) and B(-) has been connected, there is no need for external 120Ω resistor.
4	DIGI.OUTPUT_NC	1.5mm <sup>2</sup>	Digital output port	AC250V/8A, it is recommended to connect DC 30V/8A due to insufficient safety requirements.
5	DIGI.OUTPUT_COM	1.5mm <sup>2</sup>		
6	DIGI.OUTPUT_NO	1.5mm <sup>2</sup>		
7	B+	2.5mm <sup>2</sup>	DC(8~35)V	Controller power input.
8	B-	2.5mm <sup>2</sup>		
9	PE	2.5mm <sup>2</sup>	Ground connection	

**10.3 HPM6 MODULE**

**10.3.1 TERMINAL DESCRIPTION**



**Fig.5 – HPM6 Terminal Drawing**

**10.3.2 TS #1 POWER AND RELAY OUTPUT PORT**

**Table 18 – TS #1 Power and Relay Output Port**

Terminal	Function	Cable Size	Description	Remark
1	PE	2.5mm <sup>2</sup>	Ground connection	
2	B-	2.5mm <sup>2</sup>	DC(8~35)V	Controller power input
3	B+	2.5mm <sup>2</sup>		
4	COM1	1.5mm <sup>2</sup>	port 5~6 COM	
5	D01	1.5mm <sup>2</sup>	Digital output port 1 (engine start)	DC30V/8A
6	D02	1.5mm <sup>2</sup>	Digital output port 2 (engine stop)	DC30V/8A
7	D03	1.5mm <sup>2</sup>	Digital output port 3 (speed raise)	DC30V/8A
8	D04	1.5mm <sup>2</sup>	Digital output port 3 (speed drop)	DC30V/8A
9	D05	1.5mm <sup>2</sup>	Digital output port 5 (audible alarm output)	DC30V/8A
10				
11	D06_NO	1.5mm <sup>2</sup>	Digital output port 6 (close output)	DC30V/7A
12	D06_COM	1.5mm <sup>2</sup>		
13	D06_NC	1.5mm <sup>2</sup>		
14	D07_NO	1.5mm <sup>2</sup>	Digital output port 6 (open output)	DC30V/7A
15	D07_COM	1.5mm <sup>2</sup>		
16	D07_NC	1.5mm <sup>2</sup>		

**NOTE:** If battery is used as power, power must directly connect the battery, but not starting power or charging generator to ensure HPM6 stable supply.

### 10.3.3 TS #2 CANBUS AND RS485 COMMUNICATION PORT

**Table 19 – TS #2 CANBUS and RS485 Communication Port**

Terminal	Function	Cable Size	Description	Remark
17	CANL	0.5mm <sup>2</sup>	CANBUS communication port	Communication port of expansion module; It is used for expanding digital input module, digital output module or power acquisition module.
18	CANH	0.5mm <sup>2</sup>		
19	TR	0.5mm <sup>2</sup>	Pin-out terminal of 120Ω terminal matching resistor inside the controller CANBUS communication port	TR and CANH terminal short connected, which means 120Ω resistor inside controller CANH and CANL has been connected, there is no need for external 120Ω resistor.
20	B(-)	0.5mm <sup>2</sup>	RS485 communication port	Default baud rate 9600bps, no parity, 2-bit stop bit; Standard MODBUS-RTU protocol.
21	A(+)	0.5mm <sup>2</sup>		
22	TR	0.5mm <sup>2</sup>	Pin-out terminal of 120Ω terminal matching resistor inside the controller RS485 communication port	TR and A(+) terminal short connected, which means 120Ω resistor inside controller A(+) and B(-) has been connected, there is no need for external 120Ω resistor.

### 10.3.4 TS #3 ANALOG OUTPUT PORT

**Table 20 – TS #3 Analog Output Port**

Terminal	Function	Cable Size	Description	Remark
23	+	AOUT1 (GOV)	Output -20mA~20mA	Can be configured as GOV, AVR, transmitter output.
24	-			
25	+	AOUT2 (AVR)		
26	-			
27	+	AOUT3		
28	-			
29	+	AOUT4		
30	-			

**10.3.5 TS #4 TRIODE OUTPUT PORT**

**Table 21 – TS #4 Triode Output Port**

Terminal	Function	Cable Size	Description	Remark
31	D08	1.0mm <sup>2</sup>	Digital output port 8	Digital output ports 8-20 are triode outputs, which require terminal 44 to connect B+ voltage, then output from terminal 31 to 43. The rated on-load current is 1A.
32	D09	1.0mm <sup>2</sup>	Digital output port 9	
33	D010	1.0mm <sup>2</sup>	Digital output port 10	
34	D011	1.0mm <sup>2</sup>	Digital output port 11	
35	D012	1.0mm <sup>2</sup>	Digital output port 12	
36	D013	1.0mm <sup>2</sup>	Digital output port 13	
37	D014	1.0mm <sup>2</sup>	Digital output port 14	
38	D015	1.0mm <sup>2</sup>	Digital output port 15	
39	D016	1.0mm <sup>2</sup>	Digital output port 16	
40	D017	1.0mm <sup>2</sup>	Digital output port 17	
41	D018	1.0mm <sup>2</sup>	Digital output port 18	
42	D019	1.0mm <sup>2</sup>	Digital output port 19	
43	D020	1.0mm <sup>2</sup>	Digital output port 20	
44	COM(B+)	2.5mm <sup>2</sup>	Digital output port 8-20 COM	Connect B+
45	B-	1.5mm <sup>2</sup>	B-	Connect B-

**10.3.6 TS #5 ANALOG INPUT PORT**

**Table 22 – TS #5 Analog Input Port**

Terminal	Function	Cable Size	Description	Remark
46	AI1	1.0mm <sup>2</sup>	AI1 can configure input as resistance type ((0-1000)Ω), current type ((0-20)mA), voltage type ((0-10)V).	Signal + terminal
47	B-	1.0mm <sup>2</sup>		Signal - terminal
48	AI2	1.0mm <sup>2</sup>	AI2 can configure input as resistance type ((0-1000)Ω), current type ((0-20)mA), voltage type ((0-10)V).	Signal + terminal
49	B-	1.0mm <sup>2</sup>		Signal - terminal
50	DC10.0V	1.0mm <sup>2</sup>	Provides 10V power for voltage type input of AI1/AI2.	Max output current 30mA

**10.3.7 TS #6, TS #7 DIGITAL INPUT PORT**

**Table 23 – TS #6, TS #7 Digital Input Port**

Terminal	Function	Cable Size	Description	Remark
51	DI1	1.0mm <sup>2</sup>	Digital Input 1 (close feedback input)	Terminal 71 (B-) connected active.
52	DI2	1.0mm <sup>2</sup>	Digital Input 2 (manual mode input)	
53	DI3	1.0mm <sup>2</sup>	Digital Input 3 (auto mode input)	
54	DI4	1.0mm <sup>2</sup>	Digital Input 4 (semi-auto mode input)	
55	DI5	1.0mm <sup>2</sup>	Digital Input 5 (HC inquiry 1)	
56	DI6	1.0mm <sup>2</sup>	Digital Input 6 (HC feedback 1)	
57	DI7	1.0mm <sup>2</sup>	Digital Input 7	
58	DI8	1.0mm <sup>2</sup>	Digital Input 8	
59	DI9	1.0mm <sup>2</sup>	Digital Input 9	
60	DI10	1.0mm <sup>2</sup>	Digital Input 10	
61	DI11	1.0mm <sup>2</sup>	Digital Input 11	
62	DI12	1.0mm <sup>2</sup>	Digital Input 12	
63	DI13	1.0mm <sup>2</sup>	Digital Input 13	
64	DI14	1.0mm <sup>2</sup>	Digital Input 14	
65	DI15	1.0mm <sup>2</sup>	Digital Input 15	
66	DI16	1.0mm <sup>2</sup>	Digital Input 16	
67	DI17	1.0mm <sup>2</sup>	Digital Input 17	
68	DI18	1.0mm <sup>2</sup>	Digital Input 18	
69	DI19	1.0mm <sup>2</sup>	Digital Input 19	
70	DI20	1.0mm <sup>2</sup>	Digital Input 20	
71	B-	1.5mm <sup>2</sup>	Digital Input 1-20 COM B-	

**10.3.8 TS #8, TS #9, TS #10 GEN/BUS VOLTAGE, GEN/EARTH CURRENT INPUT PORT**

**Table 24 – TS #8, TS #9, TS #10 Gen/Bus Voltage, Gen/Earth Current Input Port**

Terminal	Function	Cable Size	Description	Remark
72	L1 (Bus)	1.5mm <sup>2</sup>	(Bus) A phase voltage input	
73	L2 (Bus)	1.5mm <sup>2</sup>	(Bus) B phase voltage input	
74	L3 (Bus)	1.5mm <sup>2</sup>	(Bus) C phase voltage input	
75	N (Bus)	1.5mm <sup>2</sup>	(Bus) N phase voltage input	
76	L1 (Gen)	1.5mm <sup>2</sup>	(Gen) A phase voltage input	
77	L2 (Gen)	1.5mm <sup>2</sup>	(Gen) B phase voltage input	
78	L3 (Gen)	1.5mm <sup>2</sup>	(Gen) C phase voltage input	
79	N (Gen)	1.5mm <sup>2</sup>	(Gen) N phase voltage input	
80	S1 (CT1)	2.5mm <sup>2</sup>	Gen A phase current	Rated input 5A
81	S2 (CT1)	2.5mm <sup>2</sup>		
82	S1 (CT2)	2.5mm <sup>2</sup>	Gen B phase current	Rated input 5A
83	S2 (CT2)	2.5mm <sup>2</sup>		
84	S1 (CT3)	2.5mm <sup>2</sup>	Gen C phase current	Rated input 5A
85	S2 (CT3)	2.5mm <sup>2</sup>		
86	S1 (CT4)	2.5mm <sup>2</sup>	Earth current	Rated input 5A
87	S2 (CT4)	2.5mm <sup>2</sup>		


**10.3.9 COMMUNICATION PORT**

**Table 25 – Communication Port**

Terminal	Function	Cable Size	Parameter	Remark
	USB DEVICE		USB comm. port	USB-TYPE B port, connect PC software.
	USB HOST		USB port	USB-TYPE A port, connect USB to record historical data.
	ETHERNET 1	SF/UTP CAT5e	ETHERNET port 1	RJ45 port, connect master control module, PC software, display module or other monitoring platforms.
	ETHERNET 2	SF/UTP CAT5e	ETHERNET port 2	
	ETHERNET 3	SF/UTP CAT5e	ETHERNET port 3	
	ETHERNET 4	SF/UTP CAT5e	ETHERNET port 4	

**10.4 WIRE CONNECTION**


**10.4.1 TYPICAL APPLICATION DIAGRAM**



**Fig.6 – HPM6 Typical Application Diagram**


**NOTE:** Current transformer CT2 can be disconnected in 3P3W (Enable gen load configuration “three-phase three-wire two-meter method”).

**10.4.2 AC WIRE CONNECTION (3 PHASE 4 WIRE)**




**Fig.7 – 3 Phase 4 Wire Connection Diagram**

**10.4.3 AC WIRE CONNECTION (SINGLE PHASE)**



**Fig.8 – Single Phase Connection Diagram**

**10.4.4 AC WIRE CONNECTION (2 PHASE 3 WIRE)**



**Fig.9 – 2 Phase 3 Wire Connection Diagram**


### 10.4.5 ANALOG INPUT PORT

HPM6 AI1 and AI2 ports support (0~1k) $\Omega$  resistance input, (0~20)mA current input and (0~10)V voltage input function. Controller supplies 10V power for voltage input equipment. These two input ports can be connected to signal to adjust frequency and voltage. For example, AI1 is set as voltage type fixed active power input, AI2 is voltage type fixed reactive power input, it is shown as below:

**Table 26 – Analog Frequency/Voltage Adjusting Function Description**

Function	Description	External Set-point Trigger Bar	Input Voltage
AI1	External frequency adjust	Single unit running or generator breaker is opened.	(0-10)V DC
	External active power adjust	Constant power output is required for HPM6 paralleled with shore power/shaft generator/bus.	(0-10)V DC
AI2	External voltage adjust	Single unit running or generator breaker is opened.	(0-10)V DC
	External reactive power adjust	Constant power output is required for HPM6 paralleled with shore power/shaft generator/bus.	(0-10)V DC


0~10V input wire connection:




**Fig.10 – 0~10V Input Wire Connection Diagram**

### 10.4.6 MSC NETWORK COMMUNICATION PORT

Data sharing and communication of HPM6 all modules are implemented via network port. Detailed connection way is as following:




**Fig.11 – HPM6 Communication Connection Diagram 1**



**Fig.12 – HPM6 Communication Connection Diagram 2**

**10.4.7 MSC APPLICATION DIAGRAM**



**Fig.13 – MSC Application Diagram**




Fig.14 – MSC Application Diagram of Two Bus with Bustie Switch

**NOTE:** Switch feedback signal of bustie switch/disconnector can be connected to any one master control module. It is recommended to connect all master control modules to bustie switch feedback signal.

## 11. POWER MANAGEMENT AND WORKFLOW CHART

### 11.1 ILLUSTRATION

There are two kinds of power management mode: Equal load sharing and fixed power output.

### 11.2 EQUAL LOAD SHARING

Equal load sharing is active both in auto mode and semi-auto mode. In both cases, load sharing is carried out via network bus.

There are two kinds of equal load sharing ways: active load sharing and reactive load sharing.

- a) Active load sharing: the real-time equal load sharing of active power of each unit on bus can be adjusted via GOV or relay output.
- b) Reactive load sharing: the real-time equal load sharing of reactive power of each unit on bus can be adjusted via AVR or relay output.

### 11.3 FIXED POWER OUTPUT


Each unit can be selected as running with fixed power. This can be done via digital input or parameter setting.

The unit works in fixed power mode will automatically be set in SEMI-AUTO. Only one generator per independent bus can run in this mode.

Active power output value and reactive power output value can be set, in addition, power factor also can be set.

When the generator main switch is closed, the generator power will be increased to the fixed power set-point.

The following figure shows the fixed power DG & SG on-load diagram in SG mode:



**Fig.15 – SG Fixed Power Load Distribution Diagram**

Suppose SG rated power is 1000kW, DG rated power is 500kW, the fixed min on-load percentage is 10%, the fixed max on-load percentage is 90% and the fixed output power percentage is 80%. According to the change of the total load, DG and SG on-load are as shown in the 5 parts of figure above:

The first part: (0-150)kW, SG and DG share the power;

The second part: (150-850)kW, DG on-load is 50kW(10%), the rest is loaded with SG;

The third part: (850-1200)kW, SG on-load is 800kW(80%), the rest is loaded with DG;

The fourth part: (1200-1300)kW, DG on-load is 400kW(80%), the rest is loaded with SG;

The fifth part: (1300-1500)kW, SG on-load is 900kW(90%)+sharing excess power (total load-1300kW), DG on-load is 400kW(90%)+sharing excess power (total power-1300kW).

**NOTE:** If the fixed min on-load percentage is set to 0, DG will start with load only when SG on-load exceeds the fixed power percentage.

## 11.4 SYNCHRONIZATION

HPM6 controller enables dynamic and static synchronizations. It is defaulted to adopt dynamic synchronization because of its fast speed to close breakers. It is with 0.1Hz slip frequency, synchronization can be finished in 10s and ramp on load immediately once generator closed.

During dynamic synchronization, the unit which is going to be synchronized is running at a different speed to generator on the bus, and the speed difference between them is named as slip frequency. Generally, the synchronizing unit is running at a positive slip frequency which means it is relatively faster than bus generator, so that the generator reverse power is avoided after synchronizing.

The aim of synchronization is reducing the phase angle between two systems (refer to 3-phase systems of generator and bus).

Voltage difference, frequency difference and angle difference should be set during dynamic synchronization. The breaker is going to be closed if all of them meet the requirement between generator and bus.

Static synchronization means that genset ready to synchronize runs in same or extremely similar speed with bus genset, adjusts phase synchronization by phase synchronizer, and sends breaker close signal. It is not recommended to use relay control in static synchronization because it can't precisely adjust due to its slow response. In static synchronization, breaker response time has no higher requirements because of very small or non-existent frequency difference.

## 11.5 HEAVY CONSUMER INQUIRY

### 11.5.1 ILLUSTRATION

Each HPM6 controller can handle up to four Heavy Consumers (HC).

Response priority for the same controller is HC1>HC2>HC3>HC4 if HC ID and priority are both set as 128; while for the different controllers, controller's ID determines HC response priority, which means first response to HC request from controller with small ID number.

If HC ID and priority are not 128, HC response depends on ID and priority, which means first response with small priority, first response with small ID number if the priority is same.

If HC ID number is same and not equal to 128, this heavy consumer has redundancy, which means HC signal can be connected to multiple ports. It is active when one HC request feedback is active. When HC power meets the requirement, it outputs HC permission and response signals.

When a heavy consumer is requested to the power station, system will reserve the required power on the bus, until sufficient predicted available power is present at the bus.

### 11.5.2 HEAVY CONSUMER REQUEST

Heavy load equipment should send a heavy consumer request before starting up. Each HC request signal can set the corresponding inquiry power value and rated power value. HC signal is divided into continuous signal and pulse signal. If bus still has no sufficient left available power for HC response when HC request failure time is over, controller will send HC request failure alarm. If the inquiry signal is pulse signal, this heavy consumer inquiry is over after request failure alarm is acknowledged.

### 11.5.3 HEAVY CONSUMER RESPONSE

If a heavy consumer is requested, the system calculates the power needed according to the requested value of heavy consumer power. If the request is not satisfied, the controller will start the corresponding standby units, if satisfied and the heavy consumer stability delays, then the response signal will be initiated, heavy consumer response output delay ends, if the heavy consumer feedback inactive system is only heavy consumer includes its rated power, and the controller does not reserve any power after the heavy consumer feedback is active.

Example (three 100kW gensets):

- 1) There is 60kW redundancy on bus which is composed by two 100kW parallel running gensets with 140kW load, then the heavy consumer request 1 is active (request power is 70kW);
- 2) An additional genset should be started if the power needed is insufficient;
- 3) There is 160kW redundancy on bus after genset starting and in parallel, then the response signal will be initiated.

### 11.5.4 HEAVY CONSUMER PERMISSION


If a heavy consumer is requested, the system calculates the power needed according to the requested value of heavy consumer power. If the request is not satisfied, the controller will start the corresponding standby units, if satisfied and the heavy consumer stability delays, then the heavy consumer permission signal will be initiated and the signal is variable. If the current bus power is not enough, the heavy consumer permission signal will not output.

### 11.5.5 HEAVY CONSUMER FEEDBACK


The feedback can be divided into digital signal and analog signal according to the type of heavy consumer (fixed power and variable power), analog signal can be collected by analog input or HMP300 communication input. Heavy consumer feedback signal is sent to the controller after the requested heavy consumer starts normally. If it is a fixed power one, the system will not reserve any power for the heavy consumer after the controller receives the digital feedback signal. If it is a variable power one, when the controller receives an analog feedback signal  $\geq 2\%$  of the rated power of heavy consumer, it is considered that the heavy consumer has been started, and the system reserves the remaining power of the rated power of heavy consumer (rated power of heavy consumer - current power of heavy consumer).

After heavy consumer is acknowledged, if HC feedback failure time is over, controller still not receive the HC feedback signal, it will send HC feedback failure alarm

Digital feedback is shown in the figure below:



**Fig.16 – Fixed Heavy Consumer Sequence Diagram 1**




**Fig.17 – Fixed Heavy Consumer Sequence Diagram 2**


Illustration for the fixed heavy consumer sequence diagram:

- a) The HC1 request power is 300kW, HC1 rated power is 150kW;
- b) The bus reserves 300kW for HC1;
- c) The bus has enough redundant power and starts after heavy consumer stability delay;
- d) After the heavy consumer stability delay, the controller starts to output HC response signal;
- e) During or after the output delay of heavy consumer response, the bus has different processing states for HC1 heavy consumer according to the different states of heavy consumer feedback and request signals;
- f) If the heavy consumer feedback is active, the bus will no longer reserve any power for HC1;
- g) If the heavy consumer feedback is inactive, the bus will only reserve the rated power for HC1 when heavy consumer request is active;
- h) If the heavy consumer feedback is inactive, the bus will not reserve any power for HC1 when heavy consumer request is inactive.

Analog feedback is shown in the figure below:



**Fig.18 – Analog Heavy Consumer Sequence Diagram 1**




**Fig.19 – Analog Heavy Consumer Sequence Diagram 2**

### 11.6 NON ESSENTIAL LOAD (NEL) TRIP

When controller detects generator over power, over current, it can trip some non-essential loads to realize self-protection. There are 3 NELs trip, the priority is  $NEL1 > 2 > 3$  (NEL1 trips first). If the active power or current has exceeded the set value, the corresponding NEL will trip after the trip delay, and the warning alarm will be initiated. NEL trip can be reused after alarm response only.

**11.7 WORKFLOW CHART**

**11.7.1 START**



**Fig.20 – System Start Workflow Chart**

11.7.2 STOP




Fig.21 – System Stop Workflow Chart

11.7.3 CLOSE BREAKER




Fig.22 – System Breaker Close Workflow Chart

11.7.4 OPEN BREAKER




Fig.23 – System Breaker Open Workflow Chart

11.7.5 HEAVY CONSUMER




Fig.24 – Heavy Consumer Workflow Chart

11.7.6 LIGHT CONSUMER




Fig.25 – Light Consumer Workflow Chart

## 12. PARAMETER SETTINGS

### 12.1 ILLUSTRATION

This part contains all controller parameters, in which partial parameters only can be configured by upper computer.

### 12.2 MODULE SETTING

**Table 27 – Module Parameter Settings**

No.	Item	Range	Default	Description
Module Setting				
1	Controller Type	(0-1)	0	0: DG Mode 1: SG Mode
2	Power On Mode	(0-2)	0	0: Semi-auto Mode; 1: Auto Mode; 2: Manual Mode.
3	Language	(0-2)	0	0: Simplified Chinese; 1: English; 2: Others.
4	Password	(0-65535)	00318	It is used for entering parameter setting.
5	Engine Fault Action	(0-6)	0: Block	Alarm action type when engine fault input port is active.
6	SG Mode	(0-2)	0	0: Load Takeover Mode 1: Fixed Power Mode 2: Load Sharing Mode
7	Self-check Abnormal Action	(0-2)	1: Force to Manual Mode	If controller self-check is abnormal, corresponding actions will be initiated. 0: No Action 1: Force to Manual Mode 2: Force to Semi-auto Mode
8	Safe Alarm Action	(0-1)	0: Disable	If it is enabled, in semi-auto mode, safety trip and safety trip and stop alarms will execute corresponding actions. If it is disabled, in semi-auto mode, there are only safety trip and safety trip and stop alarms without action.
9	Safe Mode with Load	(0-1)	1: Enable	Load or not after genset starts in safe mode.
10	Start Enable during Stopping	(0-1)	0	0: Disabled
11	USB Enable	(0-1)	0	0: Disabled
12	USB Data Record	(0.1-3600.0)s	1.0	Interval time of USB data record in

No.	Item	Range	Default	Description	
	Interval			genset running.	
13	Alarm Data Analysis Record Interval	(0.0-60.0)s	0.1	Interval time of alarm data analysis record.	
14	Self-check Abnormal Selection		0x0b1f	Bit0: Controller Power Bit1: Total Modules Few Bit2: MSC Bus Loss Bit3: MSC Bus Abnormal Bit4: Genset Status Bit5: Reserved Bit6: Reserved Bit7: Reserved Bit8: DIN16 Communication Bit9: DOUT16 Communication Bit10: Reserved Bit11: HMP300 Communication Bit12: Reserved Bit13: Reserved Bit14: Reserved Bit15: Reserved	
15	RS485 Comm.	Baud Rate	(0-3)	2	0: 2400bps 1: 4800bps 2: 9600bps 3: 19200bps
16		Stop Bit	(0-1)	0	0: 2-bit 1: 1-bit
17		Address	(1-254)	1	Controller communication address for remote monitoring.
18	CAN Comm. Rate	(0-2)	1	0: 500kbps 1: 250kbps 2: 125kbps	
19	Power Rated Voltage	(10.0-50.0)V	24.0	Standard value for judging power over voltage and under voltage.	
20	Over Volt 1	Action	(0-1)	1: Enable	Set value is the percentage of power rated voltage, return value and delay value can be set.
21		Auto ACK	(0-1)	0: Disable	
22		Alarm Self-lock	(0-1)	0: Disable	
23		Threshold	(0-200.0)%	120.0	
24		Return Value	(0-200.0)%	115.0	
25		Delay Value	(0.1-3600.0)s	60.0	
26		Alarm Type	(0-6)	1: Warning	
27	Active Range	(0-20)	0: Always Active		

No.	Item	Range	Default	Description
28	Over Volt 2	Action	(0-1)	0: Disable
29		Auto ACK	(0-1)	0: Disable
30		Alarm Self-lock	(0-1)	0: Disable
31		Threshold	(0-200.0)%	120.0
32		Return Value	(0-200.0)%	115.0
33		Delay Value	(0.1-3600.0)s	60.0
34		Alarm Type	(0-6)	1: Warning
35		Active Range	(0-20)	0: Always Active
36	Under Volt 1	Action	(0-1)	1: Enable
37		Auto ACK	(0-1)	0: Disable
38		Alarm Self-lock	(0-1)	0: Disable
39		Threshold	(0-200.0)%	85.0
40		Return Value	(0-200.0)%	90.0
41		Delay Value	(0.1-3600.0)s	60.0
42		Alarm Type	(0-6)	1: Warning
43		Active Range	(0-20)	0: Always Active
44	Under Volt 2	Action	(0-1)	0: Disable
45		Auto ACK	(0-1)	0: Disable
46		Alarm Self-lock	(0-1)	0: Disable
47		Threshold	(0-200.0)%	85.0
48		Return Value	(0-200.0)%	90.0
49		Delay Value	(0.1-3600.0)s	60.0
50		Alarm Type	(0-6)	1: Warning
51		Active Range	(0-20)	0: Always
52	1#DIN 16	Action	(0-1)	0: Disable
53		Auto ACK	(0-1)	0: Disable
54		Alarm Self-lock	(0-1)	0: Disable
55		Delay Value	(0.1-3600.0)s	5.0
56		Alarm Type	(0-6)	1: Warning
57		2#DIN 16	Action	(0-1)
58	Auto ACK		(0-1)	0: Disable
59	Alarm Self-lock		(0-1)	0: Disable
60	Delay Value		(0.1-3600.0)s	5.0
61	Alarm Type		(0-6)	1: Warning
62	1#DO	Action	(0-1)	0: Disable

When HPM6 input ports are insufficient, expand external input module 1 is used, if still not enough, input module 2 is used.

When HPM6 output ports are

No.	Item		Range	Default	Description
63	UT16	Auto ACK	(0-1)	0: Disable	insufficient, expand external output module 1 is used, if still not enough, output module 2 is used.
64		Alarm Self-lock	(0-1)	0: Disable	
65		Delay Value	(0.1-3600.0)s	5.0	
66		Alarm Type	(0-6)	1: Warning	
67		2#DO UT16	Action	(0-1)	
68	Auto ACK		(0-1)	0: Disable	
69	Alarm Self-lock		(0-1)	0: Disable	
70	Delay Value		(0.1-3600.0)s	5.0	
71	Alarm Type		(0-6)	1: Warning	
72	1#HM P300	Action	(0-1)	0: Disable	When HMP300 is selected to get power signal by HPM6 HC feedback type, HMP300 can be enabled.
73		Auto ACK	(0-1)	0: Disable	
74		Alarm Self-lock	(0-1)	0: Disable	
75		Delay Value	(0.1-3600.0)s	5.0	
76		Alarm Type	(0-6)	1: Warning	
77	2#HM P300	Action	(0-1)	0: Disable	
78		Auto ACK	(0-1)	0: Disable	
79		Alarm Self-lock	(0-1)	0: Disable	
80		Delay Value	(0.1-3600.0)s	5.0	
81		Alarm Type	(0-6)	1: Warning	
82	Network Enable		(0-1)	1: Enable	
83	IP Address		(0-255)	192.168.0.144	
84	Subnet Mask		(0-255)	255.255.255.0	
85	Default Gateway		(0-255)	192.168.0.1	
86	DNS Address		(0-255)	192.168.0.1	
87	MAC Address		(0-255)		MAC of each controller is different.
88	Ring	Action	(0-1)	1: Enable	It is enabled when ring has redundancy.
89	Disc.	Auto ACK	(0-1)	0: Disable	
90	Alarm	Alarm Self-lock	(0-1)	0: Disable	

**12.3 BUS SETTING**

**Table 28 – Bus Parameter Settings**

No.	Items	Range	Default	Description	
<b>Bus Setting</b>					
1	Rated Voltage	(30-30000)V	400	Standard for checking bus over/under voltage. (It is primary voltage when using voltage transformer; it is line voltage when AC system is 3P3W while it is phase voltage when using other AC system).	
2	Rated Frequency	(10.0-75.0)Hz	50.0	Standard for checking bus over/under frequency.	
3	Volt. Trans.(PT)	Action	(0-1) 0: Disable 1: Enable	0: Disable	Users can set the primary voltage and secondary voltage of the voltage transformer.
4		PT Primary	(30-30000)V	100	
5		PT Secondary	(30-1000)V	100	
6	ROCOF	Action	(0-1)	0: Disable	When controller detects bus frequency change rate is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.
7		Auto ACK	(0-1)	0: Disable	
8		Alarm Self-lock	(0-1)	0: Disable	
9		Threshold	(0-10.00)Hz/s	0.20	
10		Return Value	(0-10.00)Hz/s	0.15	
11		Delay Value	(0.1-3600.00) s	0.1	
12		Alarm Type	(0-6)	1: Warning	
13	Active Range	(0-20)	6: Gen Normal		
14	Vector Shift	Action	(0-1)	0: Disable	When controller detects bus voltage vector shift value is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.
15		Auto ACK	(0-1)	0: Disable	
16		Alarm Self-lock	(0-1)	0: Disable	
17		Threshold	(0-60.0)°	6.0	
18		Return Value	(0-60.0)°	5.0	
19		Delay Value	(0.1-3600.00)s	0.1	
20		Alarm Type	(0-6)	1: Warning	
21	Active Range	(0-20)	6: Gen Normal		
22	Over Voltage 1 Set	Action	(0-1) 0: Disable	1: Enable	Setting value is bus rated voltage's percentage, and both return value and

No.	Items	Range	Default	Description
		1: Enable		delay value can be set.
23	Auto ACK	(0-1) 0: Disable 1: Enable	0: Disable	
24	Alarm Self-lock	(0-1) 0: Disable 1: Enable	0: Disable	
25	Threshold	(0-200.0)%	110.0	
26	Return Value	(0-200.0)%	109.0	
27	Delay Value	(0.1-3600.0)s	5.0	
28	Alarm Type	(0-6) 0: Block 1: Warning 2: Trip 3: Trip and Stop 4: Safety Trip 5: Safety Trip and Stop 6: Indication	1: Warning	
29	Active Range	(0-20) 0: Always Active 1: Inactive 2: Before Gen Close 3: After Gen Close 4: Gen Close on Bus 5: No Gen Close on Bus 6: Gen Normal 7: Other Gens Close 8: Start Delay 9: After Gen Close Delay 10: Before Gen Close Delay 11: Gen Load Normal 12: Gen Close Delay on Bus	0: Always Active	

No.	Items	Range	Default	Description
		13: No Gen Close Delay on Bus 14: Gen Normal Delay 15: Other Gens Close Delay 16: Gen Load Normal Delay 17-20: Reserved		
30	Over Voltage 2 Set	Action	(0-1)	1: Enable
31		Auto ACK	(0-1)	0: Disable
32		Alarm Self-lock	(0-1)	0: Disable
33		Threshold	(0-200.0)%	120.0
34		Return Value	(0-200.0)%	119.0
35		Delay Value	(0.1-3600.0)s	3.0
36		Alarm Type	(0-6)	2: Trip
37		Active Range	(0-20)	0: Always Active
38	Over Voltage 3 Set	Action	(0-1)	0: Disable
39		Auto ACK	(0-1)	0: Disable
40		Alarm Self-lock	(0-1)	0: Disable
41		Threshold	(0-200.0)%	130.0
42		Return value	(0-200.0)%	129.0
43		Delay Value	(0.1-3600.0)s	1.0
44		Alarm Type	(0-6)	2: Trip
45	Active Range	(0-20)	0: Always Active	
46	Under Voltage 1 Set	Action	(0-1)	1: Enable
47		Auto ACK	(0-1)	0: Disable
48		Alarm Self-lock	(0-1)	0: Disable
49		Threshold	(0-200.0)%	95.0
50		Return Value	(0-200.0)%	96.0
51		Delay Value	(0.1-3600.0)s	5.0
52		Alarm Type	(0-6)	1: Warning
53		Active Range	(0-20)	4: Gen Close on Bus

No.	Items	Range	Default	Description
54	Under Voltage 2 Set	Action	(0-1)	1: Enable
55		Auto ACK	(0-1)	0: Disable
56		Alarm Self-lock	(0-1)	0: Disable
57		Threshold	(0-200.0)%	80.0
58		Return Value	(0-200.0)%	81.0
59		Delay Value	(0.1-3600.0)s	3.0
60		Alarm Type	(0-6)	2: Trip
61	Active Range	(0-20)	4: Gen Close on Bus	
62	Under Voltage 3 Set	Action	(0-1)	0: Disable
63		Auto ACK	(0-1)	0: Disable
64		Alarm Self-lock	(0-1)	0: Disable
65		Threshold	(0-200.0)%	70.0
66		Return Value	(0-200.0)%	71.0
67		Delay Value	(0.1-3600.0)s	2.0
68		Alarm Type	(0-6)	2: Trip
69	Active Range	(0-20)	4: Gen Close on Bus	
70	Over Frequency 1 Set	Action	(0-1)	1: Enable
71		Auto ACK	(0-1)	0: Disable
72		Alarm Self-lock	(0-1)	0: Disable
73		Threshold	(0-200.0)%	105.0
74		Return Value	(0-200.0)%	104.0
75		Delay Value	(0.1-3600.0)s	5.0
76		Alarm Type	(0-6)	1: Warning
77	Active Range	(0-20)	0: Always Active	
78	Over Frequency 2 Set	Action	(0-1)	1: Enable
79		Auto ACK	(0-1)	0: Disable
80		Alarm Self-lock	(0-1)	0: Disable
81		Threshold	(0-200.0)%	110.0
82		Return Value	(0-200.0)%	109.0

Setting value is bus rated frequency's percentage, return value and delay value can be set according to actual situations.

No.	Items	Range	Default	Description
83		Delay Value	(0.1-3600.0)s	8.0
84		Alarm Type	(0-6)	2: Trip
85		Active Range	(0-20)	0: Always Active
86	Over Frequency 3 Set	Action	(0-1)	0: Disable
87		Auto ACK	(0-1)	0: Disable
88		Alarm Self-lock	(0-1)	0: Disable
89		Threshold	(0-200.0)%	120.0
90		Return Value	(0-200.0)%	119.0
91		Delay Value	(0.1-3600.0)s	6.0
92		Alarm Type	(0-6)	2: Trip
93	Active Range	(0-20)	0: Always Active	
94	Under Frequency 1 Set	Action	(0-1)	1: Enable
95		Auto ACK	(0-1)	0: Disable
96		Alarm Self-lock	(0-1)	0: Disable
97		Threshold	(0-200.0)%	96.0
98		Return Value	(0-200.0)%	97.0
99		Delay Value	(0.1-3600.0)s	5.0
100		Alarm Type	(0-6)	1: Warning
101	Active Range	(0-20)	4: Gen Close on Bus	
102	Under Frequency 2 Set	Action	(0-1)	1: Enable
103		Auto ACK	(0-1)	0: Disable
104		Alarm Self-lock	(0-1)	0: Disable
105		Threshold	(0-200.0)%	93.0
106		Return Value	(0-200.0)%	94.0
107		Delay Value	(0.1-3600.0)s	10.0
108		Alarm Type	(0-6)	2: Trip
109	Active Range	(0-20)	4: Gen Close on Bus	
110	Under Frequency 3 Set	Action	(0-1)	0: Disable
111	Auto ACK	(0-1)	0: Disable	
112	Alarm	(0-1)	0: Disable	

No.	Items	Range	Default	Description
	Self-lock			
113	Threshold	(0-200.0)%	92.0	
114	Set Value	(0-200.0)%	93.0	
115	Delay	(0.1-3600.0)s	8.0	
116	Alarm Type	(0-6)	2: Trip	
117	Active Range	(0-20)	4: Gen Close on Bus	

**12.4 GENERATOR SETTING**

**Table 29 – Generator Parameter Settings**

No.	Items	Range	Default	Description
<b>Generator Setting</b>				
1	AC System	(0-3)	0: 3P3W	0: 3 phase, 4 wire (3P4W); 1: 3 phase, 3 wire (3P3W); 2: 2 phase, 3 wire (2P3W); 3: Single phase, 2 wire (1P2W).
2	Rated Voltage	(30-30000)V	400	To offer standards for detecting of generator's over/under voltage. (It is primary voltage when using voltage transformer; it is line voltage when AC system is 3P3W while it is phase voltage when using other AC system).
3	Min. Loading Voltage	(0-200.0)%	95.0	Setting value is percentage of generator rated voltage. Detect when controller prepares loading.
4	Max. Loading Voltage	(0-200.0)%	105.0	When generator voltage is between min loading voltage and max loading voltage, it will enter into normally running.
5	Crank Disconnect Volt	(0-200.0)%	80.0	To offer standards for detecting crank disconnect voltage is satisfied or not.
6	Rated Frequency	(10.0-75.0)Hz	50.0	To offer standards for detecting over/under/load frequency.
7	Min. Loading Frequency	(0-200.0)%	94.0	Setting value is percentage of generator rated frequency. Detect when controller prepares loading.
8	Max. Loading Frequency	(0-200.0)%	101.0	When generator frequency is between min loading frequency and max loading frequency, it will enter

No.	Items	Range	Default	Description		
				into normal running.		
9	Crank Disconnect Freq	(0-200.0)%	85	To offer standards for detecting crank disconnect frequency is satisfied or not.		
10	Phase Sequence Select	(0-1)	0	0: L1-L2-L3 1: L1-L3-L2		
11	Harmonic Display	(0-1)	0: Disable	0: Disable; 1: Enable		
12	Volt. Trans.(PT)	Action	(0-1) 0: Disable 1: Enable	0: Disable	Primary/secondary voltage of voltage transformer can be set.	
13		PT Primary	(30-30000)V			100
14		PT Secondary	(30-1000)V			100
15	Loss of Phase Set	Action	(0-1)	1: Enable		
16		Auto ACK	(0-1)	0: Disable		
17		Alarm Self-lock	(0-1)	0: Disable		
18		Delay Value	(0.1-3600.0)s	5.0		
19		Alarm Type	(0-6)	1: Warning		
20		Active Range	(0-20)	6: Gen Normal		
21	Reverse Phase Sequence	Action	(0-1)	1: Enable		
22		Auto ACK	(0-1)	0: Disable		
23		Alarm Self-lock	(0-1)	0: Disable		
24		Delay Value	(0.1-3600.0)s	5.0		
25		Alarm Type	(0-6)	1: Warning		
26		Active Range	(0-20)	6: Gen Normal		
27	VECTOR SHIFT 1	Action	(0-1)	0: Disable	When controller detects gen vector shift is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.	
28		Auto ACK	(0-1)	0: Disable		
29		Alarm Self-lock	(0-1)	0: Disable		
30		Threshold	(0-60.0)°	6.0		
31		Return Value	(0-60.0)°	5.0		
32		Delay Value	(0.1-3600.0)s	0.1		
33		Alarm Type	(0-6)	1: Warning		
34		Active Range	(0-20)	6: Gen Normal		
35	VECTOR SHIFT 2	Action	(0-1)	0: Disable		
36		Auto ACK	(0-1)	0: Disable		

No.	Items	Range	Default	Description	
37	Alarm Self-lock	(0-1)	0: Disable		
38		Threshold	(0-60.0)°		6.0
39		Return Value	(0-60.0)°		5.0
40		Delay Value	(0.1-3600.0)s		0.1
41		Alarm Type	(0-6)		1: Warning
42		Active Range	(0-20)		6: Gen Normal
43	Voltage THD 1 Set	Action	(0-1)	0: Disable	When controller detects voltage total harmonic distortion percentage is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.
44		Auto ACK	(0-1)	0: Disable	
45		Alarm Self-lock	(0-1)	0: Disable	
46		Threshold	(0-200.0)%	10.0	
47		Return Value	(0-200.0)%	5.0	
48		Delay Value	(0.1-3600.0)s	5.0	
49		Alarm Type	(0-6)	1: Warning	
50		Active Range	(0-20)	6: Gen Normal	
51	Voltage THD 2 Set	Action	(0-1)	0: Disable	
52		Auto ACK	(0-1)	0: Disable	
53		Alarm Self-lock	(0-1)	0: Disable	
54		Threshold	(0-200.0)%	10.0	
55		Return Value	(0-200.0)%	5.0	
56		Delay Value	(0.1-3600.0)s	5.0	
57		Alarm Type	(0-6)	1: Warning	
58		Active Range	(0-20)	6: Gen Normal	
59	Voltage SHD 1 Set	Action	(0-1)	0: Disable	When controller detects voltage any one harmonic distortion percentage is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.
60		Auto ACK	(0-1)	0: Disable	
61		Alarm Self-lock	(0-1)	0: Disable	
62		Threshold	(0-200.0)%	10.0	
63		Return Value	(0-200.0)%	5.0	
64		Delay Value	(0.1-3600.0)s	5.0	
65		Alarm Type	(0-6)	1: Warning	
66		Active Range	(0-20)	6: Gen Normal	

No.	Items	Range	Default	Description	
67	Voltage SHD 2 Set	Action	(0-1) 0: Disable		
68		Auto ACK	(0-1) 0: Disable		
69		Alarm Self-lock	(0-1) 0: Disable		
70		Threshold	(0-200.0)% 10.0		
71		Return Value	(0-200.0)% 5.0		
72		Delay Value	(0.1-3600.0)s 5.0		
73		Alarm Type	(0-6) 1: Warning		
74		Active Range	(0-20) 6: Gen Normal		
75	Over Voltage 1 Set	Action	(0-1) 0: Disable 1: Enable	Setting value is percentage of generator rated voltage. Delay value and return value can be set.	
76		Auto ACK	(0-1) 0: Disable 1: Enable		
77		Alarm Self-lock	(0-1) 0: Disable 1: Enable		
78		Threshold	(0-200.0)% 105.0		
79		Return Value	(0-200.0)% 104.0		
80		Delay Value	(0.1-3600.0)s 5.0		
81		Alarm Type	(0-6) 0: Block 1: Warning 2: Trip 3: Trip and Stop 4: Safety Trip 5: Safety Trip and Stop 6: Indication		1: Warning
82		Active Range	(0-20) 0: Always Active 1: Inactive 2: Before Gen Close 3: After Gen Close 4: Gen Close on Bus 5: No Gen Close on Bus		0: Always Active

No.	Items	Range	Default	Description
		6: Gen Normal 7: Other Gens Close 8: Start Delay 9: After Gen Close Delay 10: Before Gen Close Delay 11: Gen Load Normal 12: Gen Close Delay on Bus 13: No Gen Close Delay on Bus 14: Gen Normal Delay 15: Other Gens Close Delay 16: Gen Load Normal Delay 17-20: Reserved		
83	Over Voltage Set 2	Action	(0-1)	1: Enable
84		Auto ACK	(0-1)	0: Disable
85		Alarm Self-lock	(0-1)	0: Disable
86		Threshold	(0-200.0)%	115.0
87		Return Value	(0-200.0)%	114.0
88		Delay Value	(0.1-3600.0)s	1.0
89		Alarm Type	(0-6)	2: Trip
90		Active Range	(0-20)	0: Always Active
91	Over Voltage Set 3	Action	(0-1)	0: Disable
92		Auto ACK	(0-1)	0: Disable
93		Alarm Self-lock	(0-1)	0: Disable
94		Threshold	(0-200.0)%	120.0
95		Return Value	(0-200.0)%	119.0
96		Delay Value	(0.1-3600.0)s	1.0
97		Alarm Type	(0-6)	2: Trip
98		Active	(0-20)	0: Always

No.	Items	Range	Default	Description
		Range	Active	
99	Under Voltage Set 1	Action	(0-1)	1: Enable
100		Auto ACK	(0-1)	0: Disable
101		Alarm Self-lock	(0-1)	0: Disable
102		Threshold	(0-200.0)%	95.0
103		Return Value	(0-200.0)%	96.0
104		Delay Value	(0.1-3600.0)s	5.0
105		Alarm Type	(0-6)	1: Warning
106		Active Range	(0-20)	3: After Gen Close
107	Under Voltage Set 2	Action	(0-1)	1: Enable
108		Auto ACK	(0-1)	0: Disable
109		Alarm Self-lock	(0-1)	0: Disable
110		Threshold	(0-200.0)%	80.0
111		Set Value	(0-200.0)%	81.0
112		Delay	(0.1-3600.0)s	3.0
113		Alarm Type	(0-6)	2: Trip
114		Active Range	(0-20)	3: After Gen Close
115	Under Voltage Set 3	Action	(0-1)	0: Disable
116		Auto ACK	(0-1)	0: Disable
117		Alarm Self-lock	(0-1)	0: Disable
118		Threshold	(0-200.0)%	70.0
119		Set Value	(0-200.0)%	71.0
120		Delay	(0.1-3600.0)s	1.0
121		Alarm Type	(0-6)	2: Trip
122		Active Range	(0-20)	3: After Gen Close
123	Voltage Imbalance 1 Set	Action	(0-1)	1: Enable
124		Auto ACK	(0-1)	0: Disable
125		Alarm Self-lock	(0-1)	0: Disable
126		Threshold	(0-200.0)%	10.0
127		Set Value	(0-200.0)%	5.0
128		Delay	(0.1-3600.0)s	5.0
129		Alarm Type	(0-6)	1: Warning
130		Active Range	(0-20)	3: After Gen Close

When controller detects voltage imbalance percentage is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.

No.	Items	Range	Default	Description
131	Voltage Imbalance 2 Set	Action	(0-1)	0: Disable
132		Auto ACK	(0-1)	0: Disable
133		Alarm Self-lock	(0-1)	0: Disable
134		Threshold	(0-200.0)%	10.0
135		Set Value	(0-200.0)%	5.0
136		Delay	(0.1-3600.0)s	5.0
137		Alarm Type	(0-6)	1: Warning
138		Active Range	(0-20)	3: After Gen Close
139	Over Frequency 1 Set	Action	(0-1)	1: Enable
140		Auto ACK	(0-1)	0: Disable
141		Alarm Self-lock	(0-1)	0: Disable
142		Threshold	(0-200.0)%	105.0
143		Return Value	(0-200.0)%	104.0
144		Delay Value	(0.1-3600.0)s	5.0
145		Alarm Type	(0-6)	1: Warning
146		Active Range	(0-20)	0: Always Active
147	Over Frequency 2 Set	Action	(0-1)	1: Enable
148		Auto ACK	(0-1)	0: Disable
149		Alarm Self-lock	(0-1)	0: Disable
150		Threshold	(0-200.0)%	107.0
151		Return Value	(0-200.0)%	106.0
152		Delay Value	(0.1-3600.0)s	3.0
153		Alarm Type	(0-6)	2: Trip
154		Active Range	(0-20)	0: Always Active
155	Over Frequency 3 Set	Action	(0-1)	0: Disable
156		Auto ACK	(0-1)	0: Disable
157		Alarm Self-lock	(0-1)	0: Disable
158		Threshold	(0-200.0)%	110.0
159		Return Value	(0-200.0)%	109.0
160		Delay Value	(0.1-3600.0)s	1.0
161		Alarm Type	(0-6)	2: Trip
162		Active	(0-20)	0: Always

Setting value is percentage of generator rated frequency. Delay value and return value can be set according to actual situation.

No.	Items	Range	Default	Description
		Range	Active	
163	Under Frequency 1 Set	Action	(0-1)	1: Enable
164		Auto ACK	(0-1)	0: Disable
165		Alarm Self-lock	(0-1)	0: Disable
166		Threshold	(0-200.0)%	95.0
167		Return Value	(0-200.0)%	96.0
168		Delay Value	(0.1-3600.0)s	5.0
169		Alarm Type	(0-6)	1: Warning
170		Active Range	(0-20)	3: After Gen Close
171	Under Frequency 2 Set	Action	(0-1)	1: Enable
172		Auto ACK	(0-1)	0: Disable
173		Alarm Self-lock	(0-1)	0: Disable
174		Threshold	(0-200.0)%	93.0
175		Return Value	(0-200.0)%	94.0
176		Delay Value	(0.1-3600.0)s	3.0
177		Alarm Type	(0-6)	2: Trip
178		Active Range	(0-20)	3: After Gen Close
179	Under Frequency 3 Set	Action	(0-1)	0: Disable
180		Auto ACK	(0-1)	0: Disable
181		Alarm Self-lock	(0-1)	0: Disable
182		Threshold	(0-200.0)%	90.0
183		Return Value	(0-200.0)%	91.0
184		Delay Value	(0.1-3600.0)s	1.0
185		Alarm Type	(0-6)	2: Trip
186		Active Range	(0-20)	3: After Gen Close
187	ROCOF 1	Action	(0-1)	0: Disable
188		Auto ACK	(0-1)	0: Disable
189		Alarm Self-lock	(0-1)	0: Disable
190		Threshold	(0-10.00)Hz/s	0.20
191		Return Value	(0-10.00)Hz/s	0.19
192		Delay Value	(0.1-3600.0)s	0.1

When controller detects that ROCOF is greater than the set value, it will send alarm signal and the alarm information will be displayed on the LCD.

No.	Items	Range	Default	Description
193	Alarm Type	(0-6)	1: Warning	
194	Active Range	(0-20)	6: Gen Normal	
195	Action	(0-1)	0: Disable	
196	Auto ACK	(0-1)	0: Disable	
197	Alarm Self-lock	(0-1)	0: Disable	
198	Threshold	(0-10.00)Hz/s	0.20	
199	Return Value	(0-10.00)Hz/s	0.19	
200	Delay Value	(0.1-3600.0)s	0.1	
201	Alarm Type	(0-6)	1: Warning	
202	Active Range	(0-20)	6: Gen Normal	

SmartGen

**12.5 GENERATOR LOAD SETTING**

**Table 30 – Generator Load Settings**


No.	Items	Range	Default	Description
<b>Load Setting</b>				
1.	CT Ratio	(5-6000)/5	500/5	The ratio of external CT.
2.	Full Load Rating	(5-6000)A	500	Generator's rated current.
3.	Rated Active Power	(5-20000)kW	276	Generator's rated active power.
4.	Rated Reactive Power	(5-20000)kvar	210	Generator's rated reactive power.
5.	Earth Current Trans. Ratio	(5-6000)/5	500	The ratio of external earth current transformer.
6.	Load Slope	(0.1-100.0)%/s	3.0	Genset load percentage in unit time.
7.	Load Slope Delay Point	(0.1-40.0)%	10.0	Load point for genset loading rest.
8.	Load Slope Delay Value	(0-30)s	0	Load disconnect time for genset loading rest.
9.	Drop Power set	(0-100)%	70	When the input port is active, it is the set value of genset drop power.
10.	Unload Slope	(0.1-100.0)%/s	3.0	Genset unload percentage in unit time.
11.	Unload Slope Delay Point	(0.1-40.0)%	10.0	Unload disconnect point for genset unloading rest.
12.	Unload Slope Delay Value	(0-30)s	0	Unload disconnect time for genset unloading rest.
13.	Load Start Offset Point	(0-100.0)%	5.0	Start offset point of soft loading after closing.
14.	Unload Start Offset Point	(0-100.0)%	5.0	Start offset point of soft unloading before opening.
15.	3P3W Two-meter Method	(0-1)	0	When it is enabled, B phase current is not connected.
16.	Unload Failure Open	Action	(0-1)	1: Enable Action whether to open when unloading failure.
17.		Threshold	(0-100.0)%	10.0 Open after reaching this value when unloading failure.
18.		Delay	(0-3600)s	180 Judging delay when unloading failure.
19.	Earth Fault 1 Alarm Set	Action	(0-1)	0: Disable When controller detects earth current is greater than set value, it will issue alarm signal
20.		Auto ACK	(0-1)	
21.		Alarm Self-lock	(0-1)	

No.	Items	Range	Default	Description	
22.	Earth Fault 2 Alarm Set	Threshold	(0-200.0)%	20.0	and alarm information will be displayed on LCD.
23.		Return Value	(0-200.0)%	19.0	
24.		Delay Value	(0.1-3600.0)s	10.0	
25.		Alarm Type	(0-6)	1: Warning	
26.		Active Range	(0-20)	0: Always Active	
27.		Action	(0-1)	0: Disable	
28.		Auto ACK	(0-1)	0: Disable	
29.	Alarm Self-lock	(0-1)	0: Disable	When controller detects current total harmonic distortion is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.	
30.	Threshold	(0-200.0)%	20.0		
31.	Return Value	(0-200.0)%	19.0		
32.	Delay Value	(0.1-3600.0)s	10.0		
33.	Alarm Type	(0-6)	1: Warning		
34.	Active Range	(0-20)	0: Always Active		
35.	Current THD 1 Set	Action	(0-1)		0: Disable
36.		Auto ACK	(0-1)	0: Disable	
37.		Alarm Self-lock	(0-1)	0: Disable	
38.		Threshold	(0-200.0)%	10.0	
39.		Return Value	(0-200.0)%	5.0	
40.		Delay Value	(0.1-3600.0)s	5.0	
41.		Alarm Type	(0-6)	1: Warning	
42.	Active Range	(0-20)	3: After Gen Close	When controller detects any one harmonic distortion is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.	
43.	Current THD 2 Set	Action	(0-1)		0: Disable
44.		Auto ACK	(0-1)		0: Disable
45.		Alarm Self-lock	(0-1)		0: Disable
46.		Threshold	(0-200.0)%		10.0
47.		Return Value	(0-200.0)%		5.0
48.		Delay Value	(0.1-3600.0)s		5.0
49.		Alarm Type	(0-6)	1: Warning	
50.	Active Range	(0-20)	3: After Gen Close	When controller detects any one harmonic distortion is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.	
51.	Current SHD 1 Set	Action	(0-1)		0: Disable
52.		Auto ACK	(0-1)		0: Disable
53.		Alarm Self-lock	(0-1)		0: Disable
54.		Threshold	(0-200.0)%		10.0
55.		Return Value	(0-200.0)%		5.0
56.		Delay Value	(0.1-3600.0)s		5.0
57.		Alarm Type	(0-6)	1: Warning	
58.	Active Range	(0-20)	3: After Gen Close		

No.	Items	Range	Default	Description
59.	Current SHD 2 Set	Action	(0-1)	0: Disable
60.		Auto ACK	(0-1)	0: Disable
61.		Alarm Self-lock	(0-1)	0: Disable
62.		Threshold	(0-200.0)%	10.0
63.		Return Value	(0-200.0)%	5.0
64.		Delay Value	(0.1-3600.0)s	5.0
65.		Alarm Type	(0-6)	1: Warning
66.		Active Range	(0-20)	3: After Gen Close
67.	Gen Current 1 Set	Action	(0-1)	1: Enable
68.		Auto ACK	(0-1)	0: Disable
69.		Alarm Self-lock	(0-1)	0: Disable
70.		Threshold	(0-200.0)%	100.0
71.		Return Value	(0-200.0)%	99.0
72.		Delay Value	(0.1-3600.0)s	20.0
73.		Alarm Type	(0-6) 0: Block 1: Warning 2: Trip 3: Trip and Stop 4: Safety Trip 5: Safety Trip and Stop 6: Indication	1: Warning
74.	Active Range	(0-20) 0: Always Active 1: Inactive 2: Before Gen Close 3: After Gen Close 4: Gen Close on Bus 5: No Gen Close on Bus 6: Gen Normal 7: Other Gens Close 8: Start Delay 9: After Gen Close Delay 10: Before Gen Close Delay	0: Always Active	

No.	Items	Range	Default	Description	
		11: Gen Load Normal 12: Gen Close Delay on Bus 13: No Gen Close Delay on Bus 14: Gen Normal Delay 15: Other Gens Close Delay 16: Gen Load Normal Delay 17-20: Reserved			
75.	Gen Current 2 Set	Action	(0-1)	1: Enable	
76.		Auto ACK	(0-1)	0: Disable	
77.		Alarm Self-lock	(0-1)	0: Disable	
78.		Threshold	(0-200.0)%	110.0	
79.		Return Value	(0-200.0)%	109.0	
80.		Delay Value	(0.1-3600.0)s	60.0	
81.		Alarm Type	(0-6)	2: Trip	
82.		Active Range	(0-20)	0: Always Active	
83.	Gen Current 3 Set	Action	(0-1)	1: Enable	
84.		Auto ACK	(0-1)	0: Disable	
85.		Alarm Self-lock	(0-1)	0: Disable	
86.		Threshold	(0-200.0)%	130.0	
87.		Return Value	(0-200.0)%	129.0	
88.		Delay Value	(0.1-3600.0)s	30.0	
89.		Alarm Type	(0-6)	2: Trip	
90.	Active Range	(0-20)	0: Always Active		
91.	Gen Current 4 Set	Action	(0-1)	1: Enable	
92.		Auto ACK	(0-1)	0: Disable	
93.		Alarm Self-lock	(0-1)	0: Disable	
94.		Threshold	(0-200.0)%	150.0	
95.		Return Value	(0-200.0)%	149.0	
96.		Delay Value	(0.1-3600.0)s	10.0	
97.		Alarm Type	(0-6)	2: Trip	
98.		Active Range	(0-20)	0: Always Active	
99.	Gen Current	Action	(0-1)	0: Disable	Inverse time overcurrent. The

No.	Items	Range	Default	Description
100.	5 Set	Auto ACK	(0-1)	0: Disable
101.		Alarm Self-lock	(0-1)	0: Disable
102.		Threshold	(0-200.0)%	120.0
103.		Return Value	(0-200.0)%	119.0
104.		Delay Value	(0.1-36.0)s	12.0
105.		Alarm Type	(0-6)	1: Warning
106.		Active Range	(0-20)	0: Always Active
107.	Gen Current 6 Set	Action	(0-1)	0: Disable
108.		Auto ACK	(0-1)	0: Disable
109.		Alarm Self-lock	(0-1)	0: Disable
110.		Threshold	(0-200.0)%	140.0
111.		Return Value	(0-200.0)%	139.0
112.		Delay Value	(0.1-36.0)s	36.0
113.		Alarm Type	(0-6)	2: Trip
114.	Active Range	(0-20)	0: Always Active	
115.	Unbalanced Current 1 Set	Action	(0-1)	1: Enable
116.		Auto ACK	(0-1)	0: Disable
117.		Alarm Self-lock	(0-1)	0: Disable
118.		Threshold	(0-200.0)%	20.0
119.		Return Value	(0-200.0)%	19.0
120.		Delay Value	(0.1-3600.0)s	5.0
121.		Alarm Type	(0-6)	1: Warning
122.	Active Range	(0-20)	3: After Gen Close	
123.	Unbalanced Current 2 Set	Action	(0-1)	0: Disable
124.		Auto ACK	(0-1)	0: Disable
125.		Alarm Self-lock	(0-1)	0: Disable
126.		Threshold	(0-200.0)%	20.0
127.		Return Value	(0-200.0)%	19.0
128.		Delay Value	(0.1-3600.0)s	5.0
129.		Alarm Type	(0-6)	1: Warning
130.	Active Range	(0-20)	3: After Gen Close	
131.	Over Power 1 Set	Action	(0-1)	1: Enable
132.		Auto ACK	(0-1)	0: Disable
133.		Alarm Self-lock	(0-1)	0: Disable
134.		Threshold	(0-200.0)%	120.0
135.		Return Value	(0-200.0)%	119.0
136.		Delay Value	(0.1-3600.0)s	10.0
137.		Alarm Type	(0-6)	1: Warning



No.	Items	Range	Default	Description
138.	Active Range	(0-20)	0: Always Active	
139.	Action	(0-1)	1: Enable	
140.	Auto ACK	(0-1)	0: Disable	
141.	Alarm Self-lock	(0-1)	0: Disable	
142.	Threshold	(0-200.0)%	130.0	
143.	Return Value	(0-200.0)%	129.0	
144.	Delay Value	(0.1-3600.0)s	5.0	
145.	Alarm Type	(0-6)	2: Trip	
146.	Active Range	(0-20)	0: Always Active	
147.	Action	(0-1)	1: Enable	
148.	Auto ACK	(0-1)	0: Disable	
149.	Alarm Self-lock	(0-1)	0: Disable	
150.	Threshold	(0-200.0)%	8.0	
151.	Return Value	(0-200.0)%	7.0	
152.	Delay Value	(0.1-3600.0)s	5.0	
153.	Alarm Type	(0-6)	1: Warning	
154.	Active Range	(0-20)	0: Always Active	When controller detects reverse power value is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.
155.	Action	(0-1)	1: Enable	
156.	Auto ACK	(0-1)	0: Disable	
157.	Alarm Self-lock	(0-1)	0: Disable	
158.	Threshold	(0-200.0)%	15.0	
159.	Return Value	(0-200.0)%	14.0	
160.	Delay Value	(0.1-3600.0)s	2.0	
161.	Alarm Type	(0-6)	2: Trip	
162.	Active Range	(0-20)	0: Always Active	
163.	Action	(0-1)	1: Enable	
164.	Auto ACK	(0-1)	0: Disable	
165.	Alarm Self-lock	(0-1)	0: Disable	
166.	Threshold	(0-200.0)%	0.70	
167.	Return Value	(0-200.0)%	0.75	
168.	Delay Value	(0.1-3600.0)s	5.0	
169.	Alarm Type	(0-6)	1: Warning	
170.	Active Range	(0-20)	16: Gen Load Normal Delay	When controller detects power factor is lower than set value, it will initiate alarm signal and alarm information will be displayed on LCD.
171.	Action	(0-1)	0: Disable	
172.	Auto ACK	(0-1)	0: Disable	
173.	Alarm Self-lock	(0-1)	0: Disable	
174.	Threshold	(0-200.0)%	0.70	

No.	Items	Range	Default	Description	
175.		Return Value	(0-200.0)%	0.75	
176.		Delay Value	(0.1-3600.0)s	5.0	
177.		Alarm Type	(0-6)	1: Warning	
178.		Active Range	(0-20)	16: Gen Load Normal Delay	
179.	Loss of Excitation 1 Alarm Set	Action	(0-1)	1: Enable	When controller detects the absolute value of reactive power is greater than set value, it will initiate alarm signal and alarm information will be displayed on LCD.
180.		Auto ACK	(0-1)	0: Disable	
181.		Alarm Self-lock	(0-1)	0: Disable	
182.		Threshold	(0-200.0)%	20.0	
183.		Return Value	(0-200.0)%	19.0	
184.		Delay Value	(0.1-3600.0)s	10.0	
185.		Alarm Type	(0-6)	1: Warning	
186.	Active Range	(0-20)	0: Always Active		
187.	Loss of Excitation 2 Alarm Set	Action	(0-1)	0: Disable	
188.		Auto ACK	(0-1)	0: Disable	
189.		Alarm Self-lock	(0-1)	0: Disable	
190.		Threshold	(0-200.0)%	20.0	
191.		Return Value	(0-200.0)%	19.0	
192.		Delay Value	(0.1-3600.0)s	10.0	
193.		Alarm Type	(0-6)	1: Warning	
194.	Active Range	(0-20)	0: Always Active		
195.	Active Distribution Imbalance 1	Action	(0-1)	1: Enable	Action for active distribution percentage is greater that set value.
196.		Auto ACK	(0-1)	0: Disable	
197.		Alarm Self-lock	(0-1)	0: Disable	
198.		Threshold	(0-200.0)%	20.0	
199.		Return Value	(0-200.0)%	18.0	
200.		Delay Value	(0.1-3600.0)s	60.0	
201.		Alarm Type	(0-6)	1: Warning	
202.		Active Range	(0-20)	3: After Gen Close	
203.	Active Distribution Imbalance 2	Action	(0-1) 0: Disable 1: Enable	0: Disable	
204.		Auto ACK	(0-1)	0: Disable	
205.		Alarm Self-lock	(0-1)	0: Disable	
206.		Threshold	(0-200.0)%	20.0	
207.		Return Value	(0-200.0)%	18.0	
208.		Delay Value	(0.1-3600.0)s	60.0	
209.		Alarm Type	(0-6)	1: Warning	
210.		Active Range	(0-20)	3: After Gen	

No.	Items	Range	Default	Description		
			Close			
211.	Reactive Distribution Imbalance 1	Action	(0-1)	1: Enable	Action for reactive distribution percentage is greater that set value.	
212.		Auto ACK	(0-1)	0: Disable		
213.		Alarm Self-lock	(0-1)	0: Disable		
214.		Threshold	(0-200.0)%	20.0		
215.		Return Value	(0-200.0)%	18.0		
216.		Delay Value	(0.1-3600.0)s	60.0		
217.		Alarm Type	(0-6)	1: Warning		
218.		Active Range	(0-20)	3: After Gen Close		
219.	Reactive Distribution Imbalance 2	Action	(0-1)	0: Disable		
220.		Auto ACK	(0-1)	0: Disable		
221.		Alarm Self-lock	(0-1)	0: Disable		
222.		Threshold	(0-200.0)%	20.0		
223.		Return Value	(0-200.0)%	18.0		
224.		Delay Value	(0.1-3600.0)s	60.0		
225.		Alarm Type	(0-6)	1: Warning		
226.		Active Range	(0-20)	3: After Gen Close		
227.		Auto ACK	(0-1)	0: Disable	When any bus genset power is greater than set value, external non-essential load 1 will trip.	
228.		Alarm Self-lock	(0-1)	0: Disable		
229.		Alarm Type	(0-6)	1: Warning		
230.		Active Range	(0-20)	0: Always Active		
231.	Power Trip	Action	(0-1)	1: Enable		
232.		Threshold	(0-200.0)%	100.0		
233.		Return Value	(0-200.0)%	99.0		
234.		Delay Value	(0.1-3600.0)s	5.0		
235.	NEL 1 Trip	Action	(0-1)	0: Disable		When any bus genset current is greater than set value, external non-essential load 1 will trip.
236.		Threshold	(0-200.0)%	100.0		
237.		Return Value	(0-200.0)%	99.0		
238.		Delay Value	(0.1-999.9)s	5.0		
239.		Chinese Character String		非重要负载 1	Character string only can be set via upper computer.	
240.		English Character String		NEL1		
241.	NEL2	Auto ACK	(0-1)	0: Disable		
242.	Trip	Alarm Self-lock	(0-1)	0: Disable		

No.	Items		Range	Default	Description
243.	Alarm Type		(0-6)	1: Warning	
244.	Active Range		(0-20)	0: Always Active	
245.	Power Trip	Action	(0-1)	1: Enable	
246.		Threshold	(0-200.0)%	100.0	
247.		Return Value	(0-200.0)%	99.0	
248.		Delay Value	(0.1-3600.0)s	8.0	
249.	Current Trip	Action	(0-1)	0: Disable	When any bus genset current is greater than set value, external non-essential load 2 will trip.
250.		Threshold	(0-200.0)%	100.0	
251.		Return Value	(0-200.0)%	99.0	
252.		Delay Value	(0.1-3600.0)s	8.0	
253.	Chinese Character String			非重要负载 2	Character string only can be set via upper computer.
254.	English Character String			NEL2	
255.	Auto ACK		(0-1)	0: Disable	
256.	Alarm Self-lock		(0-1)	0: Disable	
257.	Alarm Type		(0-6)	1: Warning	
258.	Active Range		(0-20)	0: Always Active	
259.	NEL 3 Trip	Action	(0-1)	1: Enable	When any bus genset current is greater than set value, external non-essential load 3 will trip.
260.		Threshold	(0-200.0)%	100.0	
261.		Return Value	(0-200.0)%	99.0	
262.		Delay Value	(0.1-3600.0)s	10.0	
263.	Current Trip	Action	(0-1)	0: Disable	When any bus genset current is greater than set value, external non-essential load 3 will trip.
264.		Threshold	(0-200.0)%	100.0	
265.		Return Value	(0-200.0)%	99.0	
266.		Delay Value	(0.1-3600.0)s	10.0	
267.	Chinese Character String			非重要负载 3	Character string only can be set via upper computer.
268.	English Character String			NEL3	
269.	Heavy Consumer 1	Feedback Type	(0-4)	0	0 Digital Input Feedback 1 AI1 Input Feedback

No.	Items	Range	Default	Description
				2 AI2 Input Feedback 3 HMP300-1 Comm. Feedback 4 HMP300-2 Comm. Feedback
270.	Inquiry Signal	(0-1)	0	0 Continuous Signal; 1 Trigger Signal
271.	ID	(0-128)	128	Heavy consumer ID number.
272.	Priority	(0-128)	128	HC priority. The smaller the number, the higher the priority. If the priority is same, HC with small ID number, the priority is high.
273.	Rated Power	(0-60000)kW	60	HC rated power.
274.	Inquiry Power	(0-60000)kW	90	The percentage of rated power relative to heavy consumer.
275.	Stable Time	(0-3600)s	5	Bus stable time before HC running.
276.	ACK Time	(0-3600)s	5	Output ACK signal time after meeting HC demand. It is continuous output when set as 0.
277.	Feedback Failure Time	(0-3600)s	5	Feedback signal detection time after HC ACK. It doesn't detect feedback failure when set as 0.
278.	Request Failure Time	(0-3600)s	120	Time between receiving HC inquiry signal and HC ACK. Controller will initiate alarm signal when time is over. It doesn't detect request failure when set as 0.
279.	Request Failure Action	(0-2)	0	0 Alarm 1 Trip NEL 2 Alarm and Trip NEL
280.	Chinese Character String		重载 1	Character string only can be set via upper computer.
281.	English Character String		HC1	
282.	Heavy Consumer 2	Feedback Type	(0-4)	0 0 Digital Input Feedback 1 AI1 Input Feedback 2 AI2 Input Feedback 3 HMP300-1 Comm. Feedback

No.	Items	Range	Default	Description
				4 HMP300-2 Comm. Feedback
283.	Inquiry Signal	(0-1)	0	0 Continuous Signal; 1 Trigger Signal
284.	ID	(0-128)	128	Heavy consumer ID number.
285.	Priority	(0-128)	128	HC priority. The smaller the number, the higher the priority. If the priority is same, HC with small ID number, the priority is high.
286.	Rated Power	(0-60000)kW	60	HC rated power.
287.	Inquiry Power	(0-60000)kW	90	The percentage of rated power relative to heavy consumer.
288.	Stable Time	(0-3600)s	5	Bus stable time before HC running.
289.	ACK Time	(0-3600)s	5	Output ACK signal time after meeting HC demand. It is continuous output when set as 0.
290.	Feedback Failure Time	(0-3600)s	5	Feedback signal detection time after HC ACK. It doesn't detect feedback failure when set as 0.
291.	Request Failure Time	(0-3600)s	120	Time between receiving HC inquiry signal and HC ACK. Controller will initiate alarm signal when time is over. It doesn't detect request failure when set as 0.
292.	Request Failure Action	(0-2)	0	0 Alarm 1 Trip NEL 2 Alarm and Trip NEL
293.	Chinese Character String		重载 2	Character string only can be set via upper computer.
294.	English Character String		HC2	
295.	Heavy Consumer 3	Feedback Type	(0-4)	0 1 AI1 Input Feedback 2 AI2 Input Feedback 3 HMP300-1 Comm. Feedback 4 HMP300-2 Comm. Feedback
296.		Inquiry Signal	(0-1)	0 Continuous Signal; 1 Trigger

No.	Items	Range	Default	Description
				Signal
297.	ID	(0-128)	128	Heavy consumer ID number.
298.	Priority	(0-128)	128	HC priority. The smaller the number, the higher the priority. If the priority is same, HC with small ID number, the priority is high.
299.	Rated Power	(0-60000)kW	60	HC rated power.
300.	Inquiry Power	(0-60000)kW	90	The percentage of rated power relative to heavy consumer.
301.	Stable Time	(0-3600)s	5	Bus stable time before HC running.
302.	ACK Time	(0-3600)s	5	Output ACK signal time after meeting HC demand. It is continuous output when set as 0.
303.	Feedback Failure Time	(0-3600)s	5	Feedback signal detection time after HC ACK. It doesn't detect feedback failure when set as 0.
304.	Request Failure Time	(0-3600)s	120	Time between receiving HC inquiry signal and HC ACK. Controller will initiate alarm signal when time is over. It doesn't detect request failure when set as 0.
305.	Request Failure Action	(0-2)	0	0 Alarm 1 Trip NEL 2 Alarm and Trip NEL
306.	Chinese Character String		重载 3	Character string only can be set via upper computer.
307.	English Character String		HC3	
308.	Heavy Consumer 4 Feedback Type	(0-4)	0	0 Digital Input Feedback 1 AI1 Input Feedback 2 AI2 Input Feedback 3 HMP300-1 Comm. Feedback 4 HMP300-2 Comm. Feedback
309.	Inquiry Signal	(0-1)	0	0 Continuous Signal; 1 Trigger Signal
310.	ID	(0-128)	128	Heavy consumer ID number.

No.	Items	Range	Default	Description
311.	Priority	(0-128)	128	HC priority. The smaller the number, the higher the priority. If the priority is same, HC with small ID number, the priority is high.
312.	Rated Power	(0-60000)kW	60	HC rated power.
313.	Inquiry Power	(0-60000)kW	90	The percentage of rated power relative to heavy consumer.
314.	Stable Time	(0-3600)s	5	Bus stable time before HC running.
315.	ACK Time	(0-3600)s	5	Output ACK signal time after meeting HC demand. It is continuous output when set as 0.
316.	Feedback Failure Time	(0-3600)s	5	Feedback signal detection time after HC ACK. It doesn't detect feedback failure when set as 0.
317.	Request Failure Time	(0-3600)s	120	Time between receiving HC inquiry signal and HC ACK. Controller will initiate alarm signal when time is over. It doesn't detect request failure when set as 0.
318.	Request Failure Action	(0-2)	0	0 Alarm 1 Trip NEL 2 Alarm and Trip NEL
319.	Chinese Character String		重载 4	Character string only can be set via upper computer.
320.	English Character String		HC4	

**12.6 TIMER SETTING**

**Table 31 – Timer Settings**

No.	Items	Range	Default	Description
Timer Setting				
1	Start Delay	(0-3600)s	5	Time from start signal is active to genset start.
2	Stop Delay	(0-3600)s	30	Time from start signal is deactivated to genset stop.
3	Start Output Delay	(0-3600)s	8	Start relay output time. When it is 0, means output constantly.
4	Stop Output Delay	(0-3600)s	5	Stop relay output time. When it is 0, means output constantly.
5	Start Wait Delay	(0-3600)s	120	Time from start signal is active to on-load requirement is satisfied. If the requirement doesn't be satisfied but delay time is up, then the warning alarm will be initiated.
6	Stop Wait Delay	(0-3600)s	20	After the "Wait For Stop" delay, the genset is stopped successfully if the voltage and frequency are 0; while the warning alarm will be initiated if they are not 0.
7	Load Stable Delay	(0-3600)s	5	When genset starts success and on-load stable delay is beginning.
8	Transient Fault Delay	(0-100.0)s	2.0	After the on-load stable delay, If the voltage and frequency requirements are not satisfied after the transient fault delay has expired, then the "Freq/Volt Fault" alarm will be initiated.
9	Alarm Start Delay	(0-3600)s	1	Start delay caused by trip or shutdown alarm.
10	Trigger Start Delay	(0-3600)s	1	Start delay caused by human triggered (e.g. manual transfer priority, heavy consumer request and etc.)
11	Alarm Stop Delay	(0-3600)s	1	Stop delay caused by the trip or shutdown alarms.
12	Trigger Stop Delay	(0-3600)s	1	Stop delay caused by human triggered (e.g. manual transfer priority, heavy consumer request and etc.)

No.	Items	Range	Default	Description
13	Cooling Delay	(0-3600)s	0	High speed cooling time before stop output.
14	Gen Insufficient Delay	(0-3600.0)s	1.5	When current genset power can't meet load demand, alarm will be initiated after delay.
15	Crank Success Delay	(0-3600.0)s	2.0	It is considered that crank success after conditions are met and delay continues in crank rest, then it enters stable load after crank rest is over.
16	Fast Start Delay	(0-3600)s	2	Time from auto fast start conditions are active to start output rest.
17	Fast Stop Delay	(0-3600)s	2	Time from auto fast stop conditions are active to stop output rest.
18	SG-DG Max. Grid-connection Time	(0-3600.0)s	60.0	The max grid-connection time of SG and DG, alarm will be initiated when the time is over.

## 12.7 ANALOG INPUT PORTS SETTING

Table 32 – Analog Input Ports Setting

No.	Items	Range	Default	Description
Analog Input Ports Setting				
Analog Input Port 1				
1	Function	(0-4)	0	0: Not Used 1: Fixed Active Power Input 2: Fixed Reactive Power Input 3: HC Feedback Input 4: Temperature Sensor
2	Type	(0-2)	0	0: Resistance Type 1: Current Type 2: Voltage Type
3	Input Min. Value	(0.0-1000.0) $\Omega$ /mA/V	0.0	Unit is changed according to type.
4	Input Max Value	(0.0-1000.0) $\Omega$ /mA/V	600.0	
5	HC Feedback Range	(0-60000)kW	100	
6	Open Action	(0-6)	1	
7	Curve Type	(0-15)	0	
8	Upper Limit 1	Action	(0-1)	0: Disable
9		Auto ACK	(0-1)	0: Disable
10		Alarm Self-lock	(0-1)	0: Disable
11		Threshold	(0.0-1000.0) $^{\circ}$ C	100.0
12		Return Value	(0.0-1000.0) $^{\circ}$ C	90.0
13		Delay Value	(0.1-3600.0)s	5.0

No.	Items	Range	Default	Description
14	Alarm Type	(0-6)	1	
15	Active Range	(0-20)	0: Always Active	
16	Action	(0-1)	0: Disable	
17	Auto ACK	(0-1)	0: Disable	
18	Alarm Self-lock	(0-1)	0: Disable	
19	Upper Limit 2 Threshold	(0.0-1000.0)°C	90.0	
20	Return Value	(0.0-1000.0)°C	80.0	
21	Delay Value	(0.1-3600.0)s	5.0	
22	Alarm Type	(0-6)	1	
23	Active Range	(0-20)	0: Always Active	
24	Action	(0-1)	0: Disable	
25	Auto ACK	(0-1)	0: Disable	
26	Alarm Self-lock	(0-1)	0: Disable	
27	Lower Limit 1 Threshold	(0.0-1000.0)°C	10.0	
28	Return Value	(0.0-1000.0)°C	20.0	
29	Delay Value	(0.1-3600.0)s	5.0	
30	Alarm Type	(0-6)	1	
31	Active Range	(0-20)	0: Always Active	
32	Action	(0-1)	0: Disable	
33	Auto ACK	(0-1)	0: Disable	
34	Alarm Self-lock	(0-1)	0: Disable	
35	Lower Limit 2 Threshold	(0.0-1000.0)°C	20.0	
36	Return Value	(0.0-1000.0)°C	30.0	
37	Delay Value	(0.1-3600.0)s	5.0	
38	Alarm Type	(0-6)	1	
39	Active Range	(0-20)	0: Always Active	
40	1 <sup>st</sup> Point X (Resistance)	(0-6000)	0	User-defined curve.
41	2 <sup>nd</sup> Point X (Resistance)	(0-6000)	21	
42	3 <sup>rd</sup> Point X (Resistance)	(0-6000)	28	
43	4 <sup>th</sup> Point X (Resistance)	(0-6000)	39	
44	5 <sup>th</sup> Point X (Resistance)	(0-6000)	56	
45	6 <sup>th</sup> Point X (Resistance)	(0-6000)	116	
46	7 <sup>th</sup> Point X (Resistance)	(0-6000)	258	
47	8 <sup>th</sup> Point X (Resistance)	(0-6000)	300	
48	1 <sup>st</sup> Point Y (Value)	(0-10000)	140	

No.	Items	Range	Default	Description	
49	2 <sup>nd</sup> Point Y (Value)	(0-10000)	110		
50	3 <sup>rd</sup> Point Y (Value)	(0-10000)	100		
51	4 <sup>th</sup> Point Y (Value)	(0-10000)	90		
52	5 <sup>th</sup> Point Y (Value)	(0-10000)	80		
53	6 <sup>th</sup> Point Y (Value)	(0-10000)	60		
54	7 <sup>th</sup> Point Y (Value)	(0-10000)	40		
55	8 <sup>th</sup> Point Y (Value)	(0-10000)	20		
<b>Analog Input Port 2</b>					
56	Function	(0-4)	0	0: Not Used 1: Fixed Active Power Input 2: Fixed Reactive Power Input 3: HC Feedback Input 4: Temperature Sensor	
57	Type	(0-2)	0	0: Resistance Type 1: Current Type 2: Voltage Type	
58	Input Min. Value	(0.0-1000.0)Ω/mA/V	0.0	Unit is changed according to type.	
59	Input Max Value	(0.0-1000.0)Ω/mA/V	600.0		
60	HC Feedback Range	(0-60000)kW	100		
61	Open Action	(0-6)	1		
62	Curve Type	(0-15)	0		
63	Upper Limit 1	Action	(0-1)	0: Disable	
64		Auto ACK	(0-1)	0: Disable	
65		Alarm Self-lock	(0-1)	0: Disable	
66		Threshold	(0.0-1000.0)°C	100.0	
67		Return Value	(0.0-1000.0)°C	90.0	
68		Delay Value	(0.1-3600.0)s	5.0	
69		Alarm Type	(0-6)	1	
70		Active Range	(0-20)	0: Always Active	
71	Upper Limit 2	Action	(0-1)	0: Disable	
72		Auto ACK	(0-1)	0: Disable	
73		Alarm Self-lock	(0-1)	0: Disable	
74		Threshold	(0.0-1000.0)°C	90.0	
75		Return Value	(0.0-1000.0)°C	80.0	
76		Delay Value	(0.1-3600.0)s	5.0	
77		Alarm Type	(0-6)	1	
78		Active Range	(0-20)	0: Always Active	
79	Lower	Action	(0-1)	0: Disable	

No.	Items	Range	Default	Description
80	Limit 1	Auto ACK	(0-1)	0: Disable
81		Alarm Self-lock	(0-1)	0: Disable
82		Threshold	(0.0-1000.0)°C	10.0
83		Return Value	(0.0-1000.0)°C	20.0
84		Delay Value	(0.1-3600.0)s	5.0
85		Alarm Type	(0-6)	1
86		Active Range	(0-20)	0: Always Active
87	Lower Limit 2	Action	(0-1)	0: Disable
88		Auto ACK	(0-1)	0: Disable
89		Alarm Self-lock	(0-1)	0: Disable
90		Threshold	(0.0-1000.0)°C	20.0
91		Return Value	(0.0-1000.0)°C	30.0
92		Delay Value	(0.1-3600.0)s	5.0
93		Alarm Type	(0-6)	1
94	Active Range	(0-20)	0: Always Active	
95	1 <sup>st</sup> Point X (Resistance)	(0-6000)	0	User-defined curve.
96	2 <sup>nd</sup> Point X (Resistance)	(0-6000)	21	
97	3 <sup>rd</sup> Point X (Resistance)	(0-6000)	28	
98	4 <sup>th</sup> Point X (Resistance)	(0-6000)	39	
99	5 <sup>th</sup> Point X (Resistance)	(0-6000)	56	
100	6 <sup>th</sup> Point X (Resistance)	(0-6000)	116	
101	7 <sup>th</sup> Point X (Resistance)	(0-6000)	258	
102	8 <sup>th</sup> Point X (Resistance)	(0-6000)	300	
103	1 <sup>st</sup> Point Y (Value)	(0-10000)	140	
104	2 <sup>nd</sup> Point Y (Value)	(0-10000)	110	
105	3 <sup>rd</sup> Point Y (Value)	(0-10000)	100	
106	4 <sup>th</sup> Point Y (Value)	(0-10000)	90	
107	5 <sup>th</sup> Point Y (Value)	(0-10000)	80	
108	6 <sup>th</sup> Point Y (Value)	(0-10000)	60	
109	7 <sup>th</sup> Point Y (Value)	(0-10000)	40	
110	8 <sup>th</sup> Point Y (Value)	(0-10000)	20	

## 12.8 DIGITAL INPUT PORTS SETTING

HPM6 input ports are low level active, response time is over 300ms.

**Table 33 – Input Ports Settings**

No.	Items	Range	Default	Description
<b>Input Ports</b>				
<b>Digital Input Port 1</b>				
111	Contents Setting	(0-150)	02	Close input.
112	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 2</b>				
113	Contents Setting	(0-150)	25	Manual mode input.
114	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 3</b>				
115	Contents Setting	(0-150)	28	Semi-auto mode input.
116	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 4</b>				
117	Contents Setting	(0-150)	29	Auto mode input.
118	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 5</b>				
119	Contents Setting	(0-150)	08	HC Inquiry 1.
120	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 6</b>				
121	Contents Setting	(0-150)	09	HC feedback 1.
122	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 7</b>				
123	Contents Setting	(0-150)	0	Not used.
124	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 8</b>				
125	Contents Setting	(0-150)	0	Not used.
126	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 9</b>				
127	Contents Setting	(0-150)	0	Not used.
128	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 10</b>				
129	Contents Setting	(0-150)	0	Not used.
130	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 11</b>				
131	Contents Setting	(0-150)	0	Not used.
132	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 12</b>				
133	Contents Setting	(0-150)	0	Not used.
134	Active Type	(0-1)	0	0: Close Activate 1: Open Activate

No.	Items	Range	Default	Description
<b>Digital Input Port 13</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 14</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 15</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 16</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 17</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 18</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 19</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate
<b>Digital Input Port 20</b>				
1	Contents Setting	(0-150)	0	Not used.
2	Active Type	(0-1)	0	0: Close Activate 1: Open Activate

**Table 34 – Input Ports Function**

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
0.	Not Used	Invalid	X	X	X
1.	User Defined	User-defined actions when input port is active: 0: Block 1: Warning 2: Trip 3: Trip and Stop 4: Safety Trip 5: Safety Trip and Stop 6: Indication User-defined active conditions of input port: 0: Always Active 1: Inactive	√	√	√

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
		2: Before Gen Close 3: After Gen Close 4: Gen Close on Bus 5: No Gen Close on Bus 6: Gen Normal 7: Other Gens Close 8: Start Delay 9: After Gen Close Delay 10: Before Gen Close Delay 11: Gen Load Normal 12: Gen Close Delay on Bus 13: No Gen Close Delay on Bus 14: Gen Normal Delay 15: Other Gens Close Delay 16: Gen Load Normal Delay 17: Reserved 18: Reserved 19: Reserved 20: Reserved Input ports names can be downloaded into controller after defined using PC software.			
2.	Close Input	Switch close feedback signal input, used for indicating switch close/open status. If this signal no corresponding response in c/o, controller will initiate feedback fault alarm. There must be one and only one input port to select this function, otherwise controller will initiate feedback fault alarm.	√	√	√
3.	Open Input	Switch open feedback signal input, opposite the close feedback signal. After it is configured for input port, switch status must be indicated with close input and open input. If two signals are not matched or signal is not correct in c/o, controller will initiate feedback fault alarm.	√	√	√
4.	Speed Raise	Speed raise relay is active when the input is active.	X	X	√
5.	Speed Drop	Speed drop relay is active when the input is active.	X	X	√
6.	Volt Raise	Voltage raise relay is active when the input is active.	X	X	√

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
7.	Volt Drop	Voltage drop relay is active when the input is active.	X	X	√
8.	HC 1 Inquiry	Heavy consumer 1 inquiry. Acknowledge signal is initiated if the requirements are satisfied. If not satisfied, standby gensets will be started to meet with the requirement.	√	√	X
9.	HC 1 Feedback	After breaker closing, feedback signal is sent to controller to ensure the HC1 has loaded.	√	√	X
10.	HC 2 Inquiry	Heavy consumer 2 inquiry. Acknowledge signal is initiated if the requirements are satisfied. If not satisfied, standby gensets will be started to meet with the requirement.	√	√	X
11.	HC 2 Feedback	After breaker closing, feedback signal is sent to controller to ensure the HC2 has loaded.	√	√	X
12.	HC 3 Inquiry	Heavy consumer 3 inquiry. Acknowledge signal is initiated if the requirements are satisfied. If not satisfied, standby gensets will be started to meet with the requirement.	√	√	X
13.	HC 3 Feedback	After breaker closing, feedback signal is sent to controller to ensure the HC3 has loaded.	√	√	X
14.	HC 4 Inquiry	Heavy consumer 4 inquiry. Acknowledge signal is initiated if the requirements are satisfied. If not satisfied, standby gensets will be started to meet with the requirement.	√	√	X
15.	HC 4 Feedback	After breaker closing, feedback signal is sent to controller to ensure the HC4 has loaded.	√	√	X
16.	Engine Fault	Engine fault feedback input.	√	√	X
17.	Alarm Inhibit	All alarms are inhibited after input is active.	√	√	√
18.	Alarm Mute	Mute the panel buzzer and audible alarm not output.	√	√	√
19.	Alarm Reset	Reset alarms.	√	√	√
20.	Alarm ACK	Acknowledge all alarms.	√	√	√
21.	Alarm Unlock	Unlock all self-locked alarms.	√	√	√
22.	Lamp Test	Test all the LED lights.	√	√	√

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
23.	Light Consumer	The controller doesn't open breaker even if the system load has fallen below the set value.	√	√	X
24.	Fixed Power IN	Fixed power output, when the "Fixed Power Input" is active, the active power and the reactive power can be adjusted via fixed power setting parameter, or when the external adjust input is active, the active power and the reactive power can be adjusted via external SPEED IN port and VOLT IN port.	√	√	X
25.	Manual Mode	Manual mode is carried out when the input is active.	√	X	X
26.	Linear Start	Linear start mode is carried out when the input is active.	√	X	X
27.	Duty Time Start	Duty time start mode is carried out when the input is active.	√	X	X
28.	Auto Mode	Auto mode is carried out when the input is active.	√	√	√
29.	Semi-auto Mode	Semi-auto mode is carried out when the input is active.	√	√	√
30.	Remote Closing	Synchronous closing process will be carried out when the input is active.	X	√	X
31.	Remote Opening	Opening process will be carried out when the input is active.	X	√	X
32.	Remote Start	The genset will start automatically when the input is active.	X	√	X
33.	Remote Stop	The genset will stop after unload open when the input is active.	X	√	X
34.	Safe Mode	An additional genset will be started even if the power request is satisfied when the input is active.	√	X	X
35.	Standby Engine	Connect the output signal when the preparation work is done. If the function is selected, the engine will be started when the input is active.	√	√	X
36.	Remote Mode	If it is configured, system is in remote control status when the input is active, remote control (start, close, open, stop) function is active. When the input is inactive, remote control (start, close, open, stop) function is inactive.	X	√	X

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
37.	External Active Adjust	Simulate adjust frequency/active power input is active when the input port is active. Controller automatically adjust frequency/active power according to configuration when the input port is inactive.	X	√	√
38.	Start Inhibit	Semi-auto start and auto start are inhibited.	√	√	X
39.	External Overcurrent Short Circuit	External over current short circuit trip signal.	√	√	X
40.	Override Input	Genset is inhibited to trip or shutdown except for over frequency and over current.	√	√	X
41.	Emergency Trip and Stop	Trip and stop immediately.	√	√	X
42.	Top Priority	Configure the priority of controller as the highest level.	√	√	X
43.	2 <sup>nd</sup> Start Input	If it fails to start, after this input is active, it will issue start signal again.	√	√	X
44.	Manual Mode	When input is active, all gensets on the bus become manual mode.	√	√	√
45.	Semi-auto Mode	When input is active, all gensets on the bus become semi-auto mode.	√	√	√
46.	Auto Mode	When input is active, all gensets on the bus becomes auto mode.	√	√	√
47.	Light Consumer	When input is active, all gensets on the bus are active for light consumer.	√	X	X
48.	Safe Mode Input	When input is active, all gensets on the bus become safe mode.	√	X	X
49.	Semi-auto/Auto Transfer Input	When input is active, auto mode is active; When input is inactive, semi-auto mode is active.	√	√	√
50.	Genset On-load Input Inhibit	When input is active, genset close is inhibited.	√	√	X
51.	Non-auto Mode HC Permission	When input is active, in manual mode/semi-auto mode, if genset capacity meets heavy consumer request power, it will also output heavy consumer response, heavy consumer permission signal.	√	√	√
52.	Limited On-grid No.	When input is active, limit genset on grid number based on configuration (max. on-grid number).	√	√	X

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
53.	Engine Running Feedback	Engine running feedback active signal.	√	√	X
54.	Shore Power Supply Input	This input is active when shore power is closed.	√	√	√
55.	Bustie Switch 1 Break Input	When input port is active, divide a phase of bus based on current bus genset configuration; only the unit scheduled on this bus is active.	√	√	X
56.	Capacity Insufficient Reduce Load Input	When heavy consumer is requesting, if all normal gensets are on grid and still cannot meet requested power, and this input is active, it will make NEL trip.	√	√	√
57.	Abnormal Trip of Main Switch	When the input port is active, the controller issues trip alarms.	√	√	√
58.	Numbers of Running Units Reserved	When the input port is active, the units with load running on grid $\geq$ numbers of running units reserved.	√	√	√
59.	Forced Manual Mode	Controller is forced to enter manual mode when the input port is active. Its priority is higher than system mode.	√	√	√
60.	Inhibit Blackout	Block is inhibited when the input port is active.	√	√	X
61.	Forced Auto Mode	Controller is forced to enter auto mode when the input port is active. Its priority is higher than system mode.	√	√	X
62.	Reserved	Reserved			
63.	SG Enabled	If module is not set as SG mode, the controller will work in SG mode when input port is active.	√	√	X
64.	SG/DG Transferring	When input port is active, DG starts to take load, otherwise, SG starts to take load.	√	√	X
65.	SG Solenoid Valve Closing Feedback	When the controller works in SG mode and input port is active, SG is allowed to start. Otherwise, SG is not allowed to start.	√	√	X
66.	Drop Power Input	When input port is active, the controller will limit the max. output power of the genset according to the set drop value.	√	√	X
67.	SG On-load Input	When input port is active, SG starts to take load and select load distribution according to load mode.	√	√	X
68.	DG On-load Input	When input port is active, DG starts to take load and select load distribution according	√	√	X

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
		to load mode.			
69.	DG Inactive Input	When input port is active, all DG are disconnected and the load is transferred to the other power supply units.	√	√	X
70.	Bus Outage Closing Input	When input port is active, DG controller detects that the bus is outage then allows DG switch to close.	√	√	X
71.	Bustie Switch 0 Close Feedback	Bustie switch 0 is ring bustie switch, i.e. if there are N buses, it is the contact switch between bus 1 and bus N. Power management system considers that ring bus switch is closed when the input port is active.	√	√	X
72.	Bustie Switch 1 Close Feedback	Bustie switch close feedback input between bus 1 and bus 2.	√	√	X
73.	Bustie Switch 2 Close Feedback	Bustie switch close feedback input between bus 2 and bus 3.	√	√	X
74.	Bustie Switch 3 Close Feedback	Bustie switch close feedback input between bus 3 and bus 4.	√	√	X
75.	Bustie Switch 4 Close Feedback	Bustie switch close feedback input between bus 4 and bus 5.	√	√	X
76.	Bustie Switch 5 Close Feedback	Bustie switch close feedback input between bus 5 and bus 6.	√	√	X
77.	Bustie Switch 0 Open Feedback	Bustie switch 0 is ring bustie switch, ring bus switch open feedback input.	√	√	X
78.	Bustie Switch 1 Open Feedback	Bustie switch open feedback input between bus 1 and bus 2.	√	√	X
79.	Bustie Switch 2 Open Feedback	Bustie switch open feedback input between bus 2 and bus 3.			
80.	Bustie Switch 3 Open Feedback	Bustie switch open feedback input between bus 3 and bus 4.	√	√	X
81.	Bustie Switch 4 Open Feedback	Bustie switch open feedback input between bus 4 and bus 5.	√	√	X
82.	Bustie Switch 5 Open Feedback	Bustie switch open feedback input between bus 5 and bus 6.	√	√	X
83.	BTB0 Series Switch Close	It is close feedback input of series switch of ring bustie switch. Series switch means	√	√	X

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
	Feedback	that if there are N buses, other series switches besides bus contact switch between bus 1 and bus N.			
84.	BTB1 Series Switch Close Feedback	Bustie series switch close feedback input between bus 1 and bus 2.	√	√	X
85.	BTB2 Series Switch Close Feedback	Bustie series switch close feedback input between bus 2 and bus 3.	√	√	X
86.	BTB3 Series Switch Close Feedback	Bustie series switch close feedback input between bus 3 and bus 4.	√	√	X
87.	BTB4 Series Switch Close Feedback	Bustie series switch close feedback input between bus 4 and bus 5.	√	√	X
88.	BTB5 Series Switch Close Feedback	Bustie series switch close feedback input between bus 1 and bus 6.	√	√	X
89.	Reserved Power 1 Input	Power management system reserves response set power for bus when the input port is active.	√	X	X
90.	Reserved Power 2 Input		√	X	X
91.	Reserved Power 3 Input		√	X	X
92.	GB Storage Feedback	It means genset mains switch energy storage is finished, power management system can initiate close operation when the input port is active.	√	√	X
93.	Single Pulse Speed Raise Input	In manual mode, when the input port is closed once, the minimum pulse value is output from speed control output port.	X	X	√
94.	Single Pulse Speed Drop Input		X	X	√
95.	Single Pulse Voltage Raise Input	In manual mode, when the input port is closed once, the minimum pulse value is output from voltage control output port.	X	X	√
96.	Single Pulse Voltage Drop Input		X	X	√
97.	Shore Switch 0 Close	Shore switch close feedback input.	√	√	X

No.	Name	Description	Auto Mode	Semi-auto Mode	Manual Mode
	Feedback Input				
98.	Shore Switch 1 Close Feedback Input		√	√	X
99.	Shore Switch 2 Close Feedback Input		√	√	X
100.	Shore Switch 3 Close Feedback Input		√	√	X
101.	External Reactive Adjust	Simulate adjust voltage/reactive power input is active when the input port is active. Controller automatically adjust voltage/reactive power according to configuration when the input port is inactive.	√	√	X
102~150	Reserved	Reserved			

**12.9 DIGITAL OUTPUT PORTS SETTING**

**Table 35 – Output Ports Setting**

No.	Items	Range	Default	Description
Digital Output Ports				
Digital Output Port 1				
1	Contents Setting	Alarm/Function (0-255)	Function 007	Crank output.
2	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 2				
3	Contents Setting	Alarm/Function (0-255)	Function 008	Stop output.
4	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 3				
5	Contents Setting	Alarm/Function (0-255)	Function 001	Speed raise output.
6	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 4				
7	Contents Setting	Alarm/Function (0-255)	Function 002	Speed drop output.
8	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 5				
9	Contents Setting	Alarm/Function (0-255)	Function 062	HC1 ACK output.

No.	Items	Range	Default	Description
10	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 6				
11	Contents Setting	Alarm/Function (0-255)	Function 005	Close output.
12	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 7				
13	Contents Setting	Alarm/Function (0-255)	Fixed 006	Open output.
14	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 8				
15	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
16	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 9				
17	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
18	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 10				
19	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
20	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 11				
21	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
22	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 12				
23	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
24	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 13				
25	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
26	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 14				
27	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
28	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 15				
29	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
30	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 16				

No.	Items	Range	Default	Description
31	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
32	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 17				
33	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
34	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 18				
35	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
36	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 19				
37	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
38	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Digital Output Port 20				
39	Contents Setting	Alarm/Function (0-255)	Function 000	Not used.
40	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Defined Combination Output 1				
1	S1 Active Type	(0-1)0	0	Active type: 0 Close for inactive 1 Close for active Digital output port set function list.
2	S1 Set	Alarm/Function (0-255)	Alarm 000	
3	S2 Active Type	(0-1)0	0	
4	S2 Set	Alarm/Function (0-255)	Alarm 000	
5	S3 Active Type	(0-1)0	0	
6	S3 Set	Alarm/Function (0-255)	Alarm 000	
7	S4 Active Type	(0-1)0	0	
8	S4 Set	Alarm/Function (0-255)	Alarm 000	
9	S5 Active Type	(0-1)0	0	
10	S5 Set	Alarm/Function (0-255)	Alarm 000	
11	Delay Active Time	(0.0-60.0)s	0	
12	Delay Inactive Time	(0.0-60.0)s	0	
13	Active Time	(0.0-60.0)s	0	
Defined Combination Output 2-10				
1	S1 Active Type	(0-1)0	0	Active type: 0 Close for inactive 1 Close for active
2	S1 Set	Alarm/Function (0-255)	Alarm 000	

No.	Items	Range	Default	Description	
3	S2 Active Type	(0-1)0	0	Digital output port set function list.	
4	S2 Set	Alarm/Function (0-255)	Alarm 000		
5	S3 Active Type	(0-1)0	0		
6	S3 Set	Alarm/Function (0-255)	Alarm 000		
7	S4 Active Type	(0-1)0	0		
8	S4 Set	Alarm/Function (0-255)	Alarm 000		
9	S5 Active Type	(0-1)0	0		
10	S5 Set	Alarm/Function (0-255)	Alarm 000		
11	Delay Active Time	(0.0-60.0)s	0		
12	Delay Inactive Time	(0.0-60.0)s	0		
13	Active Time	(0.0-60.0)s	0		
Defined Period Output 1					
1	S1 Active Period	(0-0x7ff)	0		Active type: 0 Close for inactive 1 Close for active Digital output port set function list.
2	S1 Delay Active Time	(0.0-3600.0)s	0		
3	S1 Active Time	(0.0-3600.0)s	0		
4	S2 Active Type	(0-1)0	0		
5	S2 Set	Alarm/Function (0-255)	Alarm 000		
Defined Period Output 2-10					
1	S1 Active Period	(0-0x7ff)	0	Active type: 0 Close for inactive 1 Close for active Digital output port set function list.	
2	S1 Delay Active Time	(0.0-3600.0)s	0		
3	S1 Active Time	(0.0-3600.0)s	0		
4	S2 Active Type	(0-1)0	0		
5	S2 Set	Alarm/Function (0-255)	Alarm 000		

**Table 36 – Output Ports Function**

No.	Name	Description	Remark
0.	Not Used	This port is invalid.	
1.	Speed Raise	Active when the generator is raising speed.	
2.	Speed Drop	Active when the generator is dropping speed.	
3.	Volt Raise	Active when the generator is raising voltage.	
4.	Volt Drop	Active when the generator is dropping voltage.	
5.	Close Gen	Active when the close generator requirements are reached.	
6.	Open Gen	Active when the open generator requirements are reached.	
7.	Crank Output	Active when unit starts.	
8.	Stop Output	Active when stopping.	
9.	Remote Control	System can control its status via communication.	
10.	Generator OK	Active when the rated voltage and rated frequency are reached.	
11.	Common Alarm	Active when genset alarm occurs.	
12.	Common Indication Alarm	Active when genset indication alarm occurs.	
13.	Common Warning Alarm	Active when genset warning alarm occurs.	
14.	Common Block Alarm	Active when genset block alarm occurs.	
15.	Common Safety Trip Alarm	Active when genset safety trip alarm occurs.	
16.	Common Safety Trip and Stop Alarm	Active when genset safety trip and stop alarm occurs.	
17.	Common Trip Alarm	Active when genset trips alarm occurs.	
18.	Common Trip and Stop Alarm	Active when genset trip and stop alarm occurs.	
19.	Input 1 Active	Active when input port 1 is active.	
20.	Input 2 Active	Active when input port 2 is active.	
21.	Input 3 Active	Active when input port 3 is active.	
22.	Input 4 Active	Active when input port 4 is active.	
23.	Input 5 Active	Active when input port 5 is active.	
24.	Input 6 Active	Active when input port 6 is active.	
25.	Input 7 Active	Active when input port 7 is active.	
26.	Input 8 Active	Active when input port 8 is active.	
27.	Input 9 Active	Active when input port 9 is active.	
28.	Input 10 Active	Active when input port 10 is active.	
29.	Input 11 Active	Active when input port 11 is active.	
30.	Input 12 Active	Active when input port 12 is active.	
31.	Input 13 Active	Active when input port 13 is active.	
32.	Input 14 Active	Active when input port 14 is active.	

No.	Name	Description	Remark
33.	Input 15 Active	Active when input port 15 is active.	
34.	Input 16 Active	Active when input port 16 is active.	
35.	Input 17 Active	Active when input port 17 is active.	
36.	Input 18 Active	Active when input port 18 is active.	
37.	Input 19 Active	Active when input port 19 is active.	
38.	Input 20 Active	Active when input port 20 is active.	
39.	Reserved	Reserved	
40.	Reserved	Reserved	
41.	Defined Period Output 1	Set output according to defined period.	
42.	Defined Period Output 2		
43.	Defined Period Output 3		
44.	Defined Period Output 4		
45.	Defined Period Output 5		
46.	Defined Period Output 6		
47.	Defined Period Output 7		
48.	Defined Period Output 8		
49.	Defined Period Output 9		
50.	Defined Period Output 10		
51.	Defined Combination Output 1	Set output according to defined combination.	
52.	Defined Combination Output 2		
53.	Defined Combination Output 3		
54.	Defined Combination Output 4		
55.	Defined Combination Output 5		
56.	Defined Combination Output 6		
57.	Defined Combination Output 7		
58.	Defined Combination Output 8		
59.	Defined Combination Output 9		
60.	Defined Combination Output 10		
61.	Gen Load Indication	Active when gen takes load.	
62.	HC1 ACK	Active when bus left available power can meet heavy consumer 1 inquiry power.	
63.	HC2 ACK	Active when bus left available power can meet	

No.	Name	Description	Remark
		heavy consumer 2 inquiry power.	
64.	HC3 ACK	Active when bus left available power can meet heavy consumer 3 inquiry power.	
65.	HC4 ACK	Active when bus left available power can meet heavy consumer 4 inquiry power.	
66.	Start Failure	Active when start failure alarm occurs.	
67.	Manual Mode	Active in Manual mode.	
68.	Semi-auto Mode	Active in Semi-auto mode.	
69.	Auto Mode	Active in Auto mode.	
70.	Light Consumer	Active when light consumer outputs.	
71.	NEL 1 Trip	Active when non-essential load 1 trip occurs.	
72.	NEL 2 Trip	Active when non-essential load 2 trip occurs.	
73.	NEL 3 Trip	Active when non-essential load 3 trip occurs.	
74.	Engine Fault	Active when engine fault signal outputs.	
75.	Start Success	Active when the generator voltage and frequency have reached the requirement.	
76.	Synchronizing	Active when genset is synchronizing.	
77.	Reserved		
78.	Pre-close Output	Storage output of genset main switch.	
79.	Reserved		
80.	Reserved		
81.	PLC Flag 1	PLC logic flag outputs.	
82.	PLC Flag 2		
83.	PLC Flag 3		
84.	PLC Flag 4		
85.	PLC Flag 5		
86.	PLC Flag 6		
87.	PLC Flag 7		
88.	PLC Flag 8		
89.	PLC Flag 9		
90.	PLC Flag 10		
91.	PLC Flag 11		
92.	PLC Flag 12		
93.	PLC Flag 13		
94.	PLC Flag 14		
95.	PLC Flag 15		
96.	PLC Flag 16		
97.	PLC Flag 17		
98.	PLC Flag 18		
99.	PLC Flag 19		
100.	PLC Flag 20		
101.	Bu Voltage Abnormal		

No.	Name	Description	Remark
102.	Bus Frequency Abnormal		
103.	Bus Voltage/Frequency Abnormal		
104.	Lamp Alarm	When common alarm or common block occurs, it outputs cyclically every 1 second; it keeps outputting after acknowledge; if common trip and stop alarm occurs, it outputs cyclically every 0.5 second; it keeps outputting after acknowledge.	
105.	Audible Alarm	Output at common alarms, close to output after acknowledge.	
106.	Unload Failure		
107.	Unload Output		
108.	Gen Insufficient Capacity	When controller detects all normal gensets are on grid, and remaining power cannot request power, it outputs.	
109.	HC1 Permission	When HC requests, and bus power is met, it outputs; when power is not met, it doesn't output. If HC feedback signal is active, it continues to output.	
110.	HC2 Permission		
111.	HC3 Permission		
112.	HC4 Permission		
113.	Unbalanced Distribution of Active Power	Outputs when active power percentage and target active power percentage is greater than the set value.	
114.	Unbalanced Distribution of Reactive Power	Outputs when reactive power percentage and target reactive power percentage is greater than the set value.	
115.	Unbalanced Distribution of Load	Outputs when either unbalanced active distribution or reactive distribution is active.	
116.	Self-check Normal Output	Output when self-check conditions are met according to setting.	
117.	Reserved		
118.	Reserved		
119.	Reserved		
120.	Reserved		
121.	SG Solenoid Valve Closing	SG solenoid valve closes and outputs.	
122.	SG Solenoid Valve Opening	SG solenoid valve opens and outputs.	
123.	SG Insufficient Capacity	When the controller operates in SG mode and load receiving mode, if SG on-load is active, but SG capacity is insufficient to receive the full load, it outputs.	
124.	DG Insufficient Capacity	When the controller operates in SG mode and	

No.	Name	Description	Remark
		load receiving mode, if DG on-load is active, but DG capacity is insufficient to receive the full load, it outputs.	
125.	SG & DG Parallel No. Exceeds Limit	When SG and DG are on-grid at the same time or to be synchronized, the DG switch number exceeds the set value, it outputs.	
126.	Bus Freq. Change Abnormal	Output when the bus frequency change rate exceeds the set value and the delay value.	
127.	Gen. Freq. Change Abnormal	Generating frequency change rate exceeds the set value and the delay value.	
128.	Blackout	The controller outputs when it detects that the whole ship is black out.	
129.	NEL 1 Pre-tripping	Output when controller detects power, current is greater than NEL trip set value and in delay.	
130.	NEL 2 Pre-tripping		
131.	NEL 3 Pre-tripping		
132.	1# DIN16 IN1 Active	Outputs when DIN16-1 module input is active.	
133.	1# DIN16 IN2 Active		
134.	1# DIN16 IN3 Active		
135.	1# DIN16 IN4 Active		
136.	1# DIN16 IN5 Active		
137.	1# DIN16 IN6 Active		
138.	1# DIN16 IN7 Active		
139.	1# DIN16 IN8 Active		
140.	1# DIN16 IN9 Active		
141.	1# DIN16 IN10 Active		
142.	1# DIN16 IN11 Active		
143.	1# DIN16 IN12 Active		
144.	1# DIN16 IN13 Active		
145.	1# DIN16 IN14 Active		
146.	1# DIN16 IN15 Active		
147.	1# DIN16 IN16 Active		
148.	2# DIN16 IN1 Active	Outputs when DIN16-2 module input is active.	
149.	2# DIN16 IN2 Active		
150.	2# DIN16 IN3 Active		
151.	2# DIN16 IN4 Active		
152.	2# DIN16 IN5 Active		
153.	2# DIN16 IN6 Active		
154.	2# DIN16 IN7 Active		
155.	2# DIN16 IN8 Active		
156.	2# DIN16 IN9 Active		
157.	2# DIN16 IN10 Active		
158.	2# DIN16 IN11 Active		

No.	Name	Description	Remark
159.	2# DIN16 IN12 Active		
160.	2# DIN16 IN13 Active		
161.	2# DIN16 IN14 Active		
162.	2# DIN16 IN15 Active		
163.	2# DIN16 IN16 Active		
164-255	Reserved		

**Table 37 – Output Ports Alarms**

No.	Name	Description	Remark
0	Bus Over Voltage 1	Refer to alarm protection function description.	
1	Bus Over Voltage 2		
2	Bus Over Voltage 3		
3	Bus Under Voltage 1		
4	Bus Under Voltage 2		
5	Bus Under Voltage 3		
6	Bus Over Frequency 1		
7	Bus Over Frequency 2		
8	Bus Over Frequency 3		
9	Bus Under Frequency 1		
10	Bus Under Frequency 2		
11	Bus Under Frequency 3		
12	Bus ROCOF		
13	Bus Vector Shift		
14	Bus Loss of Phase		
15	Bus Reverse Phase Sequence		
16	Gen Over Voltage 1		
17	Gen Over Voltage 2		
18	Gen Over Voltage 3		
19	Gen Under Voltage 1		
20	Gen Under Voltage 2		
21	Gen Under Voltage 3		
22	Gen Over Frequency 1		
23	Gen Over Frequency 2		
24	Gen Over Frequency 3		
25	Gen Under Frequency 1		
26	Gen Under Frequency 2		
27	Gen Under Frequency 3		
28	Gen Over Current 1		
29	Gen Over Current 2		
30	Gen Over Current 3		
31	Gen Over Current 4		
32	Gen Over Current 5		

No.	Name	Description	Remark
33	Gen Over Current 6		
34	Gen ROCOF 1		
35	Gen ROCOF 2		
36	Gen Reverse Power 1		
37	Gen Reverse Power 2		
38	Gen Over Power 1		
39	Gen Over Power 2		
40	Gen Voltage Imbalance 1		
41	Gen Voltage Imbalance 2		
42	Gen Current Imbalance 1		
43	Gen Current Imbalance 2		
44	Earth Fault 1		
45	Earth Fault 2		
46	Gen Loss of Excitation 1		
47	Gen Loss of Excitation 2		
48	Voltage THD 1		
49	Voltage THD 2		
50	Low Power Factor 1		
51	Low Power Factor 2		
52	NEL 1 Trip		
53	NEL 2 Trip		
54	NEL 3 Trip		
55	Power Over Voltage 1		
56	Power Over Voltage 2		
57	Power Under Voltage 1		
58	Power Under Voltage 2		
59	Unbalanced Active Distribution 1		
60	Unbalanced Active Distribution 2		
61	Unbalanced Reactive Distribution 1		
62	Unbalanced Reactive Distribution 2		
63	Gen Insufficient Capacity		
64	Gen Loss of Phase		
65	Gen Reverse Phase Sequence		
66	Crank Failure		
67	No Running Feedback Fault		
68	Stop Failure		
69	Engine Fault		
70	Frequency/Voltage Fault		
71	Frequency Error		
72	External Start		
73	External Stop		
74	External Overcurrent Short		

No.	Name	Description	Remark
75	Emergency Stop		
76	Reserved		
77	Few Bus Module		
78	ID Address Error		
79	Bus Input Fault		
80	Abnormal Trip of Main Switch		
81	External Open of Main Switch		
82	Close Failure		
83	Open Failure		
84	Close Feedback Failure		
85	Open Feedback Failure		
86	Sync. Failure		
87	Unload Failure		
88	Bustie Switch 0 Feedback Fault		
89	Bustie Switch 1 Feedback Fault		
90	Bustie Switch 2 Feedback Fault		
91	Bustie Switch 3 Feedback Fault		
92	Bustie Switch 4 Feedback Fault		
93	Bustie Switch 5 Feedback Fault		
94	Bustie Switch 6 Feedback Fault		
95	Reserved		
96	Input Port 1		
97	Input Port 2		
98	Input Port 3		
99	Input Port 4		
100	Input Port 5		
101	Input Port 6		
102	Input Port 7		
103	Input Port 8		
104	Input Port 9		
105	Input Port 10		
106	Input Port 11		
107	Input Port 12		
108	Input Port 13		
109	Input Port 14		
110	Input Port 15		
111	Input Port 16		
112	Input Port 17		
113	Input Port 18		
114	Input Port 19		
115	Input Port 20		
116	Reserved		

No.	Name	Description	Remark
117	Reserved		
118	AI1 Open		
119	AI2 Open		
120	AI1 Upper Limit 1 Alarm		
121	AI1 Upper Limit 2 Alarm		
122	AI1 Lower Limit 1 Alarm		
123	AI1 Lower Limit 2 Alarm		
124	AI2 Upper Limit 1 Alarm		
125	AI2 Upper Limit 2 Alarm		
126	AI2 Lower Limit 1 Alarm		
127	AI2 Lower Limit 2 Alarm		
128	1#DIN16 IN1		
129	1#DIN16 IN2		
130	1#DIN16 IN3		
131	1#DIN16 IN4		
132	1#DIN16 IN5		
133	1#DIN16 IN6		
134	1#DIN16 IN7		
135	1#DIN16 IN8		
136	1#DIN16 IN9		
137	1#DIN16 IN10		
138	1#DIN16 IN11		
139	1#DIN16 IN12		
140	1#DIN16 IN13		
141	1#DIN16 IN14		
142	1#DIN16 IN15		
143	1#DIN16 IN16		
144	2#DIN16 IN1		
145	2#DIN16 IN2		
146	2#DIN16 IN3		
147	2#DIN16 IN4		
148	2#DIN16 IN5		
149	2#DIN16 IN6		
150	2#DIN16 IN7		
151	2#DIN16 IN8		
152	2#DIN16 IN9		
153	2#DIN16 IN10		
154	2#DIN16 IN11		
155	2#DIN16 IN12		
156	2#DIN16 IN13		
157	2#DIN16 IN14		
158	2#DIN16 IN15		

No.	Name	Description	Remark
159	2#DIN16 IN16		
160	1#DIN16 Comm. Failure		
161	2#DIN16 Comm. Failure		
162	1#DOOUT16 Comm. Failure		
163	2#DOOUT16 Comm. Failure		
164	Reserved		
165	Reserved		
166	Local Controller Comm. Failure		
167	1#HMP300 Comm. Failure		
168	2#HMP300 Comm. Failure		
169	Reserved		
170	Reserved		
171	Reserved		
172	PLC Function 1		
173	PLC Function 2		
174	PLC Function 3		
175	PLC Function 4		
176	PLC Function 5		
177	PLC Function 6		
178	PLC Function 7		
179	PLC Function 8		
180	PLC Function 9		
181	PLC Function 10		
182	PLC Function 11		
183	PLC Function 12		
184	PLC Function 13		
185	PLC Function 14		
186	PLC Function 15		
187	PLC Function 16		
188	PLC Function 17		
189	PLC Function 18		
190	PLC Function 19		
191	PLC Function 20		
192	SG&DG Parallel No. Exceeds		
193	SG Insufficient Capacity		
194	DG Insufficient Capacity		
195	SG&DG Grid-connection Timeout		
196	SG Solenoid Valve Fault		
197	Reserved		
198	Reserved		
199	Reserved		
200	Reserved		

No.	Name	Description	Remark
201	Reserved		
202	Reserved		
203	Reserved		
204	Reserved		
205	Reserved		
206	Reserved		
207	Reserved		
208	Voltage Asynchrony		
209	Frequency Asynchrony		
210	Phase Asynchrony		
211	AI1 Fault		
212	AI2 Fault		
213	Bustie Series Switch 0 Feedback Fault		
214	Bustie Series Switch 1 Feedback Fault		
215	Bustie Series Switch 2 Feedback Fault		
216	Bustie Series Switch 3 Feedback Fault		
217	Bustie Series Switch 4 Feedback Fault		
218	Bustie Series Switch 5 Feedback Fault		
219	HC1 Feedback Failure		
220	HC2 Feedback Failure		
221	HC3 Feedback Failure		
222	HC4 Feedback Failure		
223	Shore Switch Feedback Failure		
224	HC1 Request Failure		
225	HC2 Request Failure		
226	HC3 Request Failure		
227	HC4 Request Failure		
228	Switch Error		
229	IP Address Error		
230	Reserved		
231	SLD Configuration Error		
232	Shore Switch 0 Feedback Fault		
233	Shore Switch 1 Feedback Fault		
234	Shore Switch 2 Feedback Fault		
235	Shore Switch 3 Feedback Fault		
236	Ring Disconnect		

No.	Name	Description	Remark
237	DG Inactive IN Fault		
238	Bus Unavailable Close IN Fault		
239	Reserved		
240	Current THD 1		
241	Current THD 2		
242	Voltage SHD 1		
243	Voltage SHD 2		
244	Current SHD 1		
245	Current SHD 2		
246	Gen Vector Shift 1		
247	Gen Vector Shift 2		
248	Reserved		
249	Reserved		
250	Reserved		
251	Reserved		
252	Reserved		
253	Reserved		
254	Reserved		
255	Reserved		

## 12.10 ANALOG OUTPUT PORTS SETTING

**Table 38 – Analog Output Ports Setting**

No.	Item	Range	Default	Description	
Analog Output Ports					
Analog Output Port 1					
1	Function	(0-4)	1	0: Not used 1: GOV 2: AVR 3: Transmitter	
2	Output Type	(0-0)	0	0: Current	
3	Transmitter Config.	Config	(0-20)	0	Refer to <u>Transmitter Configuration Functions</u> .  Transmitter configuration min value corresponds to output min value, max value corresponds to output max value.
4		OUT Min.	(-20.0-20.0)mA	4	
5		OUT Max.	(-20.0-20.0)mA	20	
6		Config Min.	(-1000-32000)	0	
7		Config Max.	(-1000-32000)	500	
Analog Output Port 2					
8	Function	(0-4)	2	0: Not used	

No.	Item	Range	Default	Description	
				1: GOV 2: AVR 3: Transmitter	
9	Output Type	(0-0)	0	0: Current	
10	Transmitter Config.	Config	(0-20)	0	Refer to <u>Transmitter Configuration Functions</u> .
11		OUT Min.	(-20.0-20.0)mA	4	Transmitter configuration min value corresponds to output min value, max value corresponds to output max value.
12		OUT Max.	(-20.0-20.0)mA	20	
13		Config Min.	(-1000-32000)	0	
14		Config Max.	(-1000-32000)	500	
<b>Analog Output Port 3</b>					
15	Function	(0-4)	0	0: Not used 1: GOV 2: AVR 3: Transmitter	
16	Output Type	(0-0)	0	0: Current	
17	Transmitter Config.	Config	(0-20)	0	Refer to <u>Transmitter Configuration Functions</u> .
18		OUT Min.	(-20.0-20.0)mA	4	Transmitter configuration min value corresponds to output min value, max value corresponds to output max value.
19		OUT Max.	(-20.0-20.0)mA	20	
20		Config Min.	(-1000-32000)	0	
21		Config Max.	(-1000-32000)	500	
<b>Analog Output Port 4</b>					
22	Function	(0-4)	0	0: Not used 1: GOV 2: AVR 3: Transmitter	
23	Output Type	(0-0)	0	0: Current	
24	Transmitter Config.	Config	(0-20)	0	Refer to <u>Transmitter Configuration Functions</u> .
25		OUT Min.	(-20.0-20.0)mA	4	Transmitter configuration min value corresponds to output min value, max value corresponds to output max value.
26		OUT Max.	(-20.0-20.0)mA	20	

No.	Item	Range	Default	Description
27	Config Min.	(-1000-32000)	0	
28	Config Max.	(-1000-32000)	500	

**Table 39 – Transmitter Configuration Functions**

No.	Name	Description
0	Not Used	Transmitter function is not used.
1	Bus Voltage	
2	Bus Frequency	
3	Bus Active Power	
4	Bus Reactive Power	
5	Bus Apparent Power	
6	Reserved	
7	Gen Voltage	
8	Gen Frequency	
9	Gen Active Power	
10	Gen Reactive Power	
11	Gen Apparent Power	
12	Gen Power Factor	
13	Gen A Phase Current	
14	Gen B Phase Current	
15	Gen C Phase Current	
16	Gen Max. Current	
17	Bus Left Power	
18	Gen Left Power	
19	Reserved	
20	PLC Variant X1	
21	PLC Variant X2	
22	PLC Variant X3	
23	PLC Variant X4	
24	PLC Variant X5	
25	PLC Variant X6	
26	Reserved	
27	Reserved	
28	Reserved	
29	Reserved	
30	Reserved	

**12.11 GB SETTING**

**Table 40 – GB Settings**

No.	Item	Range	Default	Description	
GB Setting					
1	Close Delay	(0-20.0)s	3.0	Close pulse width, it is continuous output when set to 0.	
2	Open Delay	(0-20.0)s	3.0	Open pulse width, it is continuous output when set to 0.	
3	Action Time	(0-2000)ms	100	Time for switch receives close signal to contact closes.	
4	Storage Time	(0-3000)ms	100	Coil storage time before actions.	
5	Semi-auto Intelligent Open	(0-1)	1	0: Disable; 1: Enable. When it is enabled, in semi-auto mode, it intelligently judges whether to open.	
6	Failure Setting	Enable	(0-1)	There is no corresponding signal for close/open feedback input port in switch close/open, and the alarm action for no corresponding signal inputs for other feedback signals (like current).	
7		Auto ACK	(0-1)		0: Disable
8		Alarm Self-lock	(0-1)		1: Enable
9		Action	(0-6)		0: Block
10	Feedback Fault Setting	Enable	(0-1)	Action in close/open feedback and switch real status are inconsistent.	
11		Auto ACK	(0-1)		0: Disable
12		Alarm Self-lock	(0-1)		0: Disable
13		Action	(0-6)		1: Warning
14	Solenoid Valve Close Time	(0-20.0)s	5.0	Close pulse width, it is continuous output when set to 0.	
15	Solenoid Valve Open Time	(0-20.0)s	5.0	Open pulse width, it is continuous output when set to 0.	

**NOTE:** If close feedback input port can't be detected when close command is sent and after close delay, controller will initiate close failure alarm. If there are other close signals (like there is current) besides close input port, controller will initiate close feedback fault. If open feedback input port can't be detected when open command is sent and after open delay, controller will initiate open failure alarm. If there are other open signals (like no current) besides close input port, controller will initiate open feedback fault.

**12.12 SYNCHRONIZATION SETTING**

**Table 41 – Synchronization Settings**

No.	Item	Range	Default	Description		
Synchronization Setting						
1	GOV Output	(0-2)	1	0: Internal relay; 1: Internal analog; 2: None.		
2	GOV Reverse Output Enable	(0-1)	0	0: Disable; 1: Enable.		
3	GOV Loading Action	(0-2)	1	0: None; 1: Adjust rated frequency; 2: Adjust center point.		
4	AVR Output	(0-2)	1	0: Internal relay; 1: Internal analog; 2: None.		
5	AVR Reverse Output Enable	(0-1)	0	0: Disable; 1: Enable.		
6	AVR Loading Action	(0-2)	1	0: None; 1: Adjust rated voltage; 2: Adjust center point.		
7	Load (P) Feedback Coefficient	(0-100)%	50	The proportion of load frequency adjustment PID coefficient in whole load active adjustment coefficient.		
8	Load (Q) Feedback Coefficient	(0-100)%	50	The proportion of load voltage adjustment PID coefficient in whole load reactive adjustment coefficient.		
9	Active Adjust. Limit	(0-50.0)%	30.0	The max adjustment deviation of current power from the target power value.		
10	Reactive Adjust. Limit	(0-50.0)%	30.0			
11	Active Distribution Weight	(0.0-200.0)%	100.0	The weight of power distribution. For example, when the active distribution weight is 50%, the current genset shares load according to 50% of rated power.		
12	Reactive Distribution Weight	(0.0-200.0)%	100.0			
13	Freq. Droop	Enable	(0-1)	0	When it is enabled, target frequency adjusts according to active load.	
14		No-load	(0.0-200.0)%			101.0
15		Full-load	(0.0-200.0)%			100.0
16	Volt Droop	Enable	(0-1)	0	When it is enabled, target voltage adjusts according to reactive load.	
17		No-load	(0.0-200.0)%			101.0
18		Full-load	(0.0-200.0)%			100.0
19	Dead Bus Voltage	(1.0-20.0)%	10.0	Bus is unavailable when bus voltage is below the dead bus voltage.		
20	Sync. Voltage Difference	(1.0-10.0)%	5.0	Voltage synchronization is considered when voltage difference percentage of gen and bus is lower than sync voltage difference.		
21	Sync. Positive Freq. Difference	(0-2.00)Hz	0.20	Frequency synchronization is considered when frequency difference of gen and bus is lower than sync positive frequency difference and greater than sync. negative frequency		
22	Sync. Negative Freq. Difference	(0-2.00)Hz	0.10			

No.	Item	Range	Default	Description
				difference.
23	Sync. Phase Difference	(0-20)°	10	Phase synchronization is considered when the initial phase difference of gen and bus is lower than sync phase difference.
24	Phase Compensation	(0-360.0)°	0.0	Phase difference compensation of gen and bus sampling.
25	Sync. Failure Time	(5.0-300.0)s	60.0	When synchronization signal is not detected within set sync. failure time, corresponding alarm will be initiated according to action type.
26	Sync. Failure Action	(0-6)	1	0: Block; 1: Warning; 2: Trip; 3: Trip and Stop; 4: Safety Trip; 5: Safety Trip and Stop; 6: Indication.
27	Start Options	(0-2)	0	0: Linear Start; 1: Duty Time Start.
28	Active Output Mode	(0-2)	0	0 Share Power Output 1 Fixed Power Output 2 Analog Control Output
29	Reactive Output Mode	(0-2)	0	0 Share Power Output 1 Fixed Power Output 2 Analog Control Output
30	Reserved Running Gensets	(1-16)	1	The minimum load running gensets on the bus.
31	Max On-grid Gensets	(0-16)	16	The maximum scheduling on-grid gensets on the current bus.
32	Priority Active	(0-1)	0	If it is disabled, power management function will not change bus genset start/stop status due to priority change. It will only be active when bus needs to schedule other gensets to start.
33	Top Priority	(0-1)	1	When it is enabled, press top priority key, the current genset will have the highest priority, other gensets will sort again; When it is disabled, only the current genset has the highest priority, other genset priority has no change.
34	System Mode	(0-1)	0	If it is enabled, all bus gensets controllers mode will be changed by switching mode (key or input port).
35	Duty Start Run	(0.1-100.0)h	5.0	When it is duty time start, genset with smallest running time will start first, the next genset with less running time will start when start time reaches set duty time. The running time here refers to the

No.	Item	Range	Default	Description
				accumulated running time of user A.
36	Bus Blackout Starts	(0-16)	0	Started gensets in bus blackout.
37	Bus Blackout Start Running Time	(0-3600)s	600	Continuous running time of started gensets in bus blackout.
38	Short Close Times	(0-1)	0	Again close times when short trip is detected.
39	Bus Blackout Mode	(0-2)	0	0 No Change 1 Semi-auto Mode 2 Auto Mode
40	Inhibit Blackout	(0-1)	0	0: Disable; 1: Enable. When it is enabled in auto mode, only one genset on the bus takes load, other general trip and stop alarm open except for overspeed, overfrequency, emergency trip and stop, overcurrent is inhibited. Fault genset can open after other normal gensets starting with load. In manual mode, when only one genset on the bus takes load, general trip, stop alarm open and stop and manual open and stop are inhibited.
41	Continuous Supply	(0-1)	0	0: Disable; 1: Enable. When it is enabled in auto mode, loading genset on the bus has trip and stop alarm, the genset can disconnect after other standby gensets start and close. If voltage/frequency trip or stop alarm occurs, the fault genset will open first after other normal gensets normally run and meet load conditions, then normal gensets will close.
42	Scheduling Start Mode	(0-3)	0	0: Active Power Percentage; 1: Left Active Power; 2: Apparent Power Percentage; 3: Left Apparent Power.
43	Max. Start Load Percentage	(0-100)%	80	Bus load percentage for scheduling other gensets to start.
44	Min. Stop Load Percentage	(0-100)%	60	Bus load percentage for scheduling other gensets to stop.
45	Left Start Power	(0-20000)kW	50	Bus left power for scheduling other gensets to start.
46	Left Stop Power	(0-20000)kW	80	Bus left power for scheduling other gensets to stop.

No.	Item	Range	Default	Description
47	Fast Start/stop	(0-1)	0	
48	Max Load PCT of Fast Start	(0-100)%	90	Bus load percentage for scheduling other gensets to start.
49	Min Load PCT of Fast Stop	(0-100)%	30	Bus load percentage for scheduling other gensets to stop.。
50	Left Fast Start Power	(0-20000)kW	30	Bus left power for scheduling other gensets to start.
51	Left Fast Stop Power	(0-20000)kW	100	Bus left power for scheduling other gensets to stop.

### 12.13 SYNCHRONOUS CALIBRATION

**Table 42 – Synchronous Calibration List**

No.	Item	Range	Default	Description
Synchronous Calibration				
1	Multi-set Comm. No.	(1-16)	2	Genset numbers on the network bus.
2	Comm. Alarm Action	(0-6)	1	Communication alarm action when the module on the network bus is less than set multi-set communication numbers.
3	Module ID	(0-15)	1	ID in the communication network. The ID should be unique throughout the whole communication network.
4	Priority	(0-15)	1	The smaller of the number, the higher of the priority.
5	GOV SW1	(0-20.00)	0	Default central current is 0mA.
6	GOV SW2	(0-20.00)	2.00	Default current range is (-3.0~+3.0)mA.
7	AVR SW1	(0-20.00)	0	Default central current is 0mA.
8	AVR SW2	(0-20.00)	2.00	Default current range is (-3.0~+3.0)mA.
Frequency Sync				
9	Frequency Difference	(0-1.00)Hz	0.10	Adjusting generator frequency to make it greater than the difference value of bus frequency, that is the sliding frequency difference of dynamic sync.
10	Analog Control	Gain	(0-2000)%	The internal analog is adjusted to control the engine speed before parallel connection.
11		Stability	(0-2000)%	
12		Change	(0-2000)%	
13	Relay Control	Period	(100-10000)ms	The internal relay is adjusted to control the engine speed before
14		Min Adjust	(10-1600)ms	

No.	Item	Range	Default	Description	
15		Pulse		parallel connection.	
		Gain	(0-30000)%		10
		Dead Band	(0-10.0)%		1.0
<b>Voltage Sync</b>					
17	Analog Control	Gain	(0-2000)%	The internal analog is adjusted to control the generator voltage before parallel connection.	
18		Stability	(0-2000)%		20
19		Change	(0-2000)%		0
20	Relay Control	Period	(100-10000)ms	The internal relay is adjusted to control the generator voltage before parallel connection.	
21		Min Adjust Pulse	(10-1600)ms		100
22		Gain	(0-30000)%		10
23		Dead Band	(0-10.0)%		1.0
<b>Phase Sync</b>					
24	Phase Stable Time		(0-20.0)s	2.0	It will close after phase synchronization and delay set value in static synchronization.
25	Analog Control	Gain	(0-2000)%	The internal analog is adjusted to control the generator phase before parallel connection.	
26		Stability	(0-2000)%		20
27		Change	(0-2000)%		0
28	Relay Control	Period	(100-10000)ms	The internal relay is adjusted to control the generator phase before parallel connection.	
29		Min Adjust Pulse	(10-1600)ms		100
30		Gain	(0-30000)%		10
31		Dead Band	(0-10.0)%		1.0
<b>Active Power Control</b>					
32	Voltage Control	Gain	(0-2000)%	The internal analog voltage is adjusted to control active power after parallel connection.	
33		Stability	(0-2000)%		20
34		Change	(0-2000)%		0
35	Relay Control	Period	(100-10000)ms	The internal relay is adjusted to control active power after parallel connection.	
36		Min, Adjust Pulse	(10-1600)ms		100
37		Gain	(0-30000)%		10
38		Dead Band	(0-10.0)%		1.0
<b>Reactive Power Control</b>					
39	Voltage Control	Gain	(0-2000)%	The internal analog voltage is adjusted to control reactive power after parallel connection.	
40		Stability	(0-2000)%		20
41		Change	(0-2000)%		0
42	Relay Control	Period	(100-10000)ms	The internal relay is adjusted to control reactive power after parallel connection.	
43		Min. Adjust Pulse	(10-1600)ms		100
44		Gain	(0-30000)%		10
45		Dead Band	(0-10.0)%		1.0

No.	Item	Range	Default	Description
46	Min. Load Percentage	(0-100.0)%	10.0	The active power percentage of the unit from soft unloaded to the opening.
47	Fixed Active Power%	(0-100.0)%	30.0	The percentage of active power output in fixed power mode.
48	Fixed Reactive Power Mode	(0-1)	0	0: Power Percentage; 1: Power Factor
49	Fixed Reactive Power%	(0-100.0)%	8.0	The percentage of reactive power output in fixed power mode.
50	Fixed Power Factor	(0-100.0)%	8.0	The genset power factor in fixed power mode.
<b>Fixed Active Power</b>				
51	Output Min. Value	(0-100)%	5	When the active load percentage of any one on-grid genset is lower than set min. value and continues min delay time, fixed power genset outputs in active power.
52	Output Min. Value Delay	(0-3600.0)s	0.5	
53	Output Max. Value	(0-100)%	95	When the active load percentage of any one on-grid genset is greater than set max. value and continues max delay time, fixed power genset outputs in active power.
54	Output Max. Value Delay	(0-3600.0)s	0.5	
<b>Fixed Reactive Power</b>				
55	Output Min. Value	(0-100)%	5	When the reactive load percentage of any one on-grid genset is lower than set min. value and continues min delay time, fixed power genset outputs in reactive power.
56	Output Min. Value Delay	(0-3600.0)s	0.5	
57	Output Max. Value	(0-100)%	95	When the reactive load percentage of any one on-grid genset is greater than set max. value and continues max delay time, fixed power genset outputs in reactive power.
58	Output Max. Value Delay	(0-3600.0)s	0.5	
<b>SG Fixed Power Mode</b>				
59	DG Min. On-load%	(0-100.0)%	0.0	When the controller works in both SG mode and fixed power mode, if the total load is lower than the active power of SG fixed output, DG takes the set value and the remaining power is carried by SG. If this value is 0, when the total power is lower than the fixed active power output of SG, DG does not

No.	Item	Range	Default	Description
				start with load.
60	SG Max. On-load%	(0-100.0)%	100.0	When the controller works in both SG mode and fixed power mode, if the total load is greater than the SG and DG fixed active power percentage, DG will be loaded to the fixed active power percentage, the remaining power will be loaded by SG as much as possible and the maximum load will be the setting value. If the total load is even greater, it will be balanced by SG and DG.
61	Max. Load% of SG Receiving	(0-100.0)%	100.0	When the controller works in both SG mode and load-receiving mode, if SG on-load mode is effective, the load must be lower than receiving rated power percentage (the setting value) before SG is closing.
62	DG Stop% When SG Receiving	(0-100.0)%	50.0	When the controller works in both SG mode and load-receiving mode, if SG on-load is effective, when SG on-load is greater than the setting value of the total load, DG will start unloading and stopping and DG will stop soft loading.
63	Max. No. of SG & DG Sync.	(1-16)	16	When SG is synchronized, the current limit number of on-grid DG is higher than the setting value, closing and grid connection of SG is not allowed.
64	Analog Control Inactive Action	(0-2)	0	1: Previous Power Output; 2: Fixed Power Value Output; 2: Share Power Output.

**12.14 ENGINE SETTING**

**Table 43 – Engine Parameter Settings**

No.	Item	Range	Default	Description
Engine Setting				
1	Controller Type	(0-7)	0	0: None; 1: HMC6000S; 2: HMC6000E; 3: HMC6000A; 4: HMC6000ED; 5: HMC6000EG; 6: HMC9000S; 7: HMC9000A.
2	Engine Controller	Action	(0-1)	0: Disable
3		Auto ACK	(0-1)	0: Disable
4		Alarm Self-lock	(0-1)	0: Disable
5		Delay Value	(0.1-3600.0)s	3.0
6		Alarm Type	(0-6)	1: Warning
7		Active Range	(0-20)	0: Always Active
				Communication failure setting of engine controller.

**12.15 DISPLAY SETTING**

**Table 44 – Display Parameter Settings**

No.	Item	Range	Default	Description	
Local Setting					
1	Comm. Address	(1-254)	0	RS485 communication address of display module.	
2	Backlight Time	(1-3600)s	300	When display module is not used for a long time, LCD backlight brightness should be adjusted to less.	
3	Brightness	(1-10)	10	10-level can be adjusted.	
4	Start Interface	(0-1)	1: Enable		
5	Start Interface Display Time	(1-3600)s	3		
6	Start Image			Only can be set in upper computer.	
7	RS485 Comm.	Baud Rate	(0-3)	2	0: 2400bps 1: 4800bps 2: 9600bps 3: 19200bps
8		Stop Bit	(0-1)	0	0: 2-bit

No.	Item	Range	Default	Description
				1: 1-bit
10	Network	(0-1)	1: Enable	
11	IP Address	(0-255)	192.168.0.188	
12	Subnet Mask	(0-255)	255.255.255.0	
13	Default Gateway	(0-255)	192.168.0.1	
14	DNS Address	(0-255)	192.168.0.1	
15	MAC Address	(0-255)		Each controller has different MAC.
16	Output Port Content	Alarm/Function (0-255)	Alarm 000	Not used
17	Output Port Output Type	(0-1)	0	0: Normally Open; 1: Normally Close.

**12.16 USER-DEFINED PROTOCOL FORM SETTING**

This only can be set by upper computer.

To facilitate user remote monitoring and reduce system communication bus pressure, address 3500-3999 is added to user-defined data mapping field. By configuring data address via upper computer, user can read data of user-defined sequence via address 3500-3999.

**Table 45 – User-defined Protocol Form**

Address	Item	Description	Bytes
3500	User-defined		2Bytes
3501	User-defined		2Bytes
3502	User-defined		2Bytes
3503	User-defined		2Bytes
3504	User-defined		2Bytes
3505	User-defined		2Bytes
3506	User-defined		2Bytes
3507	User-defined		2Bytes
3508	User-defined		2Bytes
3509	User-defined		2Bytes
3510	User-defined		2Bytes
3511	User-defined		2Bytes
3512	User-defined		2Bytes
3513	User-defined		2Bytes
3514	User-defined		2Bytes
3515	User-defined		2Bytes
3516	User-defined		2Bytes
3517	User-defined		2Bytes
3518	User-defined		2Bytes
3519	User-defined		2Bytes
3520	User-defined		2Bytes
3521	User-defined		2Bytes

Address	Item	Description	Bytes
3522-3999	User-defined		2*N

### 12.17 DIN16 SETTING

HPM6 can expand with two DIN16 modules (input expansion module), which has the same input functions with HPM6.

**Table 46 – DIN16 Parameter Settings**

No.	Items	Range	Default	Description
<b>Input Port 1</b>				
1.	Contents Setting	(0-150)	0	Not Used.
2.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 2</b>				
3.	Contents Setting	(0-150)	0	Not Used.
4.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 3</b>				
5.	Contents Setting	(0-150)	0	Not Used.
6.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 4</b>				
7.	Contents Setting	(0-150)	0	Not Used.
8.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 5</b>				
9.	Contents Setting	(0-150)	0	Not Used.
10.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 6</b>				
11.	Contents Setting	(0-150)	0	Not Used.
12.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 7</b>				
13.	Contents Setting	(0-150)	0	Not Used.
14.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 8</b>				
15.	Contents Setting	(0-150)	0	Not Used.
16.	Active Type	(0-1)	0	0: Close Activate; 1: Open Activate.
<b>Input Port 9</b>				
17.	Contents Setting	(0-150)	0	Not Used.

No.	Items	Range	Default	Description
18.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.
Input Port 10				
19.	Contents Setting	(0-150)	0	Not Used.
20.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.
Input Port 11				
21.	Contents Setting	(0-150)	0	Not Used.
22.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.
Input Port 12				
23.	Contents Setting	(0-150)	0	Not Used.
24.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.
Input Port 13				
25.	Contents Setting	(0-150)	0	Not Used.
26.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.
Input Port 14				
27.	Contents Setting	(0-150)	0	Not Used.
28.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.
Input Port 15				
29.	Contents Setting	(0-150)	0	Not Used.
30.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.
Input Port 16				
31.	Contents Setting	(0-150)	0	Not Used.
32.	Active Type	(0-1)	0	0: Close Activate;1: Open Activate.

 **NOTE:** Input port functions please refer to Input Port Function setting.

## 12.18 DOUT16 SETTING

HPM6 can expand with two DOUT16 modules (output expansion module), which has the same output functions with HPM6.

**Table 47 – DOUT16 Parameter Settings**

No.	Items	Parameter Range	Default	Description
<b>Output Port 1</b>				
1.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
2.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
<b>Output Port 2</b>				
3.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
4.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
<b>Output Port 3</b>				
5.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
6.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
<b>Output Port 4</b>				
7.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
8.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
<b>Output Port 5</b>				
9.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
10.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
<b>Output Port 6</b>				
11.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
12.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
<b>Output Port 7</b>				
13.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
14.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
<b>Output Port 8</b>				

No.	Items	Parameter Range	Default	Description
15.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
16.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 9				
17.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
18.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 10				
19.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
20.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 11				
21.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
22.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 12				
23.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
24.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 13				
25.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
26.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 14				
27.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
28.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 15				
29.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.
30.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close
Output Port 16				
31.	Contents Setting	Alarm/Function (0-255)	Alarm 000	Not Used.

No.	Items	Parameter Range	Default	Description
32.	Active Type	(0-1)	0	0: Normally Open 1: Normally Close

**NOTE:** Output port functions please refer to Output Port Function list in 11.8.

## 12.19 USER-DEFINED PROTOCOL SETTING

This item can only be set by the upper computer.

In order to coordinate with address 3500-3999 to obtain user-defined data, user-defined bus data can be configured via upper computer and controller can share all ID genset defined data (100) via network bus. Then users can read each ID genset data via address 3500-3999 to configure user-defined data address.

**Table 48 – User-defined Protocol**

Address	Item	Description	Bytes
0	User-defined		2Bytes
1	User-defined		2Bytes
2	User-defined		2Bytes
3	User-defined		2Bytes
4	User-defined		2Bytes
5	User-defined		2Bytes
6	User-defined		2Bytes
7	User-defined		2Bytes
8	User-defined		2Bytes
9	User-defined		2Bytes
10	User-defined		2Bytes
11	User-defined		2Bytes
12	User-defined		2Bytes
13	User-defined		2Bytes
14	User-defined		2Bytes
15	User-defined		2Bytes
16	User-defined		2Bytes
17	User-defined		2Bytes
18	User-defined		2Bytes
19	User-defined		2Bytes
20	User-defined		2Bytes
21	User-defined		2Bytes
22-99	User-defined		2*N

## 13. COMMISSIONING

### 13.1 STEP 1: SINGLE UNIT DEBUGGING

- a) Check the parameter configuration of the controller;
- b) Check the genset connections and MSC CAN connection lines between the units. (E.g. if 3 generators are correctly connected, main screen will display Module Number: 3).
- c) Start the genset in semi-auto mode, check if generator data is normal;
- d) Start the genset in semi-auto mode, check if switch opens and closes normally;
- e) Start the genset in semi-auto mode, after closing the breaker, check if generator frequency can be adjusted to the rated frequency (e.g. set the rated frequency as 52Hz/48Hz);
- f) Start the genset in semi-auto mode, after closing the breaker, check if generator voltage can be adjusted to the rated voltage (e.g. set the rated voltage as 440V/360V);
- g) Start the genset in semi-auto mode, after closing the breaker, check if power factor, active power and reactive power are normal; if abnormal, check generator voltage and current phase sequence, current transformer incoming line direction, current transformer secondary current dotted terminal.

### 13.2 STEP 2: SEMI-AUTO PARALLEL OPERATION OFF-LOAD

- a) Semi-auto close parallel sets, check whether units synchronization is balanced and breaker close impulse current is too high; if that, adjust synchronization control parameters appropriately;
- b) During parallel operation off load, check if there is no high circumfluence on HPM6 current screen;
- c) During parallel operation off load, check if the output of active and reactive power is equal to zero; if it is not, then check if there is power oscillation; if there is, adjust the gain and stability values of engine, or adjust engine GOV or generator AVR gain and stability potentiometer to avoid active and reactive power oscillation; output close to 0; if relay adjusts speed/voltage, the droop function of speed adjusting panel and voltage adjusting panel should be opened and make droop characteristics be consistent.

### 13.3 STEP 3: SEMI-AUTO PARALLEL OPERATION ON-LOAD

- a) Semi-auto close parallel sets, perform on-load test and check if active and reactive power is evenly distributed between all the gensets;
- b) Semi-auto close parallel sets, perform soft on-load test to see if there is high overshoot or power oscillation during this period; if there is, adjust load slope properly;
- c) Semi-auto close parallel sets, perform soft off-load test to see if genset breaker opens after reaching minimum set value (%);
- d) Semi-auto close parallel sets, perform impact load test and damp load test to check if there is power oscillation.

### 13.4 STEP 4: AUTOMATIC PARALLEL OPERATION


When the controller is in auto status, if there is no power on bus, it will carry out automatic parallel, start and stop operation.

- a) Start the genset which has the highest priority or shortest running time according to the start mode;
- b) The genset which has the second highest priority or second shortest running time will start if the load has exceeded the set value or the HC request value has exceeded the set value;


- c) After the genset has started up, synchronization, parallel and share load process will begin;
- d) The genset will stop according to the preset sequence if the load has fallen below the set value (light load input deactivates.)

## 14. INSTALLATION

Controller is split type design; HPM6D display module is panel mounted and it is fixed by 4 clips when installed while HPM6 master control module is fixed by M5×4 screw. The controller’s overall dimensions and cutout dimensions are as following:



**Fig.26 – HPM6D Display Module Installation Dimensions (Unit: mm)**



**Fig.27 – HPM6 Master Control Module Installation Dimensions (Unit: mm)**

### 1) Battery Voltage Input

**NOTE:** HPM6 controller can suit for widely range of battery voltage (8~35) VDC. The wire’s diameter must be over 1.5mm<sup>2</sup> and which is connected to B+ and B- of controller power.

### 2) Output and Expand Relays

**NOTE:** Outputs of controller are divided into passive output and active output. If need to expand the relays, please add freewheel diode to both ends of expand relay’s coils (when coils of relay have DC current) in order to prevent disturbance to controller or others equipment.

### 3) AC Input

 **NOTE:** Current input of controller must be connected to outside current transformer. And the current transformer's secondary side current must be 5A. At the same time, the phases of current transformer and input voltage must be correct. Otherwise, the current of collecting and active power maybe not correct.



**WARNING!** When there is load current, transformer's secondary side is prohibited to open circuit.

### 4) Withstand Voltage Test

 **CAUTION!** When controller has been installed in control panel, if need the high voltage test, please disconnect controller's all terminal connections, in order to prevent high voltage into controller and damage it.

SmartGen

**15. FAULT FINDING**

**Table 49 – Fault Finding**

Symptoms	Possible Solutions
Controller no response with power	Check power supply; Check controller connection wirings; Check DC fuse.
Controller GOV/AVR relay no response	Check whether GOV, AVR output is selected as internal relay output.
Controller GOV, AVR output error	Check setting of central point SW1 and range SW2; Check whether GOV, AVR output is selected as internal analog output.
Impact current too large in sync closing	Detect controller voltage sampling line or adjust synchronization parameters; Debug every unit based on the commissioning process.
Grid connected load of more than two units	Adjust load control parameters; Debug every unit based on the commissioning process.
Paralleling units cannot raise/drop power, or just can little raise/drop power	When the internal relay speed control, check whether the potentiometer is stuck or in limit, whether the speed control pulse width is too small at rated speed; When the internal analog speed control, SW1, SW2 set error, or adjust the speed control unit, EMC parameters.
Trip in running	Check related switch and its connections according to the information on LCD.
Genset is running while switch is not operating	Check if the output signal of the controller is matched with switch signal; Check the connections between switch and controllers.
MSC modules too few	Check whether MSC module number is correct; Detect if the MSC LINK communication is normal.
RS485 comm. abnormal	Check connections; Check setting of COM port is correct or not; Check RS485's connections of A and B is reverse connected or not; Check whether communication port of PC is normal.
Network monitoring comm.	Check connections; Check whether network IP, MAC address is correct.